LV power circuit breakers and switch-disconnectors **Masterpact NT and NW**









The Guiding System, the new way to create your electrical installations

A comprehensive offer of products with consistent design

The Guiding System is first and foremost a Merlin Gerin product offer covering all electrical distribution needs. However, what makes all the difference is that these products have been designed to operate togheter: mechanical and electrical compatibility, interoperability, modularity, communication. Thus the electrical installation is both optimised and more efficient: better continuity of supply, enhanced safety for people and equipment, guaranteed upgradeability, effective monitoring and control.

Tools to simplify design and implementation

With the Guiding System, you have a comprehensive range of tools - the Guiding Tools - that will help you increase your product knowledge and product utilisation. Of course this is in compliance with current standards and procedures. These tools include technical booklets and guides, design aid software, training courses, etc. and are regularly updated.

The Guiding System, combined with the know-how and creativity, allows optimised, reliable, open-ended and standard compliant installations

For a genuine partnership with you

Because each electrical installation is unique, there is no standard solution. With the Guiding System, the variety of combinations allows for genuine customisation solutions. You can create and implement electrical installations to meet your creative requirements and design knowledge. You and Merlin Gerin's Guiding System form a genuine partnership.

For more details on the Guiding System, consult www.merlin-gerin.com

A consistent design of offers from Medium Voltage to Ultra terminal

Discrimination guarantees

co-ordination between the

serial-connected circuit-

breakers. Should a fault occurs downstream, only the circuit-breaker placed immediately upstream from the fault will trip.



The temperature rise tests performed in the laboratory operating characteristics of guarantee safety and durability of installations.

All Merlin Gerin offers are designed according to electrical, mechanical and communication consistency rules.

The products express this consistency by their overall design and shared ergonomics.

Electrical consistency:

Each product complies with or enhances system performance at coordination level: breaking capacity, lsc, temperature rise, etc. for more safety, continuity of supply (discrimination) or economic optimisation (cascading).

The leading edge technologies employed in Merlin Gerin's Guiding System ensure high performance levels in discrimination and cascading of protection devices, electrodynamic withstand of switches and current distributors, heat loss of devices, distribution blocks and enclosures.

Likewise, inter-product ElectroMagnetic Compatibility (EMC) is guaranteed.



Prefabricated and tested solutions, upstream and downstream from the device complying with the IEC 60439-1 switchboard standard.



Canalis KT busbar trunking

on the Masterpact 3200 A

circuit-breaker.

Mechanical consistency:

Each product adopts dimensional standards simplifying and optimising its use within the system.

It shares the same accessories and auxiliaries and complies with global ergonomic choices (utilisation mode, operating mode, setting and configuration devices, tools, etc.) making its installation and operation within the system a simpler process.

Communication consistency:

Each product complies with global choices in terms of communication protocols (Modbus, Ethernet, etc.) for simplified integration in the management, supervision and monitoring systems.

Readyarent

Thanks to the use of standard Web technologies, you can offer your customers intelligent Merlin Gerin switchboards allowing easy access to information: follow-up of currents, voltages, powers, consumption history, etc.

Guiding Tools for more efficient design and implementation of your installations.

Guiding Tools allow optimised use of the Guiding System offers. They simplify life and increase productivity.

SM6

Medium voltage switchboard system from 1 to 36 kV

Satia

Ultra compact ML/LV substation from 250 to 630 kVA

Masterpact

Protection switchgear from 100 to 6300 A



Trihal MV/LV dry cast resin transformer from 160 to 5000 kVA



Evolis MV vacuum switchgear and components from 1 to 24 kV.

The Technical guide

These technical guides help you comply with installation standards and rules i.e.: The electrical installation guide, the protection guide, the switchboard implementation guide, the technical booklets and the co-ordination tables all form genuine reference tools for the design of highperformance electrical installations. For example, the LV protection co-ordination guide - discrimination and cascading optimises choice of protection and connection devices while also increasing markedly continuity of supply in the installations.



CAD software and tools

The CAD software and tools enhance productivity and safety. They help you create your installations by simplifying product choice through easy browsing in the Guiding System offers.

Last but not least, they optimise use of our products while also complying with standards and proper procedures.



Compact

Protection switchgear system from 100 to 630 A

Multi 9

Modular protection switchgear system up to 125 A

Prisma Plus

Functional system for electrical distribution switchboards up to 3200 A



Training

Training allows you to acquire the Merlin Gerin expertise (installation design, work with power on, etc.) for increased efficiency and a guarantee of improved customer service.

The training catalogue includes beginner's courses in electrical distribution, knowledge of MV and LV switchgear, operation and maintenance of installations, design of LV installations to give but a few examples.







The original Masterpact has set a new standard for power circuit breakers around the world.

Over the years, other major manufacturers have tried to keep up by developing products incorporating Masterpact's most innovative features, including the breaking principle, modular design and the use of composite materials.

Today, Schneider Electric continues to innovate with the new Merlin Gerin Masterpact NT and NW ranges.

In addition to the traditional features of power circuit breakers (withdrawability, discrimination and low maintenance), Masterpact now offers built-in communications and metering functions, all in optimised frame sizes.

Masterpact NT and NW incorporate the latest technology to enhance both performance and safety. Easy to install, with user-friendly, intuitive operation and environment-friendly design, they are, quite simply, circuit breakers of their time. Masterpact

General content

Presentation	6
Functions and characteristics	13
Dimensions and connection	59
Electrical diagrams	87
Installation recommendations	9 7
Additional characteristics	121
Catalogue numbers, spare parts and order form	127

New Masterpact, *new levels of performance*

Five performance levels



H1 - for industrial sites with high short-circuit levels or installations with two parallel-connected transformers.

H2 - high-performance for heavy industry where very high short-circuits can occur.

H3 - for incoming devices supplying critical applications requiring both high performance and a high level of discrimination.

L1 - for high current-limiting capability and a discrimination level (37 kA) as yet unequalled by any other circuit breaker of its type; intended for the protection of cable-type feeders or to raise the performance level of a switchboard when the transformer power rating is increased.





Masterpact can be integrated in a general supervision system to optimise installation operation and maintenance. The communication architecture is open, and may be upgraded for interfacing with any protocol.

Switch-disconnector versions

The switch-disconnectors are derived directly from the circuit breakers and offer the same features and performance levels. They are available in HA, NA and HF versions, depending on the models. The HF version includes instantaneous protection to prevent closing on a short-circuit. Once closed, the switch-disconnectors are unprotected and behave like ordinary switches. They are often used for busbar coupling.

Special applications

■ 1000 V AC:

□ Masterpact NW H10 circuit breakers and switch-disconnectors, 800 to 4000 A, 3P or 4P, drawout version and H10 circuit breaker performance level

□ Masterpact NW DC circuit breakers and switch-disconnectors, 1000 to 4000 A, fixed and drawout versions and N and H circuit breaker performance levels (see special DC catalogue no. ART10886)

right-hand neutral:

□ Masterpact NT630 to 1600 A and NW800 to 6300 A circuit breakers and switch-disconnectors, 4P, fixed and drawout versions and H1 and H2 circuit breaker performance levels

■ industrial environments with high concentrations of sulphur compounds (standard IEC 721-3-3):

□ Masterpact NW800 to 4000 A circuit breakers with corrosion protection, drawout version and H2 circuit breaker performance level

installation earthing:

□ Masterpact NW earthing switch, compatible with NW800 to 4000 A, 3P or 4P, drawout version with N1, H1, NA and HA performance levels.



3 frame sizes, 2 families

The new range of power circuit breakers includes two families:

Masterpact NT, the world's smallest true power circuit breaker, with ratings from 800 to 1600 A
 Masterpact NW, in two frame sizes, one from 800 to 4000 A and the other from 4000 A to 6300 A.





		NT 08	NT 10	NT 12	NT 16		
H1	42 kA						
H2	50 kA						
L1	150 kA						

Masterpact NW 800 to 4000 A



			NW 08	NW 10	NW 12	NW 16	NW 20	NW 25	NW 32	NW 40
N	11	42 kA					-			-
н	11	65 kA								
н	12	100 kA								
H 0074	13	150 kA								
۶-76 ۲-76	1	150 kA								

4000 to 6300 A









Optimised volumes

The smallest circuit breaker in the world

Masterpact NT innovates by offering all the performance of a power circuit breaker in an extremely small volume. The 70 mm pole pitch means a three-pole drawout circuit breaker can be installed in a switchboard section 400 mm wide and 400 mm deep.

Practical installation solutions

The new range improves upon all the installation solutions which have already made Masterpact a success. It has been designed to standardise switchboards, optimise volumes and simplify installation:

- incoming connection to top or bottom terminals
- no safety clearance required
- connection:
- □ horizontal or vertical rear connection
- □ front connection with minimum extra space
- $\hfill\square$ mixed front and rear connections
- 115 mm pole pitch on all versions
- no derating up to 55 °C and 4000 A.



Optimised volumes

Up to 4000 A, Masterpact NW circuit breakers are all the same size, the same as the old M08 to 32 range.

From 4000 A to 6300 A, there is just one size, much smaller than before.

Retrofit solutions

Special connections are available to replace a fixed or drawout Masterpact M08 to 32 with a Masterpact NW, without modifying the busbars or the door cut-out.

Ease of installation



Vertical front connection of a fixed Masterpact NW.

With optimised sizes, the Masterpact NT and NW ranges simplify the design of switchboards and standardise the installation of devices:

- a single connection layout for Masterpact NT
- three connection layouts for Masterpact NW:
- □ one from 800 to 3200 A
- □ one for 4000 A
- □ one up to 6300 A
 - identical connection terminals from 800 to 6300 A (Masterpact NW)

■ front connection requires little space because the connectors to not increase the depth of the device

rear connection to vertical or horizontal busbars simply by turning the connectors 90°.



Vertical and horizontal rear connection of a fixed Masterpact NW.



Connection to busbars.

Innovation



Filtered breaking

Greater dependability...

Filtered breaking



The patented new design of the arc chutes includes stainless-steel filters. The chutes absorb the energy released during breaking, thus limiting the stresses exerted on the installation. They filter and cool the gases produced, reducing effects perceptible from the outside.

Automatic unlatching



The automatic unlatching of the circuit breaker operating mechanism for high short-circuits extends performance up to 150 kA. It produces ultra-fast tripping for all short-circuits higher than 37 kA (L1) and 65 kA (H3). For lower short-circuits, the system does not react so that the control unit can provide total discrimination with downstream devices.

More intelligent trip units... Today, with the high speed of calculation, the small size of memories and advances in miniaturisation, trip units have become circuit breaker control units offering increasingly powerful functions. They accurately measure system parameters, instantly calculate values, store data, log events, signal alarms, communicate, take action, etc. The new Masterpact ranges, equipped with Micrologic control units, constitute both an extremely reliable protective device and an accurate measurement instrument.

User friendly...

Intuitive use...

Micrologic control units are equipped with a digital LCD display used in conjunction with simple navigation buttons. Users can directly access parameters and settings. Navigation between screens is intuitive and the immediate display of values greatly simplifies settings. Text is displayed in the desired language.

... backed by incomparable security



Protection functions are separate from the measurement functions and are managed by an ASIC electronic component. This independence guarantees immunity from conducted or radiated disturbances and ensures a high degree of reliability.

A patented "double setting" system for protection functions establishes: a maximum threshold set using the control-unit dials

■ fine adjustments via the keypad or remotely. The fine adjustments for thresholds (to within one ampere) and tripping delays (to within a fraction of a second) are displayed directly on the screen.

The control unit cover can be lead-sealed to prevent uncontrolled access to the dials and protect the settings.



Navigation buttons on a Micrologic P control unit.

Ready for the future

Compliance with environmental requirements

Schneider Electric fully takes into account environmental requirements, starting right from the design phase of every product through to the end of its service life:

 the materials used for Masterpact are not potentially dangerous to the environment
 the production facilities are non-polluting in

compliance with the ISO 14001 standard ■ filtered breaking eliminates pollution in the switchboard

■ the energy dissipated per pole is low, making energy losses insignificant

■ the materials are marked to facilitate sorting for recycling at the end of product service life.

Simple upgrading of installations

Installations change, power levels increase, new equipment is required and switchboards must be extended. Masterpact is designed to adapt to these changes:

■ all control units are interchangeable

communication with a supervision system is an option that may be added at any time

■ a reserve chassis can be pre-addressed so that system parameters do not have to be modified when

a drawout device is installed at a later date ■ any future changes to the products will be designed to ensure continuity with the current

ranges, thus simplifying installation upgrades.

Masterpact

Functions and characteristics

Presentation	6
General overview	14
Detailed contents	14
Circuit breakers and switch-disconnectors	16
NT06 to NT16 and NW08 to NW63	16
NT06 to NT16	18
NW08 to NW63	20
Micrologic control units Overview of functions Micrologic A "ammeter" Micrologic P "power" Micrologic H "harmonics" Accessories and test equipment	22 24 26 30 32
Communication	34
COM option in Masterpact	34
Overview of functions	35
Masterpact in a communication network	36
Masterpact and the MPS100 Micro Power Server	38
Connections	40
Overview of solutions	40
Optional accessories	41
Locking	44
On the device	44
On the chassis	45
Indication contacts	46
Remote ON / OFF	48
Remote tripping	51
Accessories	52
Source-changeover systems	53
Presentation	53
Mechanical interlocking	54
Electrical interlocking	55
Associated automatic controllers	56
Display modules	57
Dimensions and connection	59
Electrical diagrams	87
Installation recommendations	97
Additional characteristics	121
Catalogue numbers, spare parts and order form	127

General overview Detailed contents

This chapter describes all the functions offered by Masterpact NT and NW devices. The two product families have identical functions implemented using the same or different components depending on the case.



PB100763-56



Circuit breakers and switch-disconnectors page 16

ratings:

- □ Masterpact NT 630 to 1600 A
- □ Masterpact NW 800 to 6300 A
- circuit breakers type N1, H1, H2, H3, L1
- switch-disconnectors type NA, HA, HF
- 3 or 4 poles
- fixed or drawout versions
- option with neutral on the right
- protection derating.

Micrologic control units

Ammeter A

- 2.0 basic protection
- 5.0 selective protection
- 6.0 selective + earth-fault protection
- 7.0 selective + earth-leakage protection

Power meter P

- 5.0 selective protection
- 6.0 selective + earth-fault protection
- 7.0 selective + earth-leakage protection

Harmonic meter H

- 5.0 selective protection
- 6.0 selective + earth-fault protection
- 7.0 selective + earth-leakage protection
- external sensor for earth-fault protection
- rectangular sensor for earth-leakage protection
- setting options (long-time rating plug):
- □ low setting 0.4 to 0.8 x Ir
- □ high setting 0.8 to 1 x Ir
- without long-time protection
- external power-supply module
- battery module.

Communication

- COM option in Masterpact
- Masterpact in a communication network
- Masterpact and the Micro Power Server MPS100.

Connections

- rear connection (horizontal or vertical)
- front connection
- mixed connections
- optional accessories
- □ bare-cable connectors and connector shields
- terminal shields
- vertical-connection adapters
- □ cable-lug adapters
- □ interphase barriers
- spreaders
- □ disconnectable front-connection adapter
- □ safety shutters, shutter locking blocks, shutter position indication and locking.





page 22

DB101123

page 34



General overview Detailed contents







Locking

- pushbutton locking by padlockable transparent cover
- OFF-position locking by padlock or keylock
- chassis locking in disconnected position by keylock
- chassis locking in connected, disconnected
- and test positions
- door interlock (inhibits door opening with breaker
- in connected position)
- racking interlock (inhibits racking with door open)
- racking interlock between crank and OFF pushbutton
- automatic spring discharge before breaker removal
- mismatch protection.



page 44



Indication contacts

standard or low-level contacts:

- □ ON/OFF indication (OF)
- □ "fault trip" indication (SDE)

□ carriage switches for connected (CE) disconnected (CD) and test

- (CT) positions
- programmable contacts:
- □ 2 contacts (M2C)
- □ 6 contacts (M6C).





M2C contact.

DB101

page 48

Remote operation

- remote ON/OFF: □ gear motor
- □ XF closing or MX opening voltage releases
- □ PF ready-to-close contact
- □ options: RAR automatic or Res electrical remote reset
- BPFE electrical closing pushbutton
- remote tripping function:
- □ MN voltage release
- standard
- adjustable or non-adjustable delay
- □ or second MX voltage release.







MX, XF and MN volage releases.

Accessories

- auxiliary terminal shield
- operation counter
- escutcheon
- transparent cover for escutcheon
- escutcheon blanking plate.



page 52

Circuit breakers and switch-disconnectors NT06 to NT16 and NW08 to NW63

NT and NW selection criteria

	Masterpact	NT			Masterpact	NW		
	Standard appli	cations		Special applications	Standard applications			
	NT630-1600 H1	NT630-1600 H2	NT630-1000 L1	NT630-1600 H10	NW800-1600 N1	NW800-4000 H1		
Type of application	Standard applications with low short-circuit currents	Applications with medium-level short-circuit currents	Limiting circuit breaker for protection of cable-type feeders or upgraded transformer ratings	1000 V systems, e.g. mines and wind power	Standard applications with low short-circuit currents	Circuit breaker for industrial sites with high short-circuit currents		
Icu/Ics at 440 V	42 kA	50 kA	130 kA	-	42 kA	65 kA		
Icu/Ics at 1000 V	-	-	-	20 kA	-	-		
lcu/lcs at 500 V DC L/R < 15 ms	-	-	-	-	-	-		
Position of neutral	Left	Left	Left	Left	Left	Left or right		
Fixed	F	F	F	F	F	F		
Drawout	D	D	D	D	D	D		
Switch-disconnector version	Yes	No	No	Yes	Yes	Yes		
Front connection	Yes	Yes	Yes	Yes	Yes	Yes up to 3200 A		
Rear connection	Yes	Yes	Yes	Yes	Yes	Yes		
Type of Micrologic control unit	A, P, H	A, P, H	A, P, H	A, consult us for P and H	A, P, H	A, P, H		

Masterpact NT06 to NT16 installation characteristics

Circuit bre	eaker	NT06, NT08	, NT10		NT12, NT16							
Туре		H1	H2	L1	H10	H1	H2	H10				
Connection												
Drawout	FC	•	•				•	-				
	RC	-						•				
Fixed	FC	=		•				=				
	RC	•						-				
Dimensions (m	nm) H x W x D											
Drawout	3P	322 x 288 x 277										
	4P	322 x 358 x 277										
Fixed	3P	301 x 276 x 196										
	4P	301 x 346 x 196										
Weight (kg) (ap	oproximate)											
Drawout	3P/4P	30/39										
Fixed	3P/4P	14/18										

Masterpact NW08 to NW63 installation characteristics

Circuit bre	eaker	NW08, N	IW10, NV	V12, NW [·]	16		NW20						
Туре		N1	H1	H2	L1	H10	H1	H2	H3	L1	H10		
Connection													
Drawout	FC			-	-	-	•		-		-		
	RC												
Fixed	FC	-			-	-		-	-	-	-		
	RC	-		•	-	-			-	-	-		
Dimensions (n	nm) H x W x D	l i i i i i i i i i i i i i i i i i i i											
Drawout	3P	439 x 441 x 395											
	4P	439 x 556 x	395										
Fixed	3P	352 x 442 x	297										
	4P	352 x 537 x	297										
Weight (kg) (a	pproximate)												
Drawout	3P/4P	90/120											
Fixed	3P/4P	60/80											

(1) Except 4000 A.

Circuit breakers and switch-disconnectors NT06 to NT16 and NW08 to NW63

				Special applica	tions							
	NW800-4000 H2	NW2000-4000 H3	NW800-2000 L1	NW H10	NW H2 with anti- corrosion protection	NW1000-4000 DC N	NW1000-4000 DC H	NW earthing switch				
	High-performance circuit breaker for heavy industry with high short- circuit currents	Incoming device with very high performance for critical applications	Limiting circuit breaker for protection of cable-type feeders or upgraded transformer ratings	1000 V systems, e.g. mines and wind power	Environments with high sulphur contents	DC system	DC system	Installation earthing				
	100 kA	150 kA	150 kA	-	100 kA	-	-	-				
	-	-	-	50 kA	-	-	-	-				
	-	-	-	-	-	35 kA	85 kA	-				
	Left or right	Left	Left	Left	Left or right	-	-	-				
	F	-	-	-	-	F	F	-				
	D	D	D	D	D	D	D	D				
	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes				
	Yes up to 3200 A	Yes up to 3200 A	Yes up to 3200 A	No	Yes up to 3200 A	No	No	Yes up to 3200 A				
-	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes				
	A, P, H	A, P, H	A, P, H	A, consult us for P and H	A, P, H	DC Micrologic	DC Micrologic	-				

NW25, NW32,	NW40			NW40b, NW50	, NW63
H1	H2	H3	H10	H1	H2
 <mark>=</mark> (1)	(1)	<mark>=</mark> (1)	-	-	-
				•	
(1)	(1)	-	-	-	-
		-	-		
				479 x 786 x 395	
				479 x 1016 x 395	
				352 x 767 x 297	
				352 x 997 x 297	
				225/300	
				120/160	

Circuit breakers and switch-disconnectors NT06 to NT16

Common characteristics

Number of poles

Rated insulation voltage (V)



Impulse withstand voltage (kV)		Uimp	12		
Rated operational voltage (V AC 50/60	Hz)	Ue	690/1000		
Suitability for isolation		IEC 60947-2	—×I/		
Degree of pollution		IEC 60664-1	3		
Circuit-breaker character	istics as per l	EC 60947	/-2		
Rated current (A)		In	at 40 °C/50 °C (1)		
Rating of 4th pole (A)					
Sensor ratings (A)					
Type of circuit breaker					
Ultimate breaking capacity (kA rms)		lcu	220/415 V		
V AC 50/60 Hz			440 V		
			525 V		
			690 V		
			1000 V		
Rated service breaking capacity (kA rm	s)	lcs	% Icu		
Utilisation category	0)		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
Rated short-time withstand current (kA	rms)	low	0.5 s		
V AC 50/60 Hz	1110)	1011	1 e		
			3 6		
Integrated instantaneous protection (kA	$pook \pm 10\%$		53		
Pated making capacity (kA poak)		lom	220/415 V		
			440 \/		
V AC 50/60 HZ			440 V		
			525 V		
			690 V		
<u> </u>			1000 V		
Break time (ms) between tripping order	and arc extinction				
Closing time (ms)			-		
Circuit-breaker character	istics as per l	NEMA AB	1		
Breaking capacity (kA)			240 V		
V AC 50/60 Hz			480 V		
			600 V		
Switch-disconnector cha	racteristics as	s per IEC	60947-3 and Annex A		
Type of switch-disconnector					
Rated making capacity (kA peak)		lcm	220 V		
AC23A/AC3 category V AC 50/60 Hz			440 V		
			525/690 V		
			1000 V		
Rated short-time withstand current (kA	rms)	Icw	0.5 s		
AC23A/AC3 category V AC 50/60 Hz	- /		1 s		
			3.5		
Ultimate breaking capacity Icu (kA rms)	with an external pro	tection relay	690 V		
Maximum time delay: 350 ms	mar an oxionia pro	loolion rolay			
Mechanical and electrical	l durabilitv as	per IEC	60947-2/3 at In/le		
Service life Mechanical	with maintenance	•			
C/O cycles x 1000	without maintenan	се			
Type of circuit breaker		In (A)			
Rated current		C - 7			
C/O cycles x 1000 Electrical	without maintenand	ce	440 ∨ (4)		
IFC 60947-2			690 V		
			1000 V		
Type of circuit breaker or switch-dis	connector				
Rated operationnal current	,connector	ie (A)	AC23A		
	without mainter	22	440 \/ (4)		
UNU UYURS X TUUU ERECUTICAT	without maintenant	6	++v V V''		

3/4

1000

690V

AC3 (5)

380/415 V (kW)

440 V (kW)

440 V ⁽⁴⁾

690 V

le (A)

without maintenance

Ui

(1) 50 °C: rear vertical connected. Refer to temperature derating tables for other connection types.
(2) See the current-limiting curves in the "additional" characteristics" section. (3) SELLIM system. (4) Available for 480 V NEMA.

(5) Suitable for motor control (direct-on-line starting).

IEC 60947-3

Motor power

Rated operationnal current

C/O cycles x 1000 Electrical

IEC 60947-3 Annex M/IEC 60947-4-1

Type of circuit breaker or switch-disconnector

Circuit breakers and switch-disconnectors NT06 to NT16

Sensor selection													
Sensor rating (A)	250 ⁽¹⁾	400	630	800	1000	1250	1600						
Ir thresold setting(A)	100 to 250	160 to 400	250 to 630	320 to 800	400 to 1000	500 to 1250	640 to 1600						
(1) For NT02 rating, please consult us.													

NT06				NT08 NT10 N						NT12 NT16							
630				800				1000				1250			1600		
630				800				1000				1250			1600		
400 to 6	630			400 t	o 800			400 to	1000			630 to 1	250		800 to ⁻	600	
H1	H2	L1 ⁽²⁾	H10	1.1				1. I.I.				H1	H2	H10			
42	50	150	-									42	50	-			
42	50	130	-									42	50	-			
42	42	100	-									42	42	-			
42	42	25	-									42	42	-			
-	-	-	20									-	-	20			
100 %												100 %					
В	В	A	В									В	В	В			
42	36	10	20									42	36	20			
42	36	-	20									-	36	20			
24	20	-	_									24	20	-			
-	90	10 x In (3)	-									-	90	-			
88	105	330	-									88	105	-			
88	105	286	-									88	105	-			
88	88	220	-									88	88	-			
88	88	52	-									88	88	-			
-	-	-	42									-	-	42			
25	25	9	-									25	25	-			
< 50	-											< 50	-				
												1					
42	50	150										42	50				
42	50	100	_									42	50	_			
42	42	25	-									42	42	_			
12	12	20											12				
на	HA10											нл	HA10				
75	IIAIU											75	IIAIV				
75	_											75	_				
75	_											75	_				
15	10											15	42				
-	42											-	42				
36	20											36	20				
20	20											20	20				
20	20											20	20				
50												50					
05																	
∠5 12 5																	
12.5	U 2	14 1	10	L 1	U 2	11	LI10	U 1	⊔ 2	11	LI10	U 1	U 2	L 10	LI10	L 1	U 2
620	пг			000	п2	L1	пі	1000	пг	LI	піv	1250	пг	пі	1600	пі	Π <u>2</u>
6	6	3 _		6 00	6	3	_	6	6	3	_	6	6	_	1000	6	6
2	2	3 - 2		2	2	3 2	-	2	2	3	-	2	2	-	-	2	2
5	5	2 -	5	5	5	2	-	5	5	2	-	3	3	-	-	3	5
- H1/H2/k	-	- 0	.5	-	-	-	0.5	-	-	-	0.5	-	-	0.5	0.5	-	-
630				800				1000				1250			1600		
6				6				6				6			6		
3				3				3				3			3		
U H1/H2/4	HΔ			0				3				5			5		
500				630				800				1000			1000		
≤ 250				250 to 3	335			335 to 4	150			450 to 5	60		450 to 4	560	
≤ 300				300 to 4	100			400 to 5	500			500 to 6	30		500 to 6	630	
6												500 10 0			000101		

Circuit breakers and switch-disconnectors NW08 to NW63





Common characteristics		
Number of poles		3/4
Rated insulation voltage (V)	Ui	1000/1250
Impulse withstand voltage (kV)	Uimp	12
Rated operational voltage (V AC 50/60 Hz)	Ue	690/1150
Suitability for isolation	IEC 60947-2	-×-/
Degree of pollution	IEC 60664-1	4 (1000 V) / 3 (1250 V)
Circuit-breaker characteristics as per	IEC 60947	7-2
Rated current (A)		at 40 °C / 50 °C (1)
Rating of 4th pole (A)		
Sensor ratings (A)		
Type of circuit breaker		
Ultimate breaking capacity (kA rms)	lcu	220/415/440 V
V AC 50/60 Hz		525 V
		690 V
		1150 V
Rated service breaking capacity (kA rms)	lcs	% Icu
Utilisation category		
Rated short-time withstand current (kA rms)	lcw	1 s
V AC 50/60 Hz		3 s
Integrated instantaneous protection (kA peak ±10 %)		
Rated making capacity (kA peak)	lcm	220/415/440 V
V AC 50/60 Hz		525 V
		690 V
		1150 V
Break time (ms) between tripping order and arc extinction		
Closing time (ms)		
Circuit-breaker characteristics as per	NEMA AB	81
Breaking capacity (kA)		240/480 V
V AC 50/60 Hz		600 V
Unprotected circuit-breaker characte	ristics:	
Tripping by shunt trip as per IEC 60947-2		
Type of circuit breaker		

Type of circuit breaker			
Ultimate breaking capacity (kA rms) V AC 50/60 Hz	lcu	220690 V	
Rated service breaking capacity (kA rms)	lcs	% Icu	-
Rated short-time withstand current (kA rms)	lcw	1 s	
		3 s	
Overload and short-circuit protection with external prote short-circuit protection, maximum delay: 350 ms ⁽⁴⁾	ction relay:		

Rated making capacity (kA peak) V AC 50/60 Hz	lcm	220690 V	

Switch-disconnector characteristics as per IEC 60947-3 and Annex A

Type of switch-disconnector			
Rated making capacity (kA peak)	lcm	220690 V	
AC23A/AC3 category V AC 50/60 Hz		1150 V	
Rated short-time withstand current (kA rms)	lcw	0.5 s	
AC23A/AC3 category V AC 50/60 Hz		1 s	
		3.5	

Mechanical and electrical durability as per IEC 60947-2/3 at In/le

Service life	Mechanical	with maintenance		
C/O cycles x 1000		without maintenanc	е	
Type of circuit breaker			In (A)	
Rated current				
C/O cycles x 1000	Electrical	without maintenanc	e	440 V ⁽⁵⁾
IEC 60947-2				690 V
				1150 V
Type of circuit breaker	or switch-dis	sconnector	le (A)	
Rated operational curre	ent			AC23A
C/O cycles x 1000	Electrical	without maintenanc	e	440 V ⁽⁵⁾
IEC 60947-3				690 V
Type of circuit breaker	or switch-dis	sconnector	le (A)	
Rated operational curre	ent			AC3 ⁽⁶⁾
Motor power				380/415 V (kW)
				440 ∨ ⁽⁵⁾ (kW)
				690 V (kW)
C/O cycles x 1000	Electrical	without maintenanc	e	440/690 V ⁽⁵⁾
IEC 60947-3 Annex M/IEC	C 60947-4-1			

(1) 50 °C: rear vertical connected. Refer to temperature derating tables for other connection types.

(2) See the current-limiting curves in the "additional

characteristics" section.

(3) Equipped with a trip unit with a making current

of 90 kA peak. (4) External protection must comply with permissible thermal constraints of the circuit breaker (please consult us).

No fault-trip indication by the SDE or the reset button.

(5) Available for 480 V NEMA.

(6) Suitable for motor control (direct-on-line starting).

Circuit breakers and switch-disconnectors NW08 to NW63

Sensor selection													
Sensor rating (A)	250 ⁽¹⁾	400	630	800	1000	1250	1600	2000	2500	3200	4000	5000	6300
Ir thresold setting(A)	100	160	250	320	400	500	630	800	1000	1250	1600	2000	2500
	to 250	to 400	to 630	to 800	to 1000	to 1250	to 1600	to 2000	to 2500	to 3200	to 4000	to 5000	to 6300
(A) Fan AllAloo nation alagan anna													

(1) For NW02 rating, please consult us.

NW08	NW10	NW12	NW16		NW20					NW25	NW32	NW40		NW40b	NW50	NW63
800	1000	1250	1600		2000					2500	3200	4000		4000	5000	6300
800	1000	1250	1600		2000					2500	3200	4000		4000	5000	6300
400 to 800	400 to 1000	630 to 1250	800 to 1	600	1000 to 2	2000				1250 to 2500	1600 to 3200	2000 to	4000	2000 to 4000	2500 to 5000	3200 to 6300
N1	H1	H2	L1 ⁽²⁾	H10	H1	H2	H3	L1 ⁽²⁾	H10	H1	H2	H3	H10	H1	H2	
42	65	100	150	-	65	100	150	150	-	65	100	150	-	100	150	
42	65	85	130	-	65	85	130	130	-	65	85	130	-	100	130	
42	65	85	100	-	65	85	100	100	-	65	85	100	-	100	100	
-	-	-	-	50	-	-	-	-	50	-	-	-	50	-	-	
100 %					100 %					100 %				100 %		
В					В					В				В		
42	65	85	30	50	65	85	65	30	50	65	85	65	50	100	100	
22	36	50	30	50	36	75	65	30	50	65	75	65	50	100	100	
Without	Without	190	80	Without	Without	190	150	80	Without	Without	190	150	Without	Without	270	
88	143	220	330	-	143	220	330	330	-	143	220	330	-	220	330	
88	143	187	286	-	143	187	286	286	-	143	187	286	-	220	286	
88	143	187	220	-	143	187	220	220	-	143	187	220	-	220	220	
-	-	-	-	105	-	-	-	-	105	-	-	-	105	-	-	
25	25	25	10	25	25	25	25	10	25	25	25	25	25	25	25	
< 70					< 70					< 70				< 80		
42	65	100	150	-	65	100	150	150	-	65	100	150	-	100	150	
42	65	85	100	-	65	85	100	100	-	65	85	100	-	100	100	

	HA	HF ⁽³⁾	HA	HF ⁽³⁾	HA	HF ⁽³⁾	НА
	50	85	50	85	55	85	85
100 %			100 %		100 %		100 %
	50	85	50	85	55	85	85
	36	50	36	75	55	75	85
	Without	Without	Without	Without	Without	Without	Without
	105	187	105	187	121	187	187

NW08/N	W10/NW1	12		NW16			NW20)		NW25/	NW32/	NW40	NW40b/NW50/NW63
NA	HA	HF	HA10	HA	HF	HA10	HA	HF	HA10	HA	HF	HA10	HA
88	105	187	-	105	105 187 -		105	187	-	121	187	-	187
-	-	-	105	-	-	105	-	-	105	-	-	105	-
-	-	-	-	-	-	-	-	-	-	-	-	-	-
42	50	85	50	50 85 50 5		50	85	50	55	85	50	85	
-	36	50	50	50	50	50	50	50	50	55	75	50	85

25				20						10				
12.5				10						5				
N1/H1/H2	L1	H10		H1/H2	L1	H10	H1/H2	H3	H10	H1	H2			
800/1000/1	250/1600			2000			2500/32	00/4000		4000b/500	0/6300			
10	3	-		8	3	-	5	1.25	-	1.5	1.5			
10	3	-		6	3	-	2.5	1.25	-	1.5	1.5			
-	-	0.5	-	-	0.5	-	-	0.5	-	-				
H1/H2/NA	/HA/HF			H1/H2/	13/HA/H	IF		H1/H2/HA						
800/1000/1	250/1600			2000			2500/32	00/4000		4000b/5000/6300				
10				8			5			1.5				
10				6			2.5			1.5				
H1/H2/HA/	/HF			H1/H2/I	13/HA/H	IF								
800	1000	1250	1600	2000										
335 to 450	450 to 560	560 to 670	670 to 900	900 to 1	150									
400 to 500 500 to 630 500 to 800 800 to 1000					1000 to 1300									
≤ 800 800 to 1000 1000 to 1250 1250 to 1600					2000									
6					<u>.</u>									

Micrologic control units Overview of functions

All Masterpact circuit breakers are equipped with a Micrologic control unit that can be changed on site.

Control units are designed to protect Power circuits and loads. Alarms may be programmed for remote indications. Measurements of current, voltage, frequency, power and power quality optimise continuity of service and energy management.

Dependability

Integration of protection functions in an ASIC electronic component used in all Micrologic control units guarantees a high degree of reliability and immunity to conducted or radiated disturbances.

On Micrologic A, P and H control units, advanced functions are managed by an independent microprocessor.

Micrologic name codes



X: type of protection

- 2 for basic protection
- 5 for selective protection
- 6 for selective + earth-fault protection
- 7 for selective + earth-leakage protection.

Y: control-unit generation

Identification of the control-unit generation. "0" signifies the first generation.

Z: type of measurement

- A for "ammeter"
- P for "power meter"
- H for "harmonic meter".



Current protection

Micrologic 2: basic protection



Micrologic 5: basic protection



Protection: long time + short time + instantaneous

Micrologic 6: selective + earth-fault protection



Protection:

- long time
- + short time
- + instantaneous
- + earth fault

Micrologic 7: selective + earth-leakage protection

⁵⁰ t

0

lΔn



+ earth leakage

Isd

Hi

DB101117

0 Ir

Micrologic control units Overview of functions

Measurements and programmable protection

A: ammeter

■ I1, I2, I3, IN, Iearth-fault, Iearth-leakage and maximeter for these measurements

- fault indications
- settings in amperes and in seconds.
 - P: A + power meter + programmable protection
 - measurements of V, A, W, VAR, VA, Wh, VARh, VAh, Hz, V_{peak}, A_{peak}, power factor and maximeters and minimeters
 IDMTL long-time protection, minimum and maximum voltage and frequency, voltage and current imbalance, phase sequence, reverse power
 - Ioad shedding and reconnection depending on power or current

measurements of interrupted currents, differentiated fault indications, maintenance indications, event histories and time-stamping, etc.

H: P + harmonics

- power quality: fundamentals, distortion, amplitude and phase of harmonics up to the 31st order
- waveform capture after fault, alarm or on request
- enhanced alarm programming: thresholds and actions.



Micrologic control units Micrologic A "ammeter"

Micrologic A control units protect power circuits.

They also offer measurements, display, communication and current maximeters. Version 6 provides earth-fault protection, version 7 provides earth-leakage protection.



Long-time current setting and tripping delay.

- Overload signal (LED) at 1.125 lr. Short-time pick-up and tripping delay. 2 3
- 4 Instantaneous pick-up.
- Earth-leakage or earth-fault pick-up and tripping delay. 5 Earth-leakage or earth-fault test button. 6
- Long-time rating plug screw.
- 7 8 Test connector.
- Lamp test, reset and battery test. 9
- 10 Indication of tripping cause.
- 11 Digital display.
- 12 Three-phase bargraph and ammeter.
- 13 Navigation buttons.

Protection settings

Protection thresholds and delays are set using the adjustment dials.

×

The selected values are momentarily displayed in amperes and in seconds.

Overload protection

True rms long-time protection.

Thermal memory: thermal image before and after tripping.

Setting accuracy may be enhanced by limiting the setting range using a different long-time rating plug.

The long-time rating plug "OFF" enables to cancel the overload protection.

Short-circuit protection

Short-time (rms) and instantaneous protection.

Selection of l²t type (ON or OFF) for short-time delay.

Earth fault protection

Residual or source ground return.

Selection of I²t type (ON or OFF) for delay.

Residual earth-leakage protection (Vigi).

Operation without an external power supply.

 \sim DC-component withstand class A up to 10 A.

Neutral protection

On three-pole circuit breakers, neutral protection is not possible.

On four-pole circuit breakers, neutral protection may be set using a three-position switch: neutral unprotected (4P 3d), neutral protection at 0.5 In (4P 3d + N/2), neutral protection at In (4P 4d).

Zone selective interlocking (ZSI)

A ZSI terminal block may be used to interconnect a number of control units to provide total discrimination for short-time and earth-fault protection, without a delay before tripping.



Micrologic A control units measure the true rms value of currents.

They provide continuous current measurements from 0.2 to 20 In and are accurate to within 1.5% (including the sensors).

A digital LCD screen continuously displays the most heavily loaded phase (Imax) or displays the I_1 , I_2 , I_3 , I_N , I_g , $I_{\Delta n}$, stored-current (maximeter) and setting values by successively pressing the navigation button.

The optional external power supply makes it possible to display currents < 20 % In. Below 0.05 In, measurements are not significant. Between 0.05 and 0.2 In, accuracy is to within 0.5% In + 1.5% of the reading.

Communication option

In conjunction with the COM communication option, the control unit transmits the following:

- setting values
- all "ammeter" measurements
- tripping causes
- maximeter reset.

Note: Micrologic A control units come with a transparent leadseal cover as standard.

Micrologic control units Micrologic A "ammeter"

Protection			Mic	rolo	nic 2	ΟΔ									<u>*</u>
					910 2							+ /			
Current setting (A)	lr – lo v		0.4	0.5	0.6	07	0.8	0 0	0.95	0.08	1		l 📥 Ir		
Tripping between 1.05 and 1.20 x	lr		Other	range	o.u or die	sable h	v chan	nina lor	na-time	rating	nlua	011.2	Í I		
Time setting		tr (s)	0.5	1	2	4	8	12	16	20	24	- B	í l		
Time delay (s)	Accuracy: 0 to -30 %	1.5 x lr	12.5	25	50	100	200	300	400	500	600		h tr		
	Accuracy: 0 to -20 %	6 x lr	0.7(1)	1	2	4	8	12	16	20	24		🚶 "		
	Accuracy: 0 to -20 %	7.2 x lr	0.7(2)	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6				
Thermal memory			20 mi	nutes	before	and aft	er tripp	ina				-	<	📥 Isd	
(1) 0 to -40 % - (2) 0 to -60 %			-					5				- 0	i	<u> </u>	
Instantaneous												Ū			
Pick-up (A)	Isd = Ir x		1.5	2	2.5	3	4	5	6	8	10				
Accuracy: ±10 %															
Time delay			Max r	esetta	ble tim	e: 20 m	าร					-			
			Max b	oreak t	ime: 80) ms						_			
Ammotor			Mio	rala	~:~)										menu
	anto		IVIIC	roio	gic z	.U A									
Display from 20 to 200 % of Im	ICIIIS		14	10	12	IN									
Accuracy: 1 5 % (including conco	ro)		II No ou	IZ Williony	13		01.00) 0/ In)							
Accuracy: 1.5 % (including senso	15)		INO au	ixiliary	Source		e1>20	J % IN)				_			
			ii max	iz ma:	∧ із та	in ma	1.4					-			
Protection			Mic	rolo	aic 5	.0/6	6.0 / 7	7.0 A							- W
			Micr	ologic	50/6	50/70						+ 1			
Current setting (A)	lr – In x		0.4	0.5	06	07	0.8	09	0.95	0.98	1	<u> </u>	¦ ⇔lr		
Tripping between 1.05 and 1.20 x	II = 111 ×		Othor	range	o.u	0.1 cabla b	v chan	aina lor	0.55	rating	nlua	01127		1	$-I^2$ t on
Time setting	. 11	tr (s)	0.5	1	2	<u>4</u>	8	12	16	20	24	- 19	tr 🔥	N.	¥
Time delay (s)	Accuracy: 0 to -30 %	15 x lr	12.5	25	50	100	200	300	400	500	600	-	,	Ī	_I ² t off
Time delay (3)	Accuracy: 0 to -20 %	6 v Ir	0 7(1)	1	2	100	200	12	16	20	24			Isd	
	Accuracy: 0 to -20 %	7 2 y lr	0.7(2)	0 69	- 1 38	- 27	55	83	11	13.8	16.6			【 🔥 tsd	
Thermal memory	Accuracy. 0 10 -20 /0	1.2 × 11	20 mi	nutes l	hefore	and aft	er trinn	ina		15.0	10.0	-		· ∠ ∱_	Б
(1) 0 to -40 % - (2) 0 to -60 %			20 111	nates i		and an		ing				-		<u> </u>	
Short time												0			1
Pick-up (A)	lsd = lr x		15	2	25	3	4	5	6	8	10				
Accuracy: +10 %				-	2.0	0		0	•	0					
Time setting tsd (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4					-			
· · · · · · · · · · · · · · · · · · ·	Cottingo	l ² t On	-	0.1	0.2	0.3	0.4								
Time delay (ms) at 10 x Ir	tsd (max resettable tir	ne)	20	80	140	230	350					-			
(I ² t Off or I ² t On)	tsd (max break time)	- /	80	140	200	320	500								
Instantaneous															
Pick-up (A)	li = ln x		2	3	4	6	8	10	12	15	off				
Accuracy: ±10 %															
Time delay			Max r	esetta	ble tim	e: 20 m	IS					-			
			Max b	oreak t	ime: 80) ms									
Earth fault			Micro	ologic	6.0 A							t			
Pick-up (A)	lg = ln x		А	в	С	D	Е	F	G	Н	J	58		h	_l ² t on
Accuracy: ±10 %	In ≤ 400 A		0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	1011	∣ 🔶 ^{lg}	' <u>×</u>	_
	400 A < In < 1250 A		0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	B		ta	₋ l [∽] t off
	In ≥ 1250 A		500	640	720	800	880	960	1040	1120	1200			- -	
Time setting tg (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4					-			
		l²t On	-	0.1	0.2	0.3	0.4					0			>
Time delay (ms)	tg (max resettable tim	e)	20	80	140	230	350					_			
at In or 1200 A (I ² t Off or I ² t On)	tg (max break time)		80	140	200	320	500								
Residual earth leakage (Vigi)			Micro	ologic	7.0 A							t,			
Sensitivity (A)	l∆n		0.5	1	2	3	5	7	10	20	30	129			
Accuracy: 0 to -20 %												B101		Δt	
Time delay ∆t (ms)	Settings		60	140	230	350	800					_	1	/ -	
	Δt (max resettable times	ne)	60	140	230	350	800					0	 I		- ,
	Δt (max break time)		140	200	320	500	1000					_			-
- A						0.10	o / -								menu
Ammeter			MIC	rolo	gic 5	.076	0.077	.0 A							
Continuous current measurem	nents														
Display from 20 to 200 % of In	,		11 N	12	13	IN	Ig	I∆n							
Accuracy: 1.5 % (Including senso	15)		INO AU	ixillary	source	e (wner	ei>20	ע״ (n) עיי				_			
IVIAXITTELETS			i max	i i z ma:	х із та	x in ma	ix ig mai	k i∆n ma	XE						

Note: All current-based protection functions require no auxiliary source. The test / reset button resets maximeters, clears the tripping indication and tests the battery.

Micrologic control units Micrologic P "power"

Micrologic P control units include all the functions offered by Micrologic A. In addition, they measure voltages and calculate power and energy values. They also offer new protection functions based on currents, voltages, frequency and power reinforce load protection.



- 1 Long-time current setting and tripping delay.
- Overload signal (LED).
- 3 Short-time pick-up and tripping delay.
- 4 Instantaneous pick-up.
- Earth-leakage or earth-fault pick-up and tripping delay. 5
- 6 Earth-leakage or earth-fault test button.
- 7 Long-time rating plug screw.
- 8 Test connector.
- 9 Lamp + battery test and indications reset.
- 10 Indication of tripping cause.
- 11 High-resolution screen.
- 12 Measurement display.
- 13 Maintenance indicators.
- 14 Protection settings.
- 15 Navigation buttons.
- 16 Hole for settings lockout pin on cover.

Protection settings



(Ľ

E

The adjustable protection functions are identical to those of Micrologic A (overloads, short-circuits, earth-fault and earth-leakage protection).

Fine adjustment

Within the range determined by the adjustment dial, fine adjustment of thresholds (to within one ampere) and time delays (to within one second) is possible on the keypad or remotely using the COM option.

IDMTL (Inverse Definite Minimum Time lag) setting

Coordination with fuse-type or medium-voltage protection systems is optimised by adjusting the slope of the overload-protection curve. This setting also ensures better operation of this protection function with certain loads.

Neutral protection

On three-pole circuit breakers, neutral protection may be set using the keypad or remotely using the COM option, to one of four positions: neutral unprotected (4P 3d), neutral protection at 0.5 In (4P 3d + N/2), neutral protection at In (4P 4d) and neutral protection at 1,6 In (4P 3d + 1,6N). Neutral protection at 1,6 In is used when the neutral conductor is twice the size of the phase conductors (major load imbalance, high level of third order harmonics).

On four-pole circuit breakers, neutral protection may be set using a three-position switch or the keypad: neutral unprotected (4P 3d), neutral protection at 0.5 In (4P 3d + N/2), neutral protection at In (4P 4d). Neutral protection produces no effect if the long-time curve is set to one of the IDMTL protection settings.

Programmable alarms and other protection.....

Depending on the thresholds and time delays set using the keypad or remotely using the COM option, the Micrologic P control unit monitors currents and voltage, power, frequency and the phase sequence. Each threshold overrun is signalled remotely via the COM option. Each threshold overrun may be combined with tripping (protection) or an indication carried out by an optional M2C or M6C programmable contact (alarm), or both (protection and alarm).

Load shedding and reconnection.....

Load shedding and reconnection parameters may be set according to the power or the current flowing through the circuit breaker. Load shedding is carried out by a supervisor via the COM option or by an M2C or M6C programmable contact.

Measurements..... The Micrologic P control unit calculates in real time all the electrical values (V, A, W, VAR, VA, Wh, VARh, VAh, Hz), power factors and crest factors.

The Micrologic P control unit also calculates demand current and demand power over an adjustable time period. Each measurement is associated with a minimeter and a maximeter.

In the event of tripping on a fault, the interrupted current is stored. The optional external power supply makes it possible to display the value with the circuit breaker open or not supplied.

Histories and maintenance indicators.....

The last ten trips and alarms are recorded in two separate history files. Maintenance indications (contact wear, operation cycles, etc.) are recorded for local access.

Indication option via programmable contacts

The M2C (two contacts) and M6C (six contacts) auxiliary contacts may be used to signal threshold overruns or status changes. They can be programmed using the keypad on the Micrologic P control unit or remotely using the COM option.

Communication option (COM)

- The communication option may be used to:
- remotely read and set parameters for the protection functions
- transmit all the calculated indicators and measurements
- signal the causes of tripping and alarms
- consult the history files and the maintenance-indicator register.
- maximeter reset.

An event log and a maintenance register, stored in control-unit memory but not available locally, may be accessed in addition via the COM option.

Note: Micrologic P control units come with a non-transparent lead-seal cover as standard.

Micrologic control units Micrologic P "power"

Protection			Micrologic 5.0 / 6.0 / 7.0 P											- * *	
Long time (rms)			Micro	ologic	5.0/6	.0 / 7.0 P						t,	ما <u>ما</u>		
Current setting (A)	lr = ln x		0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	8	T."		
Tripping between 1.05 and 1.20 x	(Ir		Other	r range	es or di	sable by	changi	ng lon	g-time	rating (olug	1011			
Time setting		tr (s)	0.5	1	2	4	8	12	16	20	24	- 8	tr 🔪		
Time delay (s)	Accuracy: 0 to -30 %	1.5 x lr	12.5	25	50	100	200	300	400	500	600	-	X.		
	Accuracy: 0 to -20 %	6 x lr	0.7(1)	1	2	4	8	12	16	20	24			Isd	
	Accuracy: 0 to -20 %	7.2 x lr	0.7(2)	0.69	1.38	2.7	5.5	8.3	11	13.8	16.6			• Atsd	
IDMTL setting	Curve slope		SIT	VIT	EIT	HVFuse	DT					-			
Thermal memory			20 m	inutes	before	and after	r trippin	g				- 0			
(1) 0 to -40 % - (2) 0 to -60 %								-				_ 0)		1
Short time (rms)															
Pick-up (A)	Isd = lr x		1.5	2	2.5	3	4	5	6	8	10				
Accuracy: ±10 %															
Time setting tsd (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4					-			
	-	I ² t On	-	0.1	0.2	0.3	0.4								
Time delay (ms) at 10 Ir	tsd (max resettable tir	me)	20	80	140	230	350					-			
(I ² t Off or I ² t On)	tsd (max break time)		80	140	200	320	500								
Instantaneous															
Pick-up (A)	li = ln x		2	3	4	6	8	10	12	15	off				
Accuracy: ±10 %												≋ t.	4		
Time delay			Maxı	resetta	ble tim	ne: 20 ms						310 11.			on
			Max I	oreak t	time: 8	0 ms						ä	l 🔶 lg	' <u>}</u>	
Earth fault			Micro	ologic	6.0 P									ta ∟l"t	off
Pick-up (A)	lg = ln x		А	В	С	D	Е	F	G	Н	J			-	
Accuracy: ±10 %	In ≤ 400 A		0.3	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	_	· ·		
	400 A < In < 1250 A		0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9	1	0)		
	In ≥ 1250 A		500	640	720	800	880	960	1040	1120	1200				
Time setting tg (s)	Settings	I ² t Off	0	0.1	0.2	0.3	0.4					-			
		I ² t On	-	0.1	0.2	0.3	0.4								
Time delay (ms)	tg (max resettable tim	ne)	20	80	140	230	350					t			
at In or 1200 A (I ² t Off or I ² t On)	tg (max break time)		80	140	200	320	500					29	T		
Residual earth leakage (Vigi)			Micro	ologic	7.0 P							31011		Δt	
Sensitivity (A)	l∆n		0.5	1	2	3	5	7	10	20	30	ä		-	
Accuracy: 0 to -20 %												0			
Time delay ∆t (ms)	Settings		60	140	230	350	800					- (,		1
	Δt (max resettable tim	ne)	60	140	230	350	800					-			
	∆t (max break time)		140	200	320	500	1000								
															R.
						-	-								NY 1711

Alarms and other	protection	Micrologic 5.0 /	6.0 / 7.0 P	
Current		Seuil	Temporisation	t ≜
Déséquilibre de courant	Iunbalance	0.05 to 0.6 laverage	1 to 40 s	54
Max. de courant moyen	Imax demand : I1, I2, I3, IN,	0.2 In to In	15 to 1500 s	threshold
Earth fault alarm				threshold
	Ι÷	20 A to 1200 A	1 to 10 s	
Voltage				
Voltage unbalance	Uunbalance	2 to 30 % x Uaverage	1 to 40 s	delay 🖵 📜
Minimum voltage	Umin	100 to Umax between pha	ases 1.2 to 5 s	delay
Maximum voltage	Umax	Umin to 1200 between pha	ases 1.2 to 5 s	
Power				6 1/0/P/F
Reverse power	rP	5 to 500 kW	0.2 to 20 s	
Frequency				
Minimum frequency	Fmin	45 to Fmax	1.2 to 5 s	
Maximum frequency	Fmax	Fmin to 440 Hz	1.2 to 5 s	
Phase sequence				
Sequense (alarm)	ΔØ	Ø1/2/3 or Ø1/3/2	0.3 s	

Load sheddir	ng and reconnection	Micrologic 5.0 /	6.0 / 7.0 P	
Measured value		Seuil	Temporisation	t ≜
Current	I	0.5 to 1 Ir per phases	20 % tr to 80 % tr	\$
Power	Р	200 kW to 10 MW	10 to 3600 s	threshold



Note: all current-based protection functions require no auxiliary source. Voltage-based protection functions are connected to AC power via a voltage measurement input built into the circuit breaker.

Micrologic control units Micrologic P "power"



Default display.



Display of a voltage.



Display of a frequency.



Display of a tripping history.



Display of a maximum current.



Display of a power.



Display of a demand power.



Display after tripping

Navigation from one display to another is intuitive. The six buttons on the keypad provide access to the menus and easy selection of values. When the setting cover is closed, the keypad may no longer be used to access the protection settings, but still provides access to the displays for measurements, histories, indicators, etc.

Measurements.....

Instantaneous values

The value displayed on the screen is refreshed every second.

А

Minimum and maximum values of measurements are stored in memory (minimeters and maximeters).

1

2

Ν

X

3

Currents

I rms

	A	E-lault		E-leakaye	
I max rms	Α	1	2	3	Ν
	A	E-fault		E-leakage	
Voltages					
U rms	V	12	23	31	
V rms	V	1N	2N	3N	
U average rms	V	(U12 + U2	3 + U31) / 3		
U unbalance	%				
Power, energy					
P active, Q reactive, S apparent	W, Var, VA	Totals			
E active, E reactive, E apparent	Wh, VARh, VAh	Totals con	sumed - sup	plied	
		Totals con	sumed		
		Totals sup	plied		
Power factor	PF	Total			
Frequencies					
F	Hz				

Demand metering

The demand is calculated over a fixed or sliding time window that may be programmed from 5 to 60 minutes. According to the contract signed with the power supplier, an indicator associated with a load shedding function makes it possible to avoid or minimise the costs of overrunning the subscribed power. Maximum demand values are systematically stored and time stamped (maximeter).

Currents					
I demand	A	1	2	3	Ν
	A	E-fault		E-leakage	
I max demand	A	1	2	3	Ν
	A	E-fault		E-leakage	
Power					
P, Q, S demand	W, Var, VA	Totals			
P, Q, S max demand	W, Var, VA	Totals			

Minimeters and maximeters

Only the current and power maximeters may be displayed on the screen.

Histories The last ten trips and alarms are recorded in two separate history files that may be displayed on the screen.

- tripping history:
- □ type of fault
- □ date and time
- □ values measured at the time of tripping (interrupted current, etc.)
- alarm history:
- □ type of alarm
- □ date and time

□ values measured at the time of the alarm.

Maintenance indicators (with COM option).....

A number of maintenance indicators may be called up on the screen:

- contact wear
- operation counter:
- □ cumulative total
- □ total since last reset.

Micrologic control units Micrologic P "power"

æ	POW	ERLO		ystem	Manage	er Demo		I	144			
7	File	Eait	view	Setup	Contro	i <u>D</u> ispla	y <u>Heports</u>	100IS	window	Help		
9	0 -	۲	1			Sampling	Mode : MA	NUAL		conds 💌		
3=	()											
	-			1-								
	Time			Event						Module		†
	04/21/98	08-49	06	Net Server !	Shutriown	110	er i master	Leval	-	Prevail only Nati	ards.	
	04/21/98	08:49	:01	User Log O	at	Ŭŝ	ar : master	User	avel: 1	SMS-3000 Client		
	04/21/98	08:48:	:38	DB Table CI	tange	Us	er : master	TOD	Event Tasks	Alarm Setup		
	04/21/98	08:48:	30	DB Table CI	egner	Us	er : master	Tasks		Alarm Setup		
	04/21/98	08:45:	:16	DB Table Ci	sange	Us	er : master	TOD	Events	Alarm Setup		
	042130	00.39	19	Oser Log In	a a la	05	ST : ITTASSIEF	User	evel : 1	SWS-3000 Clen	i andi	
	04/21/98	08.33	06	Net Server	an. Satat		r ossus - Kay Pouli	u Leval	- 4	PowerLogic New	nort	
	0421/98	08:38	57	User Lon In				2010		EventiAlarmNet	work	
	04/21/98	08:30	44	Net Server :	Shutdown	Us	er : master	Leve	:1	PowerLogic Net	aork	
	04/21/98	08:24:	31	Security Ch	eck	Ke	Status : Key Foun	d		PowerLogic Netv	aork	
	04/21/98	08:24:	:30	Net server S	Started	Us	er : master	Leve	:1	PowerLogic Netv	aork	
	04/21/96	08:24:	:15	User Log N						Event/Alarm Net	work	
	042136	08:18:	307	IPU Error		Us	97 : NA	Euc.	US LL D	SMS-3000 Clen		
	04/21/98	07.643	100 55	DB Table CI	sange	US	ST - 1	Logg	ar Template Devic	es Logger Setup		
	04/21/08	07.53	-50	DB Table Ci	ange	100		Logg	or Tormolator	Logger Setup		
	042198	07.51	46	DB Table CI	aroa	Üs	er i mæster	Anole	o Levels Assiste	d Alarm Setup		
	04/21/98	07:51:	33	DB Table CI	eoner	Üs	er : master	Anelo	o Levels Templat	e Alarm Setup		
	04/21/98	07:51:	29	DB Table CI	hange	Us	er : master	Funct	ions	Alarm Setup		
	04/21/98	07:50:	17	DB Table CI	arga	Us	er : master	Digits	Levels Assigned	Alarm Setup		
	04/21/98	07:50:	:17	DB Table CI	ange	Us	er : master	Analo	g Levels Assigne	d Alarm Setup		
	042136	07:49:	13	Setup: Devi	ce name un	inge De	Ace : MicroLogic Br	eaker User	maszer	Device Setup		
	04/21/90	07-48-	-10	Satur: Devi	te Name Ch	U900 De	ice : Transformer I	eaner User	marier	Device Setup		
	04/21/98	07-48	22	Satury Devi	re Aridari	nge De	áce - Transformar T	arro liser	moster	Device Setup		
	04/21/98	07:46:	54	User Log In		Us	ar : master	User	Lave : 1	SMS-3000 Client		
	04/21/98	07:44:	:59	Security Ch	eck	Ke	Status : Key Foun	d		PowerLogic Netv	nork	
	04/21/98	07:44:	:59	Net Server !	Started	Us	er imaster	Leve	(1	PowerLogic Netv	aork	+
Re	adv					ONLINE	: DEMO	N	o working s	system	9:30	

Display of an event log on a supervisor.

With the communication option

Additional measurements, maximeters and minimeters

Certain measured or calculated values are only accessible with the COM communication option:

- I peak / √2, (I1 + I2 + I3)/3, I unbalance
- load level in % Ir
- total power factor.

The maximeters and minimeters are available only via the COM option for use with a supervisor.

Event log

- All events are time stamped.
- trips
- beginning and end of alarms
- modifications to settings and parameters
- counter resets
- system faults:
- fallback position
- thermal self-protection
- Ioss of time
- overrun of wear indicators
- test-kit connections
- etc.

Maintenance register

Used as an aid in troubleshooting and to better plan for device maintenance operations.

- highest current measured
- operation counter
- number of test-kit connections
- number of trips in operating mode and in test mode
- contact-wear indicator.

Additional technical characteristics

Setting the display language

System messages may be displayed in six different languages. The desired language is selected via the keypad.

Protection functions

All current-based protection functions require no auxiliary source. Voltage-based protection functions are connected to AC power via a voltage measurement input built into the circuit breaker.

Measurement functions

Measurement functions are independent of the protection functions.

The high-accuracy measurement module operates independently of the protection module, while remaining synchronised with protection events.

Measurement-calculation mode

measurement functions implement the new "zero blind time" concept which consists in continuously measuring signals at a high sampling rate. The traditional "blind window" used to process samples no longer exists. This method ensures accurate energy calculations even for highly variable loads (welding machines, robots, etc.)

energies are calculated on the basis of the instantaneous power values, in two manners:

□ the traditional mode where only positive (consumed) energies are considered □ the signed mode where the positive (consumed) and negative (supplied) energies are considered separately.

Accuracy of measurements (including sensors)

- voltage (V) 0.5 %
- current (A) 1.5 %
- frequency (Hz) 0.1 %

■ power (W) and energy (Wh) 2 %.

Stored information

The fine setting adjustments, the last 100 events and the maintenance register remain in the control-unit memory even when power is lost.

Time-stamping

Time-stamping is activated as soon as time is set manually or by a supervisor. No external power supply module is required (max. drift of 1 hour per year).

Reset

An individual reset, via the keypad or remotely, acts on alarms, minimum and maximum data, peak values, the counters and the indicators.



Micrologic control units Micrologic H "harmonics"

Micrologic H control units include all the functions offered by Micrologic P. Integrating significantly enhanced calculation and memory functions, the Micrologic H control unit offers in-depth analysis of power quality and detailed event diagnostics. It is intended for operation with a supervisor.



- In addition to the Micrologic P functions, the Micrologic H control unit offers:
- in-depth analysis of power quality including calculation of harmonics and the
- fundamentals
- diagnostics aid and event analysis through waveform capture
- enhanced alarm programming to analyse and track down a disturbance on the AC power system.

Measurements.....

- The Micrologic H control unit offers all the measurements carried out by Micrologic P, with in addition:
- phase by phase measurements of:
- □ power, energy
- □ power factors
- calculation of:
- □ current and voltage total harmonic distortion (THD)
- □ current, voltage and power fundamentals
- □ current and voltage harmonics up to the 31st order.

Instantaneous values displayed on the screen

Currents					
l rms	Α	1	2	3	N
	А	E-fault		E-leakage	
I max rms	А	1	2	3	Ν
	A	E-fault		E-leakage	
Voltages					
U rms	V	12	23	31	
V rms	V	1N	2N	3N	
U average rms	V	(U12 + U23	3 + U31) / 3		
U unbalance	%				
Power, energy					
P active, Q reactive, S apparent	W, Var, VA	Totals	1	2	3
E active, E reactive, E apparent	Wh, VARh, VAh	Totals cons	sumed - sup	plied	

	vvii, v/uxii, v/ui		ica Supplica	
		Totals consum	ned	
		Totals supplie	d	
Power factor	PF	Total 1	2	3
Frequencies				
F	Hz			

Power-quality indicators

Total fundamentals		U	I	Ρ	Q	S	
THD	%	U	I				
U and Iharmonics	Amplitude	3	5	7	9	11	13

Harmonics 3, 5, 7, 9, 11 and 13, monitored by electrical utilities, are displayed on the screen.

Demand measurements

Similar to the Micrologic P control unit, the demand values are calculated over a fixed or sliding time window that may be set from 5 to 60 minutes.

Currents						
I demand	A	1	2	3	Ν	
	А	E-fault		E-leaka	ge	
I max demand	A	1	2	3	Ν	
	A	E-fault		E-leaka	ge	
Power						
P, Q, S demand	W, Var, VA	Totals				
P, Q, S max demand	W, Var, VA	Totals				

Maximeters

Only the current maximeters may be displayed on the screen.

Histories and maintenance indicators

These functions are identical to those of the Micrologic P.

Note: Micrologic H control units come with a non-transparent lead-seal cover as standard.

Micrologic control units Micrologic H "harmonics"



Display of harmonics up to 21th order.



Waveform capture.



Log

With the communication option

Additional measurements, maximeters and minimeters

Certain measured or calculated values are only accessible with the COM communication option:

- I peak / √2 (I₁ + I₂ + I₃)/3, I_{unbalance}
- Ioad level in % Ir
- power factor (total and per phase)
- voltage and current THD
- K factors of currents and average K factor
- crest factors of currents and voltages
- all the fundamentals per phase
- fundamental current and voltage phase displacement
- distortion power and distortion factor phase by phase
- amplitude and displacement of current and voltage harmonics 3 to 31.

The maximeters and minimeters are available only via the COM option for use with a supervisor.

Waveform capture

The Micrologic H control unit stores the last 4 cycles of each instantaneous current or voltage measurement. On request or automatically on programmed events, the control unit stores the waveforms. The waveforms may be displayed in the form of oscillograms by a supervisor via the COM option. Definition is 64 points per cycle.

Pre-defined analogue alarms (1 to 53)

Each alarm can be compared to user-set high and low thresholds. Overrun of a threshold generates an alarm. An alarm or combinations of alarms can be linked to programmable action such as selective recording of measurements in a log, waveform capture, etc.

Event log and maintenance registers

The Micrologic H offers the same event log and maintenance register functions as the Micrologic P. In addition, it produces a log of the minimums and maximums for each "real-time" value.

Additional technical characteristics

Setting the display language

System messages may be displayed in six different languages. The desired language is selected via the keypad.

Protection functions

All current-based protection functions require no auxiliary source. Voltage-based protection functions are connected to AC power via a voltage measurement input built into the circuit breaker.

Measurement functions

Measurement functions are independent of the protection functions.

The high-accuracy measurement module operates independently of the protection module, while remaining synchronised with protection events.

Measurement-calculation mode

An analogue calculation function dedicated to measurements enhances the accuracy of harmonic calculations and the power-quality indicators. The Micrologic H control unit calculates electrical magnitudes using 1.5×10^{15} x ln dynamics (20×10^{15} Micrologic P).

Measurement functions implement the new "zero blind time" concept Energies are calculated on the basis of the instantaneous power values, in the traditional and signed modes.

Harmonic components are calculated using the discrete Fourier transform (DFT).

Accuracy of measurements (including sensors)

- voltage (V) 0.5 %
- current (A) 1.5 %
- frequency (Hz) 0.1 %
- power (W) and energy (Wh) 2 %
- total harmonic distortion 1 %

Stored information

The fine-setting adjustments, the last 100 events and the maintenance register remain in the control-unit memory even when power is lost.

Time-stamping

Time-stamping is activated as soon as time is set manually or by a supervisor no external power supply module is required (max. drift of 1 hour per year).

Reset

An individual reset, via the keypad or remotely, acts on alarms, minimum and maximum data, peak values, the counters and the indicators.

Micrologic control units Accessories and test equipment









External sensor for source ground return protection.





External sensors

External sensor for earth-fault and neutral protection

The sensors, used with the 3P circuit breakers, are installed on the neutral conductor for: neutral protection (with Micrologic P and H)

- residual type earth-fault protection (with Micrologic A, P and H)...
- The rating of the sensor (CT) must be compatible with the rating of the circuit breaker:
- NT06 to NT16: TC 400/1600
- NW08 to NW20: TC 400/2000
- NW25 to NW40: TC 1000/4000
- NW40b to NW63: TC 2000/6300.

For oversized neutral protection the sensor rating must be compatible with the measurement range: 1.6 x IN (available up to NW 40 and NT 16).

Rectangular sensor for earth-leakage protection

The sensor is installed around the busbars (phases + neutral) to detect the zerophase sequence current required for the earth-leakage protection. Rectangular sensors are available in two sizes.

- Inside dimensions (mm)
- 280 x 115 up to 1600 A for Masterpact NT and NW
- 470 x 160 up to 4000 A for Masterpact NW.

External sensor for source ground return protection

The sensor is installed around the connection of the transformer neutral point to earth and connects to the Micrologic 6.0 control unit via an MDGF module to provide the source ground return (SGR) protection.

Voltage measurement inputs

Voltage measurement inputs are required for power measurements (Micrologic P or H) and for earth-leakage protection (Micrologic 7...).

As standard, the control unit is supplied by internal voltage measurement inputs placed downstream of the pole for voltages between 220 and 690 V AC. On request, it is possible to replace the internal voltage measurement inputs by an external voltage input (PTE option) which enables the control unit to draw power directly from the distribution system upstream of the circuit breaker. An 3 m cable with ferrite comes with this PTE option.

Long-time rating plug

Four interchangeable plugs may be used to limit the long-time threshold setting range for higher accuracy.

The time delay settings indicated on the plugs are for an overload of 6 Ir (for further details, see the characteristics on pages 25 and 27).

As standard, control units are equipped with the 0.4 to 1 plug.

Setting ranges

Standard	lr = ln x	0.4	0.5	0.6	0.7	0.8	0.9	0.95	0.98	1	Ĵ
_ow-setting option	lr = ln x	0.4	0.45	0.50	0.55	0.60	0.65	0.70	0.75	0.8	
High-setting option	lr = ln x	0.80	0.82	0.85	0.88	0.90	0.92	0.95	0.98	1	
Off plug		No loi	ng-time	protec	tion (Ir	= In fo	r Isd se	etting)			

Important: long-time rating plugs must always be removed before carrying out insulation or dielectric withstand tests.

External 24 V DC power-supply module

The external power-supply module makes it possible to use the display even if the circuit breaker is open or not supplied (for the exact conditions of use, see the "electrical diagrams" part of this catalogue).

This module powers both the control unit (100 mA) and the M2C and M6C programmable contacts (100 mA).

With the Micrologic A control unit, this module makes it possible to display currents of less than 20 % of In.

With the Micrologic P and H, it can be used to display fault currents after tripping.

Characteristics

- power supply:
- □ 110/130, 200/240, 380/415 V AC (+ 10 % 15 %)

□ 24/30, 48/60, 100/125 V DC (+20 % -20 %)

output voltage: 24 V DC ± 5%, 200 mA; towards the end of 2004, the available output current will be increased from 200 mA to 1 A

- ripple < 1 %
- dielectric withstand : 3.5 kV rms between input/output, for 1 minute
- overvoltage category: as per IEC 60947-1 cat. 4.

Battery module

The battery module makes it possible to use the display even if the power supply to the Micrologic control unit is interrupted and still commucating with the supervisor.

Characteristics

- battery run-time: 12 hours (approximately)
- mounted on vertical backplate or symmetrical rail.

Micrologic control units Accessories and test equipment



M2C, M6C programmable contacts

These contacts are optional equipment for the Micrologic P and H control units. They are described with the indication contacts for the circuit breakers.

Characteristics			M2C/M6C
Minimum load			10 mA/24 V
Breaking capacity (A)	V AC	240	5
p.f.: 0.7		380	
	V DC	24	1.8
		48	1.5
		125	0.4
		250	0.15

M2C: 24 V DC power supplied by control unit (consumption 100 mA). M6C: external 24 V DC power supply required (consumption 100 mA).



Lead-seal cover

Spare parts

Lead-seal covers

A lead-seal cover controls access to the adjustment dials.

When the cover is closed:

■ it is impossible to modify settings using the keypad unless the settings lockout pin on the cover is removed

the test connector remains accessible

■ the test button for the earth-fault and earth-leakage protection function remains accessible.

Characteristics

- transparent cover for basic Micrologic and Micrologic A control units
- non-transparent cover for Micrologic P and H control units.

Spare battery

A battery supplies power to the LEDs identifying the tripping causes. Battery service life is approximately ten years.

A test button on the front of the control unit is used to check the battery condition. The battery may be replaced on site when discharged.

Test equipment

Hand-held test kit

The hand-held mini test kit may be used to:

check operation of the control unit and the tripping and pole-opening system by sending a signal simulating a short-circuit

■ supply power to the control units for settings via the keypad when the circuitbreaker is open (Micrologic P and H control units).

Power source: standard LR6-AA battery.

Full function test kit

The test kit can be used alone or with a supporting personal computer.

- The test kit without PC may be used to check:
- the mechanical operation of the circuit breaker
- the electrical continuity of the connection between the circuit breaker and the control unit
- operation of the control unit:
- □ display of settings
- □ automatic and manual tests on protection functions
- □ test on the zone-selective interlocking (ZSI) function
- □ inhibition of the earth-fault protection
- □ inhibition of the thermal memory.
- The test kit with PC offers in addition:
- the test report (software available on request).



Portable test kit

Communication COM option in Masterpact

The COM option is required for integration of the circuit breaker or switch-disconnector in a supervision system.

Masterpact uses the Digipact or Modbus communications protocol for full compatibility with the SMS PowerLogic electrical-installation management systems. An external gateway is available for communication on other networks:

- Profibus
- Ethernet...

Eco COM is limited to the transmission of metering data and does not allow the control of the circuit breaker.



Digipact "device" communication module.



Modbus "device" communication module.

Modbus "chassis"

communication module





For fixed devices, the COM option is made up of:

a "device" communication module, installed behind the Micrologic control unit and supplied with its set of sensors (OF, SDE , PF and CH micro-contacts) and its kit for connection to XF and MX1 communicating voltage releases.

For drawout devices, the COM option is made up of:

a "device" communication module, installed behind the Micrologic control unit and supplied with its set of sensors (OF, SDE, PF and CH micro-contacts) and its kit for connection to XF and MX1 communicating voltage releases

a "chassis" communication module supplied separately with its set of sensors (CE, CD and CT contacts).

Status indication by the COM option is independent of the device indication contacts. These contacts remain available for conventional uses.

Digipact or Modbus "Device" communication module

This module is independent of the control unit. It receives and transmits information on the communication network. An infra-red link transmits data between the control unit and the communication module.

Consumption: 30 mA, 24 V.

Digipact or Modbus "chassis" communication module

This module is independent of the control unit. With Modbus "chassis" communication module, this module makes it possible to address the chassis and to maintain the address when the circuit breaker is in the disconnected position. Consumption: 30 mA, 24 V.

XF and MX1 communicating voltage releases

The XF and MX1 communicating voltage releases are equipped for connection to the "device" communication module.

The remote-tripping function (MX2 or MN) are independent of the communication option. They are not equipped for connection to the "device" communication module.



- - "Chassis" communication module (option).
- 3 OF, SDE, PF and CH communicating "device" sensors.
- 4 CE, CD and CT communicating "chassis" sensors. MX1 and XF communicating release. 5
- 6



- Control unit.
Communication Overview of functions



The Masterpact circuit breakers and switch-disconnectors are compatible with the Digipact or Modbus COM option.

The COM option may be used to:

- identify the device
- indicate status conditions
- control the device.

Depending on the different types of Micrologic (A, P, H) control units, the COM option also offers:

setting of the protection and alarms functions

■ analysis of the AC-power parameters for operating-assistance and maintenance purposes.

	Switch-disconnector with		Circuit breaker with					
	communication bus		cor	communication bus				
	Digipact	Modbus	Digipact			Мо	dbus	5
Device identification								
Address	=	=	А	Ρ	Н	А	Р	н
Rating	-	-	А	Ρ	Н	А	Ρ	н
Type of device	-	-					Р	н
Type of control unit	-	-	А	Р	н	А	Р	н
Type of long-time rating plug	-	-	А	Р	Н	А	Р	н
Signalisation d'états								
ON/OFF OF	•	•	А	Ρ	Н	А	Р	н
Spring charged CH	•	•	А	Р	н	А	Р	н
Ready to close PF	•	•	А	Р	н	А	Р	н
Fault-trip SDE	-	-	A	Ρ	Н	A	Р	н
Connected/disconnected/ test position CE/CD/CT	•	•	A	Ρ	Н	A	Ρ	Н
Controls								
ON/OFF MX/XF	-	-	А	Ρ	Н	А	Р	н
Spring charging	-	-						
Reset of the mechanical	-	-						
indicator								
Protections and alarms	settings		_			_		
Reading of protections setting	gs		А	Ρ	Н	А	Ρ	н
Writing of fine settings in the range imposed by the adjustment dials							Ρ	н
Reading/writing of alarms							Р	Н
(load shedding and reconnec	t, M2C, etc.)							
Reading/writing of custom ala	arms							н
Operating and mainten	ance aids							
Measurement								
Current			A	Р	Н	А	Ρ	н
Voltages, frequency, power, e	etc.			Р	Н		Ρ	н
Power quality: fundamental, h	narmonics						_	н
Programming of demand met	ering						Р	н
Fault readings								
Type of fault						А	P	н
Interrupted current							Р	н
Waveform capture								
On faults								н
On demand or programmed								н
Histories and logs								
Trip history							Р	н
Alarm history							P	н
Event logs						Р	н	
Indicators								
Counter operation			А	Ρ	Н	A	Р	Н
Contact wear							Р	Н
Maintenance register					Р	Н		

Note: see the description of the Micrologic control units for further details on protection and alarms, measurements, waveform capture, histories, logs and maintenance indicators.

Communication Masterpact in a communication network



Devices

Circuit breakers equipped with Micrologic control units may be connected to either a Digipact or Modbus communication bus. The information made available depends on the type of Micrologic control unit (A, P or H) and on the type of communication bus (Digipact or Modbus).

Switch-disconnectors can be connected to the Digipact or Modbus communication bus. The information made available is the status of the switch-disconnector.

Communication bus

Digipact bus

The Digipact bus is the internal bus of the low-voltage switchboard in which the Digipact communicating devices are installed (Masterpact with Digipact COM, PM150, SC150, UA150, etc.). This bus must be equipped with a DC150 data concentrator (see the Powerlogic System catalogue).

Addresses

Addressing is carried out by the DC150 data concentrator.

Number of devices

The maximum number of devices that may be connected to the Digipact bus is calculated in terms of "communication points". These points correspond to the amount of traffic the bus can handle. The total number of points for the various devices connected to a single bus must not exceed 100.

If the required devices represent more than 100 points, add a second Digipact internal bus.

Communicating device	Number of points
DC150 data concentrator	4
Micrologic + Digipact COM	4
PM150	4
SC150	4
UA150	4

Length of bus

The maximum recommended length for the Digipact internal bus is 200 meters.

Bus power source

Power is supplied by the DC150 data concentrator (24 V).

Communication Masterpact in a communication network

Modbus bus

The Modbus RS485 (RTU protocol) system is an open bus on which communicating Modbus devices (Masterpact with Modbus COM, PM300, Sepam, Vigilohm, etc.) are installed. All types of PLCs and microcomputers may be connected to the bus.

Addresses

The Modbus parameters (address, baud rate, parity) are entered using the keypad on the Micrologic A, P or H. For a switch-disconnector, it is necessary to use the RSU (Remote Setting Utility) Micrologic utility.

The software layer of the Modbus protocol can manage up to 255 addresses (1 to 255).

- The "device" communication module comprises three addresses linked to:
- circuit-breaker manager
- measurement manager
- protection manager.

The "chassis" communication module comprises one address linked to:

■ the chassis manager.

The division of the system into four managers secures data exchange with the supervision system and the circuit-breaker actuators.

The manager addresses are automatically derived from the circuit-breaker address @xx entered via the Micrologic control unit (the default address is 47).

Logic addresses

•		
@xx	Circuit-breaker manager	(1 to 47)
@xx + 50	Chassis manager	(51 to 97)
@xx + 200	Measurement managers	(201 to 247)
@xx + 100	Protection manager	(101 to 147)

Number of devices

The maximum number of devices that may be connected to the Modbus bus depends on the type of device (Masterpact with Modbus COM, PM500, Sepam, Vigilohm, etc.), the baud rate (19200 is recommended), the volume of data exchanged and the desired response time. The RS485 physical layer offers up to 32

connection points on the bus (1 master, 31 slaves).

A fixed device requires only one connection point (communication module on the device).

A drawout device uses two connection points (communication modules on the device and on the chassis).

The number must never exceed 31 fixed devices or 15 drawout devices.

Length of bus

The maximum recommended length for the Modbus bus is 1200 meters.

Bus power source

A 24 V DC power supply is required (less than 20 % ripple, insulation class II).

Communication interface

The Modbus bus may be connected to the central processing device in any of three manners:

direct link to a PLC. The communication interface is not required if the PLC is equipped with a Modbus port

 direct link to a computer. The Modbus (RS485) / Serial port (RS232) communication interface is required

■ connection to a TCP/IP (Ethernet) network. The Modbus (RS485) / TCP/IP (Ethernet) communication interface is required.

Software

To make use of the information provided by the communicating devices, software with a Modbus driver must be used.

Micrologic utilities

This is a set of software that may be used with a PC to:

- display the variables (I, U, P, E, etc.) with the RDU (Remote Display Utility)
- read/write the settings with the RSU (Remote Setting Utility)

■ remotely control (ON / OFF) the device with the RCU (Remote Control Utility). Micrologic utilities are available upon request

SMS (System Manager Software)

SMS is a software to monitor LV and/or MV electrical energy.

- The SMS family includes a software range depending on the application and
- function, from single product monitoring to the management of a multiple building: Power Meter and Circuit Monitor units
- LV devices
- Sepam units.

Communication Masterpact and the MPS100 Micro Power Server

The MPS100 Micro Power Server: notifies maintenance staff when any preset alarm or trip is activated by the Micrologic trip unit, automatically sending an e-mail and/or SMS data logs are periodically forwarded

by e-mail the e-mails are sent via an Ethernet local

area network (LAN) or remotely via modem.





MPS100 Micro Power Server.



Main LV switchboard



Monitoring of your main LV switchboard via embedded web pages in the MPS100 accessible with a standard web browser.

Micro Power Server makes data collection easy for monitoring Masterpact/Compact circuit breakers

Now, more than ever, there is a need to monitor electrical distribution systems in industrial and large commercial applications. The key to managing all equipment, maximising efficiencies, reducing costs and increasing up time is having the right tools.

Micro Power Server MPS100 is designed to withstand harsh electrical environments and provide a consistent flow of easy to interpret information.

Micro Power Server is designed for unattended operation within the main LV switchboard

The MPS100 is a self-contained facility information server that serves as a standalone device for power system monitoring.

It is used to transfer power system information via a standard web browser over an Ethernet local area network (LAN) or via modem, making it possible to view power system information on a PC with an Ethernet connection.

In either capacity, the Micro Power Server functions as a web server for Micrologic trip unit and Power Meter (PM500) supervision, automatically notifying (e-mail and/or SMS) maintenance staff when any preset alarm or trip is activated in the Micrologic trip unit.

Benefits

■ view your main LV switchboard without installing software on your local PC, eliminating the need for a dedicated PC with specific software

- Micro Power Server allows centralised monitoring, so you no longer waste precious time walking around the facility to collect data
- view your main LV switchboard via a modem connection (GSM or switched network), avoiding the need for a LAN
- maintenance people are automatically notified at any time, wherever they are,
- so you do not have to stay in front of a monitor all day long
- data logs can be periodically forwarded by sending e-mails to the relevant people (maintenance, accounting, application service provider) automatically
- possibility to monitor/notify six external events (limit switches, auxiliary switches...)
- back-up of Micrologic trip unit settings in the memory of the MPS100, so you know where to retrieve it when necessary.



Communication Masterpact and the MPS100 Micro Power Server



Part numbers

MPS

100	Micro	Power	Server	

33507

.

..

Connections Overview of solutions

- *Three types of connection are available:* vertical or horizontal rear connection
- front connection
- mixed connection.

The solutions presented are similar in principle for all Masterpact NT and NW fixed and drawout devices.

Rear connection

Horizontal

PB100783-40



Vertical

Simply turn a horizontal rear connector 90° to make it a vertical connector. For the 6300 A circuit breaker, only vertical connection is available.

Front connection



Front connection is available for NW fixed and drawout versions up to 3200 A.

Mixed connection







Note: Masterpact circuit breakers can be connected indifferently with bare-copper, tinned-copper and tinned-aluminium conductors, requiring no particular treatment.

Connections Optional accessories

Turne of economic	Magternast		Masterpast NW/08 to NW/62						
Type of accessory	Wasterpact N	106 to N116	Drawout		Fixed Drowout				
	Front	Pear	Front	Pear	Front	Rear	Front	Poar	
	connection	connection	connection	connection	connection	connection	connection	connection	
Vertical connection adapters	DB101156		DBH01156						
Cable lug adapters	DB101147								
Interphase barriers	8411018C	(1)		61)		6811018C		67 LIDING	
Spreaders								5	
	DB101150		DB101150						
Disconnectable front-connection adapter									
Safety shutters with padlocking			DB101152				DBH01153		
Shutter position indication and locking							DB101154	A. C.	
Arc chute screen	(3)	(4)							

(1) Mandatory for voltages > 500 V.

(2) Except for an NW40 equipped for horizontal rear

 (a) Labor to an inverse of approximation of the analysis of the a the front.

(4) Mandatory for 1000 V.

Masterpact M replacement kit

A set of connection parts is available to allow replacement of a Masterpact M08 to M32 circuit breaker by a Masterpact NW without modifying the busbars (please consult us).

Mounting on a switchboard backplate using special brackets

Masterpact NT and NW fixed front-connected circuit breakers can be installed on a backplate without any additional accessories.

Masterpact NW circuit breakers require a set of special brackets.

Connections Optional accessories



Connections Optional accessories



Disconnectable front-connection adapter

Mounted on a fixed front-connected device, the adapter simplifies replacement of a fixed device by enabling fast disconnection from the front.



Safety shutters

Mounted on the chassis, the safety shutters automatically block access to the disconnecting contact cluster when the device is in the disconnected or test positions (degree of protection IP 20) When the device is removed from its chassis, no live parts are accessible.

The shutter-locking system is made up of a moving block that can be padlocked (padlock not supplied). The block:

- prevents connection of the device
- locks the shutters in the closed position.

For Masterpact NW08 to NW63

A support at the back of the chassis is used to store the blocks when they are not used:

- 2 blocks for NW08 to NW40
- 4 blocks for NW40b to NW63.

Shutter position indication and locking on front face

This option located on the chassis front plate indicates that the shutters are closed. It is possible to independently or separately padlock the two shutters using one to three padlocks (not supplied).



Locking On the device





Access to pushbuttons protected by transparent cover.



Pushbutton locking using a padlock.



OFF position locking using a padlock.



OFF position locking using a keylock.

Pushbutton locking

The transparent cover blocks access to the pushbuttons used to open and close the device.

It is possible to independently lock the opening button and the closing button. The locking device is often combined with a remote operating mechanism.

The pushbuttons may be locked using either:

- three padlocks (not supplied)
- lead seal
- two screws.

Device locking in the OFF position

The circuit breaker is locked in the OFF position by physically maintaining the opening pushbutton pressed down:

- using padlocks (one to three padlocks, not supplied)
- using keylocks (one or two different keylocks, supplied).

Keys may be removed only when locking is effective (Profalux or Ronis type locks).

The keylocks are available in any of the following configurations:

one keylock

one keylock mounted on the device + one identical keylock supplied separately for interlocking with another device

two different key locks for double locking.

Profalux and Ronis keylocks are compatible with each other.

A locking kit (without locks) is available for installation of one or two keylocks (Ronis, Profalux, Kirk or Castell).

Accessory-compatibility

For Masterpact NT: 3 padlocks or 1 keylock

For Masterpact NW: 3 padlocks and/or 2 keylocks

Cable-type door interlock

This option prevents door opening when the circuit breaker is closed and prevents circuit breaker closing when the door is open.

For this, a special plate associated with a lock and a cable is mounted on the right side of the circuit breaker.

With this interlock installed, the source changeover function cannot be implemented.

Locking On the chassis





"Disconnected" position locking by keylocks.

"Disconnected" position locking

Mounted on the chassis and accessible with the door closed, these devices lock the circuit breaker in the "disconnected" position in two manners:

- using padlocks (standard), up to three padlocks (not supplied)
- using keylocks (optional), one or two different keylocks are available.
- Profalux and Ronis keylocks are available in different options:
- one keylock
- two different keylocks for double locking

■ one (or two) keylocks mounted on the device + one (or two) identical keylocks supplied separately for interlocking with another device.

A locking kit (without locks) is available for installation of one or two keylocks (Ronis, Profalux, Kirk or Castell).

"Connected", "disconnected" and "test" position locking

The "connected", "disconnected" and "test" positions are shown by an indicator. The exact position is obtained when the racking handle blocks. A release button is used to free it.

On request, the "disconnected" position locking system may be modified to lock the circuit breaker in any of the three positions, "connected", "disconnected" and "test".

Door interlock catch

Mounted on the right or left-hand side of the chassis, this device inhibits opening of the cubicle door when the circuit breaker is in "connected" or "test" position. It the breaker is put in the "connected" position with the door open, the door may be closed without having to disconnect the circuit breaker.

Racking interlock

This device prevents insertion of the racking handle when the cubicle door is open.

Cable-type door interlock

This option is identical for fixed and drawout versions.

Racking interlock between crank and OFF pushbutton

This option makes it necessary to press the OFF pushbutton in order to insert the racking handle and holds the device open until the handle is removed.

Automatic spring discharge before breaker removal

This option discharges the springs before the breaker is removed from the chassis.

Mismatch protection

Mismatch protection ensures that a circuit breaker is installed only in a chassis with compatible characteristics. It is made up of two parts (one on the chassis and one on the circuit breaker) offering twenty different combinations that the user may select.





"Disconnected" position

locking by padlocks.

Door interlock



Racking interlock.



Mismatch protection.

Indication contacts

Indication contacts are available: in the standard version for relay applications ■ in a low-level version for control of PLCs and electronic circuits. M2C and M6C contacts may be

programmed via the Micrologic P and H control units.





ON/OFF indication contacts (OF) (rotary type).

ON/OFF indication contacts (OF)

Two types of contacts indicate the ON or OFF position of the circuit breaker:

microswitch type changeover contacts for Masterpact NT

■ rotary type changeover contacts directly driven by the mechanism for Masterpact NW. These contacts trip when the minimum isolation distance between the main circuit-breaker contacts is reached.

OF
Suppli

OF				NT	NW
Supplied as standard				4	4
Maximum number				4	12
Breaking capacity (A)	Standard			Minimum	load: 100 mA/24 V
p.f.: 0.3	-	V AC	240/380	6	10/6 ⁽¹⁾
AC12/DC12			480	6	10/6 ⁽¹⁾
			690	6	6
		V DC	24/48	2.5	10/6 ⁽¹⁾
			125	0.5	10/6 ⁽¹⁾
			250	0.3	3
	Low-level			Minimum	load: 2 mA/15 V DC
	-	V AC	24/48	5	6
			240	5	6
			380	5	3
		V DC	24/48	5/2.5	6
			125	0.5	6
			250	0.3	3

(1) Standard contacts: 10 A; optional contacts: 6 A.

"Fault-trip" indication contacts (SDE)

Circuit-breaker tripping due to a fault is signalled by:

■ a red mechanical fault indicator (reset)

one changeover contact (SDE).

Following tripping, the mechanical indicator must be reset before the circuit breaker may be closed.

SDE				NT/NW
Supplied as standard				1
Maximum number				2
Breaking capacity (A) p.f.: 0.3	Standard			Minimum load: 100 mA/24 V
		V AC	240/380	5
AC12/DC12			480	5
	-		690	3
		V DC	24/48	3
			125	0.3
			250	0.15
	Low-level			Minimum load: 2 mA/15 V DC
		V AC	24/48	3
			240	3
			380	3
		V DC	24/48	3
			125	0.3
			250	0.15

Combined "connected/closed" contacts (EF)

The contact combines the "device connected" and the "device closed" information to produce the "circuit closed" information.

Supplied as an option for Masterpact NW, it is mounted in place of the connector of an additional OF contact.

EF				NW
Maximum number				8
Breaking capacity (A)	Standard			Minimum load: 100 mA/24 V
p.f.: 0.3 AC12/DC12		V AC	240/380	6
			480	6
			690	6
		V DC	24/48	2.5
			125	0.8
			250	0.3
	Low-level			Minimum load: 2 mA/15 V DC
		V AC	24/48	5
			240	5
			380	5
		V DC	24/48	2.5
			125	0.8
			250	0.3



ON/OFF indication contacts (OF) (microswitch type).



Combined contacts

Indication contacts



CCE, CD and CT "connected/disconnected/test" position carriage switches.



M2C programmable contacts: circuit-breaker internal relay with two contacts.



M6C programmable contacts:

circuit-breaker external relay with six independent changeover contacts controlled from the circuit breaker via a three-wire connection.

"Connected", "disconnected" and "test" position carriage switches

Three series of optional auxiliary contacts are available for the chassis:

changeover contacts to indicate the "connected" position (CE)

■ changeover contacts to indicate the "disconnected" position (CD). This position is indicated when the required clearance for isolation of the power and auxiliary circuits is reached

■ changeover contacts to indicate the "test" position (CT). In this position, the power circuits are disconnected and the auxiliary circuits are connected.

Additional actuators

A set of additional actuators may be installed on the chassis to change the functions of the carriage switches.

			NT	NW		
Contacts			CE/CD/CT	CE/CD/CT		
Maximum number	Standard		321	3 3 3		
	with additional ac	tuators		9 0 0		
				6 3 0		
				6 0 3		
Breaking capacity (A)	Standard		Minimum I	oad: 100 mA/24 V		
p.f.: 0.3	V AC	240	8	8		
AC12/DC12		380	8	8		
		480	8	8		
		690	6	6		
	V DC	24/48	2.5	2.5		
		125	0.8	0.8		
		250	0.3	0.3		
	Low-level		Minimum I	Minimum load: 2 mA/15 V DC		
	V AC	24/48	5	5		
		240	5	5		
		380	5	5		
	V DC	24/48	2.5	2.5		
		125	0.8	0.8		
		250	0.3	0.3		

M2C / M6C programmable contacts

These contacts, used with the Micrologic P and H control units, may be programmed via the control unit keypad or via a supervisory station with the COM communication option. They require an external power supply module.

- They indicate: ■ the type of fault
- instantaneous or delayed threshold overruns.
- They may be programmed:
- with instantaneous return to the initial state
- without return to the initial state .
- with return to the initial state following a delay .

	ato rono ming a	aolay.	
Characteristics			M2C/M6C
Minimum load			100 mA/24 V
Breaking capacity (A)	V AC	240	5
p.f.: 0.7		380	3
	V DC	24	1.8
		48	1.5
		125	0.4
		250	0.15



Remote operation Remote ON / OFF

Two solutions are available for remote operation of Masterpact devices:
a point-to-point solution
a bus solution with the COM

communication option.



The remote ON / OFF function is used to remotely open and close the circuit breaker. It is made up of:

- an electric motor (MCH) equipped with a "springs charged" limit switch contact (CH)
- two voltage releases:

DB101163

DB 10 1

- □ a closing release (XF)
- \square an opening release (MX).

Optionally, other functions may be added:

- a "ready to close" contact (PF)
 an electrical closing pushbutton (BPFE)
- remote reset following a fault.
- A remote-operation function is generally combined with:
- device ON / OFF indication (OF)
- "fault-trip" indication (SDE).

Wiring diagram of a point-to-point remote ON / OFF function



Wiring diagram of a bus-type remote ON / OFF function



Note: an opening order always takes priority over a closing order.

If opening and closing orders occur simultaneously, the mechanism discharges without any movement of the main contacts. The circuit breaker remains in the open position (OFF).

In the event of maintained opening and closing orders, the standard mechanism provides an anti-pumping function by blocking the main contacts in open position.

Anti-pumping function. After fault tripping or intentional opening using the manual or electrical controls, the closing order must first be discontinued, then reactivated to close the circuit breaker.

When the automatic reset after fault trip (RAR) option is installed, to avoid pumping following a fault trip, the automatic control system must take into account the information supplied by the circuit breaker before issuing a new closing order or blocking the circuit breaker in the open position (information on the type of fault, e.g. overload, short-time fault, earth fault, earth leakage, short-circuit, etc.).

Note: MX communicating releases are of the impulse type only and cannot be used to lock a circuit breaker in OFF position. For locking in OFF position, use the remote tripping function (2nd MX or MN).

When MX or XF communicating releases are used, the third wire (C3, A3) must be connected even if the communication module is not installed. When the control voltage (C3-C1 or A3-A1) is applied to the MX or XF releases, it is necessary to wait 1.5 seconds before issuing an order. Consequently, it is advised to use standard MX or XF releases for applications such as source-changeover systems.

Remote operation Remote ON / OFF



B100797-23



Electric motor (MCH) for Masterpact NT.

Electric motor (MCH) for Masterpact NW.





XF and MX voltage releases.



"Ready to close" contacts (PF).

Electric motor (MCH)

The electric motor automatically charges and recharges the spring mechanism when the circuit breaker is closed. Instantaneous reclosing of the breaker is thus possible following opening. The spring-mechanism charging handle is used only as a backup if auxiliary power is absent.

The electric motor (MCH) is equipped as standard with a limit switch contact (CH) that signals the "charged" position of the mechanism (springs charged).

Characteristics

Power supply	V AC 50/60 Hz	48/60 - 100/130 - 200/240 - 277- 380/415 - 400/440 - 480
	V DC	24/30 - 48/60 - 100/125 - 200/250
Operating thresh	old	0.85 to 1.1 Un
Consumption (V	A or W)	180
Motor overcurrer	nt	2 to 3 In for 0.1 s
Charging time		maximum 3 s for Masterpact NT
		maximum 4 s for Masterpact NW
Operating freque	ency	maximum 3 cycles per minute
CH contact		10 A at 240 V

Voltage releases (XF and MX)

Their supply can be maintained or automatically disconnected.

Closing release (XF)

The XF release remotely closes the circuit breaker if the spring mechanism is charged.

Opening release (MX)

The MX release instantaneously opens the circuit breaker when energised. It locks the circuit breaker in OFF position if the order is maintained (except for MX "communicating" releases).

Note: whether the operating order is maintened or automatically disconnected (pulse-type), XF or MX "communicating" releases ("bus" solution with "COM" communication option) always have an impulse-type action (see diagram).

Characteristics		XF	MX		
Power supply	V AC 50/60 Hz	24 - 48 - 100/130 - 200/250 - 277 - 380/480			
	V DC	12 - 24/30 - 48/60 - 100/130 - 200/250			
Operating threshold		0.85 to 1.1 Un	0.7 to 1.1 Un		
Consumption (VA or W)		Hold: 4.5	Hold: 4.5		
		Pick-up: 200 (200 ms)	Pick-up: 200 (200 ms)		
Circuit-breaker r	esponse time at Un	55 ms ±10 (Masterpact NT)	50 ms ±10		
		70 ms ±10 (NW ≤ 4000A)			
		80 ms ±10 (NW > 4000A)			

"Ready to close" contact (PF)

The "ready to close" position of the circuit breaker is indicated by a mechanical indicator and a PF changeover contact. This signal indicates that all the following are valid:

- the circuit breaker is in the OFF position
- the spring mechanism is charged
- a maintained opening order is not present:
- □ MX energised
- □ fault trip
- □ remote tripping (second MX or MN)
- □ device not completely racked in
- □ device locked in OFF position
- □ device interlocked with a second device.

Characteristics				NT/NW
Maximum number				1
Breaking capacity (A)	Standard			Minimum load: 100 mA/24 V
p.f.: 0.3		V AC	240/380	5
AC12/DC12			480	5
			690	3
		V DC	24/48	3
			125	0.3
			250	0.15
	Low-level			Minimum load: 2 mA/15 V DC
		V AC	24/48	3
			240	3
			380	3
		V DC	24/48	3
			125	0.3
			250	0.15



Remote operation Remote ON / OFF



Electrical closing pushbutton (BPFE)

Located on the front panel, this pushbutton carries out electrical closing of the circuit breaker. It is generally associated with the transparent cover that protects access to the closing pushbutton.

Electrical closing via the BPFE pushbutton takes into account all the safety functions that are part of the control/monitoring system of the installation.

The BPFE connects to the closing release (XF) in place of the COM module.



Remote reset after fault trip

Electrical reset after fault trip (Res)

Following tripping, this function resets the "fault trip" indication contacts (SDE) and the mechanical indicator and enables circuit breaker closing. Power supply: 110/130 V AC and 200/240 V AC.



Automatic reset after fault trip (RAR)

Following tripping, a reset of the mechanical indicator (reset button) is no longer required to enable circuit-breaker closing. The mechanical (reset button) and electrical (SDE) indications remain in fault position until the reset button is pressed.

Remote operation Remote tripping





This function opens the circuit breaker via an electrical order. It is made up of:

- a shunt release (second MX)
- or an undervoltage release (MN)
- or a delayed undervoltage release (MN + delay unit).

These releases (2nd MX or MN) cannot be operated by the communication bus. The delay unit, installed outside the circuit breaker, may be disabled by an emergency OFF button to obtain instantaneous opening of the circuit breaker.

Wiring diagram for the remote-tripping function



Voltage releases (second MX)

When energised, the MX voltage release instantaneously opens the circuit breaker. A continuous supply of power to the second MX locks the circuit breaker in the OFF position.

Cł	nara	cter	ist
----	------	------	-----

Characteristics						
Power supply	V AC 50/60Hz	24 - 48 - 100/130 - 200/250 - 277- 380/480				
	V DC	12 - 24/30 - 48/60 - 100/130 - 200/250				
Operating threshold		0.7 to 1.1 Un				
Permanent locking function		0.85 to 1.1 Un				
Consumption (VA or W)		Pick-up: 200 (200 ms)	Hold: 4.5			
Circuit-breaker resp	onse time at Un	50 ms ±10		-		

Instantaneous voltage releases (MN)

The MN release instantaneously opens the circuit breaker when its supply voltage drops to a value between 35 % and 70 % of its rated voltage. If there is no supply on the release, it is impossible to close the circuit breaker, either manually or electrically. Any attempt to close the circuit breaker has no effect on the main contacts. Circuitbreaker closing is enabled again when the supply voltage of the release returns to 85 % of its rated value.

Characteristic

onaracteristics			
Power supply	V AC 50/60 Hz V DC	24 - 48 - 100/130 - 200/250 - 380/4 24/30 - 48/60 - 100/130 - 200/250	480
Operating threshold	Opening Closing	0.35 to 0.7 Un 0.85 Un	
Consumption (VA or W)		Pick-up: 200 (200 ms)	Hold: 4.5
MN consumption with delay unit (VA or	· W)	Pick-up: 200 (200 ms)	Hold: 4.5
Circuit-breaker response time at Un		40 ms ±5 for NT	
		90 ms ±5 for NW	

MN delay units

To eliminate circuit-breaker nuisance tripping during short voltage dips, operation of the MN release can be delayed. This function is achieved by adding an external delay unit in the MN voltage-release circuit. Two versions are available, adjustable and non-adjustable.

Characteristics		
Power supply	Non-adjustable	100/130 - 200/250
V AC 50-60 Hz /DC	Adjustable	48/60 - 100/130 - 200/250 - 380/480
Operating threshold	Opening	0.35 to 0.7 Un
	Closing	0.85 Un
Consommation du retardateur	Pick-up: 200 (200 r	ns) Hold: 4.5
Circuit-breaker response time at Un	Non-adjustable	0.25 s
	Adjustable	0.5 s - 0.9 s - 1.5 s - 3 s



Accessories



Auxiliary terminal shield (CB)

Optional equipment mounted on the chassis, the shield prevents access to the terminal block of the electrical auxiliaries.



Operation counter (CDM)

The operation counter sums the number of operating cycles and is visible on the front panel. It is compatible with manual and electrical control functions.



Escutcheon (CDP)

Optional equipment mounted on the door of the cubicle, the escutcheon increases the degree of protection to IP 40 (circuit breaker installed free standing: IP30). It is available in fixed and drawout versions.

Blanking plate (OP) for escutcheon

Used with the escutcheon, this option closes off the door cut-out of a cubicle not yet equipped with a device. It may be used with the escutcheon for both fixed and drawout devices.

Transparent cover (CP) for escutcheon

Optional equipment mounted on the escutcheon, the cover is hinged and secured by a screw. It increases the degree of protection to IP54, IK10. It adapts to drawout devices.

Escutcheon (CDP) with blanking plate.



Transparent cover (CP) for escutcheon.

Source-changeover systems Presentation





Service sector:

- hospital operating rooms
- safety systems for tall buildings
- computer rooms (banks, insurance companies, etc.)
- lighting systems in shopping centres.



Industry:

- assembly lines
- propulsion systems on ships
- essential auxiliaries in thermal power stations...





- Infrastructure:
- port and railway installations
 runway lighting systems
- control systems for military installations...
- i control systems for minitally installations...

Manual source-changeover systems

- A manual source-changeover system is made up of:
- 2 devices (for connecting rod systems) or 2 to 3 devices (for cable systems)
- a connecting-rod or cable type mechanical interlocking system.

Remote-operated source-changeover systems

This is the most commonly employed system. No intervention by human operators is required. The switch from the normal to the replacement source is controlled electrically.

A remote-operated source-changeover system is made up of two or three circuit breakers or switch-disconnectors linked by:

an electrical interlocking system implemented in a number of manners

■ a mechanical interlocking system that protects against the consequences of an electrical malfunction and inhibits incorrect manual operation.

Automatic source-changeover systems

An automatic controller may be added to a remote-operated source-changeover system for automatic source control according to programmable operating modes. This solution provides optimal energy management:

- switching to a replacement source depending on any external conditions
- management of power sources
- regulation
- emergency source replacement, etc.

A communications function for dialogue with a supervisor is available for the automatic controller.

Communication option

The communication option must not be used to control the opening or closing of source-changeover system circuit breakers. It should be used only to transmit measurement data or circuit-breaker status.

The eco COM option is perfectly suited to these equipments.

Source-changeover systems Mechanical interlocking

Electrical interlocking of two or three devices is used to create a remote-operated source-changeover system. A basic mechanical interlocking system enhances the reliability of system operation.



Interlocking of two devices using cables.

Interlocking of two devices using cables

To ensure a continuous supply of power, certain electrical installations are connected to two power sources:

- a normal source N
- a replacement source R which supplies the installation when source N is not available.

A source-changeover system switches between the two sources. The system may include an automatic controller which manages switching according to external conditions. A source-changeover system may comprise two or three circuit breakers or switch-disconnectors.

Interlocking of two devices using connecting rods

The two devices must be stack mounted.

- This function requires:
- an adaptation fixture on the right side of each device
- a set of connecting rods with no-slip adjustments.

The complete interlock kit is supplied for assembly by the customer. Maximum vertical distance between the fixing planes: 900 mm.

Combinations of Masterpact Normal and Replacement source devices

Devices to be interlocked		NT		NW		
		Fixed	Drawout	Fixed	Drawout	
NT	Fixed	•	-	-	-	
	Drawout	-	•	-	-	
NW	Fixed	-	-	•	•	
	Drawout	-	-	•	•	

Interlocking of two or three devices using cables

Using cables, the devices may be stack mounted or installed side-by-side.

Interlocking of two devices (Masterpact NT or NW)

This function requires:

■ an adaptation fixture on the right side of each device

■ a set of cables with no-slip adjustments.

Maximum distance between the fixing planes (vertical or horizontal): 2000 mm with a radius greater or equal to 100 mm.

For cases requiring greater distances between fixing planes, please consult us.

Interlocking of three devices (only Masterpact NW)

This function requires:

■ an adaptation fixture (different for each type of interlocking) on the right side of each device

■ two or three sets of cables with no-slip adjustments.

Maximum distance between the fixing planes (vertical or horizontal): 1000 mm with a radius greater or equal to 100 mm.

For cases requiring greater distances between fixing planes, please consult us.

Installation

The complete interlock kit is supplied for assembly by the customer.

Combinations of Masterpact Normal and Replacement source devices

All combinations of Masterpact NT and NW devices may be used together in a source-changeover system. Interlocked devices may be fixed or drawout, three or four pole, with different ratings and sizes.

Source-changeover systems Electrical interlocking

Electrical interlocking is used with the mechanical interlocking system. It controls switching between sources. An automatic controller may be added to take into account information from the distribution system.



IVE unit.

Electrical interlocking requires an electrical control device.

This function can be implemented in one of two ways:

■ using the IVE electrical interlocking unit

■ by an electrician using the electrical systems presented in the diagrams in the "Source-changeover systems" section of this catalogue.

- Characteristics of the IVE unit
- external connection terminal block:
- □ inputs: control of devices
- □ outputs: status of the SDE contacts on the Normal and Replacement source devices
- connector to the two Normal and Replacement source devices:
- □ inputs:
- status of the OF contacts on each device (ON or OFF)
- status of the SDE contacts on the Normal and Replacement source devices □ outputs: power supply for motor mechanisms
- control voltage:
- □ 24 to 250 V DC
- □ 48 to 415 V 50/60 Hz □ 440 V 60 Hz.

The control voltage for the IVE electrical interlocking unit must be identical to that of the operating mechanism.

Necessary equipment

Each device must be equipped with:

- a remote-operation system made up of:
- □ MCH gear motor
- □ MX or MN opening release
- □ XF closing release
- □ PF "ready to close" contact
- an available OF contact
- one to three CE connected-position contacts for drawout devices.





Source-changeover systems Associated automatic controllers

By combining a remote-operated sourcechangeover system with an integrated BA or UA automatic controller, it is possible to automatically control source transfer according to user-selected sequences. These controllers can be used on sourcechangeover systems comprising 2 circuit breakers.

For source-changeover systems comprising 3 circuit breakers, the automatic control diagram must be prepared by the installer as a complement to to diagrams provided in the "electrical diagrams" section of this catalogue.



BA controller.



UA controller.

Controller			BA	UA		
Compatible circuit breakers		All Compact Masterpact	NS and circuit breakers			
4-position switch						
Automatic operation			•			
Forced operation on "Normal" source	е					
Forced operation on "Replacement"	source	1				
Stop (both "Normal" and "Replacem	ent" so	urces off)				
Automatic operation						
Monitoring of the "Normal" source a	nd auto	matic changeover	•			
Generator set startup control	Generator set startup control					
Generator set shutdown control						
Load shedding and reconnection of	non-pri	ority circuits				
Changeover to the "Replacement" s if one of the phases of the "Normal"	ource phase	is absent		•		
Test						
By opening the P25M circuit breaker	r supply	ing the controller				
By pressing the test button on the free	ont of th	ne controller				
Indications						
Circuit breaker status indication on t on, off, fault trip	he fron	t of the controller:	•	•		
Automatic mode indicating contact						
Other functions						
Selection of type of "Normal" source				•		
(single-phase or three-phase)						
Voluntary transfer to "Replacement"	source	•		•		
(e.g. energy management command	15)	mant as mmanda)		_		
forced operation on "Normal" source if "Replacement" source not operation	anager e onal	nent commands),		•		
Additional contact (not part of contro Transfer to "Replacement" source of (e.g. used to test the frequency of U	oller). nly if co R).	ontact is closed	•	•		
Setting of maximum startup time for	the rep	lacement source				
Options						
Communication option						
Power supply						
Control voltages ⁽¹⁾	240 V 50/60 Hz 415 V 50/60 Hz 60 Hz	:	:			
Operating thresholds		00112	-	-		
Undervoltage	0 35 U	ln ≤ voltage ≤ 0 7 Un		-		
Phase failure 0.5 Un ≤ voltage ≤ 0.7 Un				-		
Voltage presencevoltage	voltage	e ≥ 0.85 Un		-		
Characteristics of output cor	ntacts		_	_		
Rated thermal current (A)	8					
Minimum load	- 10 m∆	at 12 V				
		CA		DC		

		CA				DC	
Utilisation category (IEC 60947-5-1)		AC12	AC13	AC14	AC15	DC12	DC13
Operational current (A)	24 V	8	7	5	6	8	2
	48 V	8	7	5	5	2	-
	110 V	8	6	4	4	0.6	-
	220/240 V	8	6	4	3	-	-
	250 V	-	-	-	-	0.4	-
	380/415 V	5	-	-	-	-	-
	440 V	4	-	-	-	-	-
	660/690 V	-	-	-	-	-	-

(1) The controller is powered by the ACP auxiliaries control plate. The same voltage must be used for the ACP plate, the IVE unit and the circuit breaker motor mechanisms. If this voltage is the same as the source voltage, then the "Normal" and "Replacement" sources can be used directly for the power supply. If not, a BC type or equivalent isolation transformer must be used.

Display modules

Perfectly integrated in the Compact and Masterpact ranges, Display modules are designed for use with Micrologic control units to provide instant and highly intuitive access to all

the information provided by the circuit breakers, including device status, current, voltage and power values, etc.



DMB300 display module: basic and harmonic measurements.



DMC300 display module: measurements, harmonic analysis, diagnosis.

Associated Micrologic control unit A = Micrologic A

A = Micrologic AP = Micrologic P

H = Micrologic H

DMB300 and DMC300 display modules use the power and communications capabilities of the Micrologic control units to centralise the display of electrical values, status conditions and alarms of one or more Compact

or Masterpact circuit breakers.

The mounting and cabling system for the display modules ensures fast, easy and reliable installation.

Start-up is immediate with no configuration or programming required.

Display modules are high-performance devices combining:

■ simple and easy-to-read dials

powerful and accurate digital processing.

Their small size and extensive communications capabilities make for easy and flexible installation and operation.

Display modules	DM	B300)	DMO	C300	
Associated circuit breakers						
Туре	Compact or Masterpact equipped with Micrologic control units				ith	
Number	1 to 4			1 to 1	6	
Display						
Screen type	Black	and w	hite	Colou	r, touch	screen
Screen size	240 x	64 pix	els	5", 32	0 x 240	pixels
Entry	5 butt	ons		Touch	screer	1
Information displayed						
Currents (per phase)						
Currents I1, I2, I3, IN	А	Р	Н	А	Р	Н
Maximum current	А	Р	н	А	Р	н
Earth-fault and earth-leakage currents	А	Р	н	А	Р	н
Demand current		Р	н		Р	н
Maximum demand current		Р	н		Р	н
Total harmonic distortion (THD)			н			н
Maximum total harmonic distortion			н			н
Amplitudes of individual harmonics						н
Voltages				•		
Phase-to-phase voltages (U1-2, U2-3, U3-1)		Р	Н		Р	Н
Minimum/maximum phase-to-phase voltages		Р	н		Р	н
Phase-to-neutral voltages (V1-N, V2-N, V3-N)		Р	н		Р	н
Minimum/maximum phase-to-neutral voltages					Р	н
Frequency		Р	н		Р	н
Voltage imbalance (% per phase)		Р	н		Р	н
Total harmonic distortion (% per phase)			н			н
Maximum total harmonic distortion (% per phase)			н			н
Amplitudes of individual harmonics			н			н
Power				•		
Active (P), reactive (Q) and apparent (S) power			Н		Р	н
Power factor and cos		Р	н		Р	н
Maximum power (P, Q, S)		Ρ	Н		Р	Н
Demand power (P, Q, S)		Ρ	Н		Р	Н
Maximum demand power		Ρ	Н		Р	Н
Metering						
Active, reactive and apparent energy		Р	Н		Р	Н
On-line help						
	On-lir inforn	ne help nation s	is availat supplied t	ole for e	each typ nodule	be of
Circuit-breaker diagnostics						
Identification of control units	A	Р	Н	A	Ρ	Н
Reading of protections	A	Р	Н	A	Р	н
Circuit-breaker status	A	Р	Н	A	Ρ	Н
Type of trip	A	Р	Н	A	Р	н
Current alarms		Р	Н		Р	н
Maintenance indicator					Р	н
Installation diagnosis						
Indication of faulty devices				A	P	н
Fault log				А	Р	Н
Installation and start-up						
Mounting	Moun spring	ted thro g-clips s	ough dooi supplied v	r, witho with the	ut tools, e mod.	using 6
Connection	Prefa	bricate	d wiring s	ystems		

Display modules

Wiring system

The wiring system is designed for low-voltage power switchboards. Installation requires no tools or special skills.

The prefabricated wiring ensures both data transmission (ModBus protocol) and 24 V DC power distribution for the display module and the communications modules on the Micrologic control units.



Masterpact circuit breakers equipped with Micrologic control units and the ModBus COM option.

Connection of DMB300 display module

Maximum distance between module and circuit breaker: 1200 m.



Masterpact circuit breakers equipped with Micrologic control units and the ModBus eco COM option.



CDM 303: Connection cable between display module and junction block.



CJB 306 junction block.



CCP 303: Connection cable between Masterpact or Compact and junction block.



CCR 301: Roll of RS 485 cable (2 RS 485 wires + 2 power supply wires).



CSD 309: SubD 9-pin connector for colour-coded connection of wires to screw terminals. Masterpact

Dimensions and connection

Presentation	6
Functions and characteristics	13
NT06 to NT16 circuit breakers	60
Fixed 3/4-poles device	60
Drawout 3/4-poles device	64
NW08 to NW32 circuit breakers	68
Fixed 3/4-poles device	68
Drawout 3/4-poles device	70
NW40 circuit breakers	72
Fixed 3/4-poles device	72
Drawout 3/4-poles device	74
NW40b to NW63 circuit breakers	76
Fixed 3/4-poles device	76
Drawout 3/4-poles device	78
NT/NW accessories	80
NT/NW external modules	82
Electrical diagrams	87
Installation recommendations	97
Additional characteristics	121
Catalogue numbers, spare parts and order form	127

Dimensions and connection

NT06 to NT16 circuit breakers Fixed 3/4-poles device

Dimensions





Bottom mounting (on base plate or rails)

DB101191





Rear mounting detail (on upright or backplate)



Rear panel cutout

Safety clearances





	Parts		
	Insulated	Metal	Energised
A	0	0	100
В	0	0	60

F : datum.

(1) Without escutcheon.(2) With escutcheon.

Door cutout

DB101195





For 1000 V

	Parts		
	Insulated	Metal	Energised
Α	0	100	500 (3)
В	0	50	100 ⁽³⁾

(3) With a minimum distance between bars of 65 mm (A and B) if the bars are not insulated.

Note: X and Y are the symmetry planes for a 3-pole device. A(*) An overhead clearance of 50 mm is required to remove the arc chutes. An overhead clearance of 20 mm is required to remove the terminal block. Horizontal rear connection

NT06 to NT16 circuit breakers Fixed 3/4-poles device

Connections







Vertical rear connection









Front connection





Detail



Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

NT06 to NT16 circuit breakers Fixed 3/4-poles device







DB 101219

82



F : datum.

NT06 to NT16 circuit breakers Fixed 3/4-poles device

Detail

Connections

Front connection via vertical connection adapters









Detail

Front connection via vertical connection adapters fitted with cable-lug adapters





Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

(1) 2 connection possibilities on vertical connection adapters (21 mm between centres).

Dimensions and connection

NT06 to NT16 circuit breakers Drawout 3/4-poles device







(*) Disconnected position.

Bottom mounting (on base plate or rails)



6 Ø6,5 25 100 90 (3P) -90 (4P) -90 - 90 - F

Rear mounting detail (on upright or backplate)



Safety clearances



Door cutout

DB101237



Rear panel cutout



For voltages < 690 V or equal to 1000 V.

	Parts		
	Insulated	Metal	Energised
Α	0	0	30
В	10	10	60
С	0	0	30

F : datum.(1) Without escutcheon.

(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device.

Merlin Gerin

NT06 to NT16 circuit breakers Drawout 3/4-poles device

Connections



Horizontal rear connection



Vertical rear connection









Y

-9,5 _{...}12,5

12,5

A

60



Detail



View A detail.

Front connection





Note: recommended connection screws: M10 class 8.8. Tightening torque: 50 Nm with contact washer.

NT06 to NT16 circuit breakers Drawout 3/4-poles device

Connections

Front connection with spreaders







Spreader detail

Middle left or middle right spreader for 4P.



View A detail.

Middle spreader for 3P.

DB101219

Left or right spreader for 4P.

Left or right spreader for 3P.







NT06 to NT16 circuit breakers Drawout 3/4-poles device

Connections

Front connection via vertical connection adapters fitted with cable-lug adapters







Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

Dimensions and connection

NW08 to NW32 circuit breakers Fixed 3/4-poles device

Dimensions





Mounting on base plate or rails



Mounting detail

Door cutout

DB101270

DB101273



Safety clearances





	Insulated parts	Metal parts	Energised parts
Α	0	0	100
В	0	0	60

(1) Without escutcheon.

(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device. A(*) An overhead clearance of 50 mm is required to remove the arc chutes. An overhead clearance of 20 mm is required to remove the terminal block.

F : datum.



NW08 to NW32 circuit breakers Fixed 3/4-poles device

Connections



Horizontal rear connection





Vertical rear connection





Detail





Front connection





Detail



Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

Dimensions and connection

NW08 to NW32 circuit breakers Drawout 3/4-poles device







(*) Disconnected position.

Mounting on base plate or rails



Mounting detail



Safety clearances





	Insulated parts	Metal parts	Energised parts
Α	0	0	0
В	0	0	60

(1) Without escutcheon.(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device.

F : datum.

👌 Merlín Gerín
NW08 to NW32 circuit breakers Drawout 3/4-poles device

Detail

Connections



Horizontal rear connection





Vertical rear connection





Detail





Detail



Front connection





Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

NW40 circuit breakers Fixed 3/4-poles device

Dimensions





Mounting on base plate or rails





DB 101270

DB101273



Safety clearances



Door cutout



	Insulated parts	Metal parts	Energised parts
Α	0	0	100
В	0	0	60

F : datum.

(1) Without escutcheon.(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device. A(*) An overhead clearance of 110 mm is required to remove the arc chutes. An overhead clearance of 20 mm is required to remove the terminal block.

👌 Merlin Gerin

NW40 circuit breakers Fixed 3/4-poles device

Connections







Detail



Vertical rear connection





Detail





Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

NW40 circuit breakers Drawout 3/4-poles device







(*) Disconnected position.

Mounting on base plate or rails



Mounting detail



Safety clearances







(1) Without escutcheon.(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device. The safety clearances take into account the space required to remove the arc chutes.

F : datum.

NW40 circuit breakers Drawout 3/4-poles device

Connections



Horizontal rear connection



Detail



Vertical rear connection







Detail



Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

derlin Gerin

NW40b to NW63 circuit breakers Fixed 3/4-poles device

Dimensions





Mounting on base plate or rails





DB101321





Door cutout



	Insulated parts	Metal parts	Energised parts
Α	0	0	100
В	0	0	60

F : datum.

(1) Without escutcheon.(2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device. A(*) An overhead clearance of 110 mm is required to remove the arc chutes. An overhead clearance of 20 mm is required to remove the terminal block.

NW40b to NW63 circuit breakers Fixed 3/4-poles device

Connections



Vertical rear connection (NW40b - NW50)





Detail













Note: recommended connection screws: **M10** s/s class A4 80. Tightening torque: **50 Nm** with contact washer.

Merlin Gerin

NW40b to NW63 circuit breakers Drawout 3/4-poles device

 \overline{O}

238,5

200,5

40

250

F

270 **(1)** 379 **(2)**

153,3 (1)

47 (1)

135 **(1)** 222 **(2)**

 \odot

0

X

Dimensions

DB101334

DB101336

DB 101293



Insulated parts		Metal parts	Energised parts		
Α	0	0	0		
В	0	0	60		

(1) Without escutcheon. (2) With escutcheon.

Note: X and Y are the symmetry planes for a 3-pole device.

F : datum.

78

🖁 Merlin Geri

NW40b to NW63 circuit breakers Drawout 3/4-poles device

Connections

244



Vertical rear connection (NW40b - NW50)







Vertical rear connection (NW63)





Detail



View A detail.

Note: recommended connection screws: **M10** s/s class A4 80. Tightening torque: **50 Nm** with contact washer.



Mounting on backplate with special brackets (Masterpact NW08 to 32 fixed)





Disconnectable front-connection adapter (Masterpact NW08 to 32 fixed)







115 115 115 DB101354 Ν γ 76 DB101278 ►-38-13 12.5 **▲** 47 ♥ Ó Ċ 3 Ø11,5 -14,5 View A detail.

Detail

Vertical rear connection



Note: recommended connection screws: **M10** class 8.8. Tightening torque: **50 Nm** with contact washer.

F : datum.





👌 Merlin C









NW40b to NW63





Escutcheon

Masterpact NT



Masterpact NW



Drawout device



Drawout device





M6C relay module





External power supply module (AD)





Battery module (BAT) Mounting





Delay unit for MN release





"Chassis" communication module ModBUS



BatiBUS



External sensor for source ground return (SGR) protection "MGDF summer" module

Sensor





NT/NW external modules

External sensor for external neutral



High: 137 mm.

1000/4000 A (NW025 to NW40)



400/2000 A (NW08 to NW20)



High: 162 mm.

2000/6300 A (NW40b to NW63)



High: 168 mm.

400/2000 A (NW08 to NW20)



2000/6300 A (NW40b to NW63)



2 identical external sensor shipped as loosed part.

Installation 400/1600 A (NT06 to NT16)



1000/4000 A (NW025 to NW40)



Rectangular sensor for earth leakage protection (Vigi)

280 x 115 mm window

 $\begin{array}{c} & & & & \\ & & & & \\ & & & & \\ & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & & & & \\ & &$







233

Busbars	l ≤ 1600 A	l ≤ 3200
Window (mm)	280 x 115	470 x 160
Weight (kg)	14	18

Busbars path

280 x 115 window Busbars spaced 70 mm centre-to-centre



2 bars 50 x 10.



2 bars 100 x 5.

470 x 160 window

Busbars spaced 115 mm centre-to-centre



4 bars 100 x 5.



4 bars 125 x 5.

Installation and connection for Digipact DMB300 **Dimensions and front-panel cut-out** 5,8 DB101397 1 B MER 11/ 21 93,4 111,3 31 1 4", select 7.1→ 202 12.1 64,8 110 **(*)** R 3,5 maxi / 2 mini 99,2^{±0,4} - 190,9 ^{±0,4} **←** 1,5 ≤ **e** ≤ 6 mm (*) With Digipact wiring system.

Installation and connection for Digipact DMC300

Dimensions and front-panel cut-out



Presentation	6
Functions and characteristics	13
Dimensions and connection	59
Masterpact NT06 to NT16	88
Fixed and drawout devices	88
Masterpact NW08 to NW63	90
Fixed and drawout devices	90
Masterpact NT and NW Communications option 24 V DC external power supply Earth-fault and earth-leakage protection Neutral protection Zone selective interlocking	92 92 94
Installation recommendations	97
Additional characteristics	121
Catalogue numbers, spare parts and order form	127

Masterpact NT06 to NT16 Fixed and drawout devices

The diagram is shown with circuits deenergised, all devices open, connected and charged and relays in normal position.



P: A + power meter + additional protection.

H : P + harmonics.

Masterpact NT06 to NT16 Fixed and drawout devices



Indication contacts								
OF4	OF3	OF2	OF1					
۲	ර_ර	ර_ර	5-0					
44	34	24	14					
۲	ර_ර	5_0	5-0					
42	32	22	12					
۲	ර _ි ර	5_0	5_0					
41	31	21	11					

Indication contacts

OF4 / OF3 / OF2 / OF1 : ON/OFF indication contacts.

(*) Spring charging motor 440/480 V AC (380 V motor + additional resistor).



Chassis of	Chassis contacts									
CD2	CD1	CE3	CE2	CE1	CT1					
600	6_0	6_0	6_0	6_0	600					
824	814	334	324	314	914					
ර <u>ි</u> ර	600	5_5	5_0	50	5-0					
822	812	332	322	312	912					
6	6	5_5	م	5-0	5_0					
821	811	331	321	311	911					

C	chas	sis contacts				
CI CI	D2 : D1	disconnected position contacts	CE3 : CE2 CE1	connected position contacts	CT1 :	test position contacts



б

drawout device only.

SDE1, OF1, OF2, OF3, OF4 supplied as standard.

_____ interconnected connections

(only one wire per connection point).

Masterpact NW08 to NW63 Fixed and drawout devices

The diagram is shown with circuits deenergised, all devices open, connected and charged and relays in normal position.



P: A + power meter + additional protection.

H: P + harmonics.

Masterpact NW08 to NW63 Fixed and drawout devices



Indication contacts								
OF4	OF3	OF2	OF1					
5_0	പ്പെ	ර ිර	5 ک					
44	34	24	14					
රි ර	රි ිර	ර ිර	ර ර					
42	32	22	12					
5_0	د	5	5_0					
41	31	21	11					

OF3 OF2 OF1

				_			
OF24	OF23	OF22	OF21	OF14	OF13	OF12	OF11
ර ි	ර ි	ර ි	5 ک	6 0	ර ර	ර ි	ර ර
244	234	224	214	144	134	124	114
රි ර	රිට	ර ි	ර ර	රි ර	ර ර	ර ි	ර ර
242	232	222	212	142	132	122	112
ර ි	ර ි	ර ි	ර ර	ර ි	ර ර	ර ි	6_0
241	231	221	211	141	131	121	111
or							
EF24	EF23	EF22	EF21	EF14	EF13	EF12	EF11
ර ි	ර ි	ර ි	ර ි	ර ි	ර ර	ර ි	ර ර
248	238	228	218	148	138	128	118
ර ි	ර ි	ර ි	ර ී	ර ි	ර ර	ර ි	ර ර
246	236	226	216	146	136	126	116
ර ි	ර ි	ර ි	ර ි	ර ි	ර ර	ර ි	ර ර
245	235	225	215	145	135	125	115

Chassis contacts							
CD2	CD1	CE3	CE2	CE1	СТЗ	CT2	CT1
ර ිර 824	ර ර 814	ර ිර 334	ර ි ර 324	ර ි 314	ර ි 934	ර ි 924	ර ර 914
ර ර 822	ර ර 812	ර ිර 332	ර ි 322	ර ර 312	ර ිර 932	ර ි 922	ර ර 912
ර ර 821	ර ර 811	ර ිර 331	ර ිර 321	ර ර 311	ර ිර 931	ර ි 921	ර ර 911
or						or	
CE5	CE4				CE9	CE8	CE7
ර ිර 354	ර ි 344				5-0 394	ර ි 384	ර ි ර 374
ර ි 352	ර ි 342				ර ි 392	ර ි 382	ර ි 372
ර ර 351	6 0 341				50 391	6 381	5 371
	sis co CD2 824 822 822 822 0r CE5 354 5354 5352 5351	Sis contacts CD2 CD1 & 824 814 & 822 812 822 812 822 812 821 811 0r 812 CE5 CE4 354 344 552 342 351 341	sis contacts CD2 CD1 CE3 624 814 334 628 814 332 829 812 332 820 812 332 821 811 331 01 811 331 01 811 331 01 814 334 354 344 344 352 342 342 351 341 341	Sis contacts CD2 CD1 CE3 CE2 0 0 334 324 0 0 334 324 0 0 334 324 0 0 332 322 0 0 332 322 0 0 331 321 0 0 331 321 0 0 331 321 0 0 331 321 0 0 331 321 0 0 0 0 354 344 0 0 352 342 0 0 351 0 0 0	Sis contacts CD2 CD1 CE3 CE2 CE1 0 0 334 324 314 0 0 334 324 314 0 0 332 322 312 0 0 332 322 312 0 0 331 321 311 0 0 331 321 311 0 0 0 0 0 354 344 0 0 0 352 342 0 0 0 352 342 0 0 0 0 0 0 0 0 0 352 342 0 0 0 0 0 0 0 0 0 0 354 0 0 0 0 0 0 0 0 0 0 0	Sis contacts CE2 CE1 CE3 CE2 CE1 CT3 CD2 CD1 CE3 CE2 CE1 CT3 S24 S14 S34 S24 S14 934 S22 S112 S32 S22 S12 932 S22 S112 S32 S22 S12 932 S21 S11 S31 S21 S11 931 OF CE5 CE4 CE9 S354 S44 S34 S34 S352 S42 S44 S392 S351 S41 S41 S391	Sis contacts CE2 CE1 CT3 CT2 CD2 CD1 CE3 CE2 CE1 CT3 CT2 S24 S14 S34 S24 S14 934 924 S22 S12 S32 S22 S12 932 922 S22 S11 S33 S22 S12 932 922 S23 S21 S11 S31 S21 S11 931 921 OF S33 S21 S11 931 921 OF CE5 CE4 OF S354 S342 S34 S34 S34 S351 S341 S391 S381

test position

connected

disconnected

Indica	ation contacts			Cha	assis contact	s			
Indica OF4 : OF3 OF2 OF1	ation contacts ON/OFF indication contacts	OF24 or EF24 OF23 or EF23 OF22 or EF22 OF21 or EF21 OF14 or EF14 OF13 or EF13 OF12 or EF12 OF11 or	Combined "connected-deconnected" indication contacts	Cha CD3 CD2 CD1 or CE6 CE5 CE4 <i>Key:</i>	disconnected position contacts connected position contacts drawout de	S CE3 CE1 CE1	connected position contacts	CT3 CT2 CT1 or CE9 CE8 CE7 or CD6 CD5 CD4	test posi contacts connecte position contacts disconne position contacts
	EF11	EF11		XX	X SDE1, OF1	1, OF2,	OF3, OF4 su	oplied as	s standard.
				6	only one w	cted co vire per	nnections connection po	oint).	

🖁 Merlin Gerin

Masterpact NT and NW Communications option 24 V DC external power supply

Connection of the communications option



None of the control-unit protection functions require an auxiliary source. However, the 24 V DC external power-supply (AD module) is required for certain operating configurations as indicated in the table below.

Circuit breaker	Closed	Open	
Voltage measurement inputs	Powered	Powered	Not powered
M2C, M6C programmable contacts option	Yes	Yes	Yes
Protection function	No	No	No
Display function	No ⁽³⁾	No ⁽⁴⁾	Yes
Time-stamping function	No	No	Yes ⁽⁵⁾
Circuit-breaker status indications and control via communications bus	No	No	No
Identification, settings, operation and maintenance aids via communications bus	No ⁽³⁾	No ⁽⁴⁾	Yes

(1) Drawout device equipped with Modbus chassis COM.

(2) Drawout device equipped with Digipact chassis COM.

(3) Except for Micrologic A control units (if current < 20 % In).

(4) Except for Micrologic A control units.

(5) Time setting is manual and can be carried out automatically by the supervisor via the communications bus. The communications bus requires its own 24 V DC power source (E1, E2). This source is not the same as the 24 V DC external power-supply module (F1-, F2+).

In case of using the 24 V DC external power supply (AD module), maximum cable length between 24 V DC (G1, G2) and the control unit (F1-, F2+) must not exceed 10 meters.

The BAT battery module, mounted in series upstream of the AD module, ensures an uninterrupted supply of power if the AD module power supply fails.

The voltage measurement inputs are standard equipment on the downstream connectors of the circuit breaker.

External connections are possible using the PTE external voltage measurement input option. With this option, the internal voltage measurement inputs are disconnected and terminals VN, V1, V2, V3 are connected only to the control unit (Micrologic P and H only). The PTE option is required for voltages less than 220 V and greater than 690 V (in which case a voltage transformer is compulsory). For three-pole devices, the system is supplied with terminal VN connected only to the control unit (Micrologic P and H).

When the PTE option is implemented, the voltage measurement input must be protected against short-circuits. Installed as close as possible to the busbars, this protection function is ensured by a P25M circuit breaker (1 A rating) with an auxiliary contact (cat. no. 21104 and 21117). This voltage measurement input is reserved exclusively for the control unit and must not ever be used to supply other circuits outside the switchboard.

Masterpact NT and NW Communications option 24 V DC external power supply

Examples using the COM communications option



This architecture provides remote display of the variables managed by Micrologic control units equipped with the eco COM Modbus module.

- I (Micrologic A)
- I, U, P, E (Micrologic P)
- I, U, P, E, THD (Micrologic H)
- No programming is required.

For Micrologic A control unit (if current < 20 % In), it is recommended to use the 24 V DC external power supply (AD module).



24 V DC 1A

junction

block CJB 306

Communicating switchboard

This configuration provides remote display and control of Masterpacts equipped with the Modbus or Digipact COM module. The Digipact bus can be combined with the Modbus bus.



Masterpact NT and NW

Earth-fault and earth-leakage protection Neutral protection Zone selective interlocking

External sensor (CT) for residual earth-fault protection

Connection of current-transformer secondary circuit for external neutral

Masterpact equipped with a Micrologic 6 A/P/H: shielded cable with 2 twisted pairs

- T1 twisted with T2
- T3 twisted with T4
- shielding connected to GND on one end only
- maximum length 10 meters
- cable cross-sectional area 0.4 to 1.5 mm²
- recommended cable: Belden 9552 or equivalent.

If supply is via the top, follow the shematics. If supply is via the bottom, control wiring is identical; for the power wiring, H1 is connected to the source side, H2 to the load side.

For four-pole versions, for residual earth-fault protection, the current transformer for the external neutral is not necessary.

If the 2000/6300 current transformer is used:

■ signals T1 and T2 must be wired in series

■ signals T3 and T4 must be wired in parallel. Connection for signal VN is required only for power measurements (3 Ø, 4 wires, 4CTs).



External transformer for source ground return (SGR) earth-fault protection

Connection of the secondary circuit

Masterpact equipped with a Micrologic 6 A/P/H:

- unshielded cable with 1 twisted pair
- maximum length 150 meters
- cable cross-sectional area 0.4 to 1.5 mm²
- terminals 5 and 6 may not be used at the same time
- use terminal 5 for NW08 to 40
- use terminal 6 for NW40b to 63
- recommended cable: Belden 9409 or equivalent.



Masterpact NT and NW Earth-fault and earth-leakage protection Neutral protection Zone selective interlocking

Earth-leakage protection

Connection of the rectangular-sensor secondary circuit Use the cable shipped with the rectangular sensor.

Store of the second sec

11 12

13

N

Neutral protection

■ three pole circuit breaker:

 Masterpact equipped with Micrologic P or H
 the current transformer for external neutral is necessary (the wiring diagram is identical to the one used for the residual earth-fault protection)

■ four pole circuit breaker:

Masterpact equipped with Micrologic A, P or H
 the current transformer for external neutral is not necessary.

Zone selective interlocking

Zone-selective interlocking is used to reduce the electrodynamic forces exerted on the installation by shortening the time required to clear faults, while maintaining time discrimination between the various devices.

A pilot wire interconnects a number of circuit breakers equipped with Micrologic A/P/H control units, as illustrated in the diagram above.

The control unit detecting a fault sends a signal upstream and checks for a signal arriving from downstream. If there is a signal from downstream, the circuit breaker remains closed for the full duration of its tripping delay. If there is no signal from downstream, the circuit breaker opens immediately, regardless

of the tripping-delay setting.

Fault 1.

Only circuit breaker A detects the fault. Because it receives no signal from downstream, it opens immediately, regardless of its tripping delay set to 0.3.

Fault 2.

Circuit breakers A and B detect the fault. Circuit breaker A receives a signal from B and remains closed for the full duration of its tripping delay set

to 0.3. Circuit breaker B does not receive a signal from downstream and opens immediately, in spite of its tripping delay set to 0.2.

Note: the maximum permissible distance between two devices is 3000 m. A downstream circuit breaker can "control" up to ten upstream circuit breakers.



Masterpact

Installation recommendations

Presentation	6
Functions and characteristics	13
Dimensions and connection	59
Electrical diagrams	87
Operating conditions	98
Installation in switchboard	100
Door interlock catch	102
Control wiring	103
Power connection	104
Recommended busbars drilling	106
Masterpact NT06 to NT16	106
Masterpact NW08 to NW63	107
Busbar sizing	108
Temperature derating	
input / output resistance	110
Derating in switchboards	111
Substitution kit	118
Fixed / drawout devices 800 to 3200 A	118
Additional characteristics	121
Catalogue numbers, spare parts and order for	127

Operating conditions



Ambient temperature

Masterpact devices can operate under the following temperature conditions:

- the electrical and mechanical characteristics are stipulated for an ambient
- temperature of -5 °C to +70 °C
- circuit-breaker closing is guaranteed down to -35 °C.
- Storage conditions are as follows:
- -40 to +85 °C for a Masterpact device without its control unit
- -25 °C to +85 °C for the control unit.



Extreme atmospheric conditions

Masterpact devices have successfully passed the tests defined by the following standards for extreme atmospheric conditions:

- IEC 68-2-1: dry cold at -55 °C
- IEC 68-2-2: dry heat at +85 °C
- IEC 68-2-30: damp heat (temperature +55 °C, relative humidity 95 %)
- IEC 68-2-52 level 2: salt mist.

Masterpact devices can operate in the industrial environments defined by standard IEC 947 (pollution degree up to 4).

It is nonetheless advised to check that the devices are installed in suitably cooled switchboards without excessive dust.

Vibrations

Masterpact devices are guaranteed against electromagnetic or mechanical vibrations.

Tests are carried out in compliance with standard IEC 68-2-6 for the levels required by merchant-marine inspection organisations (Veritas, Lloyd's, etc.):

- 2 to 13.2 Hz: amplitude ±1 mm
- 13.2 to 100 Hz: constant acceleration 0.7 g.

Excessive vibration may cause tripping, breaks in connections or damage to mechanical parts.



Operating conditions



Altitude

At altitudes higher than 2000 metres, the modifications in the ambient air (electrical resistance, cooling capacity) lower the following characteristics as follows:

Altitude (m)	2000	3000	4000	5000
Dielectric resistance voltage (V)	3500	3150	2500	2100
Average insulation level (V)	1000	900	700	600
Maximum utilisation voltage (V)	690	590	520	460
Average thermal current (A) at 40 °C	1 x In	0.99 x In	0.96 x In	0.94 x In



Electromagnetic disturbances

- Masterpact devices are protected against:
- overvoltages caused by devices that generate electromagnetic disturbances
 overvoltages caused by atmospheric disturbances or by a distribution-system
- outage (e.g. failure of a lighting system)
- devices emitting radio waves (radios, walkie-talkies, radar, etc.)
- electrostatic discharges produced by users.

Masterpact devices have successfully passed the electromagnetic-compatibility tests (EMC) defined by the following international standards:

- IEC 60947-2, appendix F
- IEC 60947-2, appendix B (trip units with earth-leakage function).
- The above tests guarantee that:
- no nuisance tripping occurs
- tripping times are respected.

Installation in switchboard

Possible positions



Power supply

Masterpact devices can be supplied either from the top or from the bottom without reduction in performance, in order to facilitate connection when installed in a switchboard.



Mounting the circuit-breaker

It is important to distribute the weight of the device uniformily over a rigid mounting surface such as rails or a base plate.

This mounting plane should be perfectly flat (tolerance on support flatness: 2 mm). This eliminates any risk of deformation which could interfere with correct operation of the circuit breaker.

Masterpact devices can also be mounted on a vertical plane using the special brackets.





Mounting on rails.



Mounting with vertical brackets.

Partitions

Sufficient openings must be provided in partitions to ensure good air circulation around the circuit breaker; Any partition between upstream and downstream connections of the device must be made of nonmagnetic material.

For high currents, of 2500 A and upwards, the metal supports or barriers in the immediate vicinity of a conductor must be made of non-magnetic material **A**. Metal barriers through which a conductor passes must not form a magnetic loop.



A : non magnetic material.



Busbars (NT, NW)

The mechanical connection must be exclude the possibility of formation of a magnetic loop around a conductor.



Busbars (NT)

For live busbars installed immediately above the circuit breaker (respecting the 100 mm safety clearance), the distance between bars must be 65 mm minimum. In a 1000 V system, the bars must be insulated.



Interphase barrier

If the insulation distance between phases is not sufficient (≤ 14 mm), it is advised to install phase barriers (taking into account the safety clearances). Mandatory for a Masterpact NT > 500 V.





Door interlock catch

Door interlock

Mounted on the right or left-hand side of the chassis, this device inhibits opening of the cubicle door when the circuit breaker is in "connected" or "test" position. It the breaker is put in the "connected" position with the door open, the door may be closed without having to disconnect the circuit breaker.

Dimensions (mm)

Туре	(1)	(2)
NT08-16 (3P)	135	168
NT08-16 (4P)	205	168
NW08-40 (3P)	215	215
NW08-40 (4P)	330	215
NW40b-63 (3P)	660	215
NW40b-63 (4P)	775	215



Breaker in "connected" or "test" position Door cannot be opened





Door can be opened



Dimensions (mm)

Туре	(1)	(2)	
NT	5	23	
NW	83	103	

Cable-type door interlock

This option prevents door opening when the circuit breaker is closed and prevents circuit breaker closing when the door is open.

For this, a special plate associated with a lock and a cable is mounted on the right side of the circuit breaker. With this interlock installed, the source changeover function cannot be implemented.



-79⊣

52 - 84 -

Note: the door interlock can either be mounted on the right side or the left side of the breaker. [F]: datum.

Control wiring

Wiring of voltage releases

During pick-up, the power consumed is approximately 150 to 200 VA. For low control voltages (12, 24, 48 V), maximum cable lengths are imposed by the voltage and the cross-sectional area of cables.

Recommended maximum cable lengths (meter).

		12 V		24 V		48 V	
		2,5 mm ²	1,5 mm ²	2,5 mm ²	1,5 mm ²	2,5 mm ²	1,5 mm ²
MN	U source 100 %	-	-	58	35	280	165
	U source 85 %	-	-	16	10	75	45
MX-XF	U source 100 %	21	12	115	70	550	330
	U source 85 %	10	6	75	44	350	210

Note: the indicated length is that of each of the two wires.

24 V DC power-supply module

External 24 V DC power-supply module for Micrologic (F1-, F2+)

■ do not connect the positive terminal (F2+) to earth

■ the negative terminal (F1-) can be connected to earth, except in IT systems

■ a number of Micrologic control units and M6C modules can be connected to the same 24 V DC power supply (the consumption of a Micrologic control unit or an M6C module is approximately 100 mA)

do not connect any devices other than a Micrologic control unit or an M6C module
 the maximum length for each conductor is ten metres. For greater distances, it is advised to twist the supply wires together

■ the 24 V DC supply wires must cross the power cables perpendicularly. If this is difficult, it is advised to twist the supply wires together

■ the technical characteristics of the external 24 V DC power-supply module for Micrologic control units are indicated on page 207E2200_Ver6.0.fm/12

Communication bus

- do not connect the positive terminal (E1) to earth
- the negative terminal (E2) can be connected to earth

 a number of "device" or "chassis" communication modules can be connected to the same 24 V DC power supply (the consumption of each module is approximately 30 mA)

the 24 V DC (E1, E2) power supply for the communication bus must be separate from the external 24 V DC power-supply module for Micrologic control units (F1-, F2+).

		mer eappij m		egie eenaera	
E1	E2	E3	E4	E5	E6
+	-	A/Tx⁻	B/Tx ⁺	A'/Rx⁻	B'/Rx+

To create a two-wire Modbus communication bus, simply connect Tx^{\cdot} with Rx^{\cdot} and Tx^{\star} with $Rx^{\star}.$

To connect a Modbus slave (Micrologic) to a Modbus master (PLC), connect:

the slave Tx^- to the master Rx^- the slave Rx^- to the master Tx^-

the slave Tx^+ to the master Rx^+ the slave Rx^+ to the master Tx^+ .

10

30

20 06

•7

08

00

RS485 Modbus Junction Block





COIOI
Black
Red
Blue
Yellow
Black
Red
White
Brown

0-1--

Power connection

Cables connections

If cables are used for the power connections, make sure that they do not apply excessive mechanical forces to the circuit breaker terminals. For this, make the connections as follows:

- extend the circuit breaker terminals using short bars designed and installed according to the
- recommendations for bar-type power connections:
- □ for a single cable, use solution **B** opposite
- $\hfill\square$ for multiple cables, use solution ${\bf C}$ opposite
- in all cases, follow the general rules for connections to busbars:
- □ position the cable lugs before inserting the bolts
- $\hfill\square$ the cables should firmly secured to the framework $\hfill E.$



E





The busbars should be suitably adjusted to ensure that the connection points are positioned on the terminals before the bolts are inserted ${f B}$

The connections are held by the support which is solidly fixed to the framework of the switchboard, such that the circuit breaker terminals do not have to support its weight **C**. (This support should be placed close to the terminals).





Electrodynamic stresses

The first busbar support or spacer shall be situated within a maximum distance from the connection point of the breaker (see table below). This distance must be respected so that the connection can withstand the electrodynamic stresses between phases in the event of a short circuit.

Maximum distance A between busbar to circuit breaker connection and the first busbar support or spacer with respect to the value of the prospective short-circuit current.						
lsc (kA)	30	50	65	80	100	150
Distance A (mm)	350	300	250	150	150	150

Power connection



Clamping

Correct clamping of busbars depends amongst other things, on the tightening torques used for the nuts and bolts. Over-tightening may have the same consequences as under-tightening.

For connecting busbars (Cu ETP-NFA51-100) to the circuit breaker, the tightening torques to be used are shown in the table below.

These values are for use with copper busbars and steel nuts and bolts, class 8.8. The same torques can be used with AGS-T52 quality aluminium bars (French standard NFA 02-104 or American National Standard H-35-1).

Examples







- Terminal screw factory-tightened to 16 Nm (NW), 13 Nm (NT). 1
- Breaker terminal.
- 2 3 4 5 Busbar.
- Bolt.
- Washer.
- 6 Nut.

Tightening torques Ø (mm) Ø (mm) Nominal Drilling

11

Tightening torques (Nm) with grower or flat washers 37.5

Tightening torques (Nm) with contact or corrugatec washers 50

Busbar drilling

Examples

10



Isolation distance



Dimensions (mm)

Ui	X min
600 V	8 mm
1000 V	14 mm

Busbar bending

When bending busbars maintain the radius indicated below(a smaller radius would cause cracks).



Dimensions (mm)

e	Radius of curvature r Min	Recommended
5	5	7.5
10	15	18 to 20

Recommended busbars drilling Masterpact NT06 to NT16




Vertical rear connection NW08 to NW32, NW40b to NW50





Front connection NW08 to NW32



-76 25+25+ **⊢1**3 DB101479 DB101478 0 0 \uparrow 0 0 L12,5 0 0 -3 Ø11,5 0 0 0 0 Q Q 0



Busbar sizing

Basis of tables:

- maximum permissible busbars temperature: 100 °C
 Ti: temperature around the circuit breaker and its
- connection
- busbar material is unpainted copper.

Front or rear horizontal connection



Masterpact	Maximum	Ti : 40 °C		Ti : 50 °C		Ti : 60 °C	
	service current	No. of 5 mm thick bars	No. of 10 mm thick bars	No. of 5 mm thick bars	No. of 10 mm thick bars	No. of 5 mm thick bars	No. of 10 mm thick bars
NT06	400	2b.30 x 5	1b.30 x 10	2b.30 x 5	1b.30 x 10	2b.30 x 5	1b.30 x 10
NT06	630	2b.40 x 5	1b.40 x 10	2b.40 x 5	1b.40 x 10	2b.40 x 5	1b.40 x 10
NT08 ou NW08	800	2b.50 x 5	1b.50 x 10	2b.50 x 5	1b.50 x 10	2b.50 x 5	1b.63 x 10
NT10 ou NW10	1000	3b.50 x 5	1b.63 x 10	3b.50 x 5	2b.50 x 10	3b.63 x 5	2b.50 x 10
NT12 ou NW12	1250	3b.50 x 5	2b.40 x 10	3b.50 x 5	2b.50 x 10	3b.63 x 5	2b.50 x 10
		2b.80 x 5	2b.40 x 10	2b.80 x 5			
NT16 ou NW16	1400	2b.80 x 5	2b.40 x 10	2b.80 x 5	2b.50 x 10	3b.80 x 5	2b.63 x 10
NT16 ou NW16	1600	3b.80 x 5	2b.63 x 10	3b.80 x 5	2b.63 x 10	3b.80 x 5	3b.50 x 10
NW20	1800	3b.80 x 5	2b.63 x 10	3b.80 x 5	2b.63 x 10	3b.100 x 5	2b.80 x 10
NW20	2000	3b.100 x 5	2b.80 x 10	3b.100 x 5	2b.80 x 10	3b.100 x 5	3b.63 x 10
NW25	2200	3b.100 x 5	2b.80 x 10	3b.100 x 5	2b.80 x 10	4b.80 x 5	2b.100 x 10
NW25	2500	4b.100 x 5	2b.100 x 10	4b.100 x 5	2b.100 x 10	4b.100 x 5	3b.80 x 10
NW32	2800	4b.100 x 5	3b.80 x 10	4b.100 x 5	3b.80 x 10	5b.100 x 5	3b.100 x 10
NW32	3000	5b.100 x 5	3b.80 x 10	6b.100 x 5	3b.100 x 10	8b.100 x 5	4b.80 x 10
NW32	3200	6b.100 x 5	3b.100 x 10	8b.100 x 5	3b.100 x 10		4b.100 x 10
NW40	3800		4b.100 x 10		5b.100 x 10		5b.100 x 10
NW40	4000		5b.100 x 10		5b.100 x 10		6b.100 x 10
NW50	4500		6b.100 x 10		6b.100 x 10		7b.100 x 10
NW50	5000		7b.100 x 10		7b.100 x 10		

With Masterpact NT, it is recommanded to use 50 mm wideness bars (see "Recommended busbars drilling").

Example

- Conditions:
- drawout version
- horizontal busbars
- T_i: 50 °C
- service current: 1800 A.

Solution:

For $T_i = 50$ °C, use an NW20 which can be connected with three 80 x 5 mm bars or two 63 x 10 mm bars.

Busbar sizing

Basis of tables:

maximum permissible busbars temperature: 100 °C
 Ti: temperature around the circuit breaker and its

connection

busbar material is unpainted copper.

Rear vertical connection



Masterpact	Maximum	Ti : 40 °C		Ti : 50 °C		Ti : 60 °C		
	service current	No. of 5 mm thick bars	No. of 10 mm thick bars	No. of 5 mm thick bars	No. of 10 mm thick bars	No. of 5 mm thick bars	No. of 10 mm thick bars	
NT06	400	2b.30 x 5	1b.30 x 10	2b.30 x 5	1b.30 x 10	2b.30 x 5	1b.30 x 10	
NT06	630	2b.40 x 5	1b.40 x 10	2b.40 x 5	1b.40 x 10	2b.40 x 5	1b.40 x 10	
NT08 ou NW08	800	2b.50 x 5	1b.50 x 10	2b.50 x 5	1b.50 x 10	2b.50 x 5	1b.50 x 10	
NT10 ou NW10	1000	2b.50 x 5	1b.50 x 10	2b.50 x 5	1b.50 x 10	2b.63 x 5	1b.63 x 10	
NT12 ou NW12	1250	2b.63 x 5	1b.63 x 10	3b.50 x 5	2b.40 x 10	3b.50 x 5	2b.40 x 10	
NT16 ou NW16	1400	2b.80 x 5	1b.80 x 10	2b.80 x 5	2b.50 x 10	3b.63 x 5	2b.50 x 10	
NT16 ou NW16	1600	3b.63 x 5	2b.50 x 10	3b.63 x 5	2b.50 x 10	3b.80 x 5	2b.63 x 10	
NW20	1800	2b.80 x 5	1b.80 x 10	2b.80 x 5	2b.50 x 10	3b.80 x 5	2b.63 x 10	
NW20	2000	2b.100 x 5	2b.63 x 10	2b.100 x 5	2b.63 x 10	3b.100 x 5	2b.80 x 10	
NW25	2200	2b.100 x 5	2b.63 x 10	2b.100 x 5	2b.63 x 10	3b.100 x 5	2b.80 x 10	
NW25	2500	4b.80 x 5	2b.80 x 10	4b.80 x 5	2b.80 x 10	4b.100 x 5	3b.80 x 10	
NW32	2800	4b.100 x 5	2b.100 x 10	4b.100 x 5	2b.100 x 10	4b.100 x 5	3b.80 x 10	
NW32	3000	5b.100 x 5	3b.80 x 10	6b.100 x 5	3b.100 x 10	5b.100 x 5	4b.80 x 10	
NW32	3200	6b.100 x 5	3b.100 x 10	6b.100 x 5	3b.100 x 10		4b.100 x 10	
NW40	3800		4b.100 x 10		4b.100 x 10		4b.100 x 10	
NW40	4000		4b.100 x 10		4b.100 x 10		4b.100 x 10	
NW50	4500		5b.100 x 10		5b.100 x 10		6b.100 x 10	
NW50	5000		5b.100 x 10		6b.100 x 10		7b.100 x 10	
NW63	5700		7b.100 x 10		7b.100 x 10		8b.100 x 10	
NW63	6300		8b.100 x 10		8b.100 x 10			

Example

Conditions:

- drawout version
- vertical connections
- T_i: 40 °C
- service current: 1100 A.

Solution :

For T_i = 40 °C use an NT12 or NW12 which can be connected with two 63 x 5 mm bars or with one 63 x 10 mm bar.



Temperature derating Power dissipation and input / output resistance

Temperature derating

The table below indicates the maximum current rating, for each connection type, as a function of Ti around the circuit breaker and the busbars. Circuit breakers with mixed connections have the same derating as horizontally connected breakers. For Ti greater than 60 °C, consult us. Ti: temperature around the circuit breaker and its connection.

Version	Drawo	Drawout F						Fixed												
Connection	Front	or real	r horizo	ontal		Rear v	ertica	I			Front	or rea	r horiz	ontal		Rear v	ertica	I		
Temp. Ti	40	45	50	55	60	40	45	50	55	60	40	45	50	55	60	40	45	50	55	60
NT06 H1/L1	630					630					630					630				
NT08 H1/L1	800					800					800					800				
NT10 H1/L1	1000					1000					1000					1000				
NT12 H1	1250					1250					1250					1250				
NT16 H1	1600		1520	1480	1430	1600			1560	1510	1600				1550	1600				
NW08 N/H/L	800					800					800					800				
NW10 N/H/L	1000					1000					1000					1000				
NW12 N/H/L	1250					1250					1250					1250				
NW16 N/H/L	1600					1600					1600					1600				
NW20 H1/H2/H3	2000			1980	1890	2000					2000				1920	2000				
NW20 L1	2000		1900	1850	1800	2000					-	-	-	-	-	-	-	-	-	-
NW25 H1/H2/H3	2500					2500					2500					2500				
NW32 H1/H2/H3	3200		3100	3000	2900	3200					3200					3200				
NW40 H1/H2/H3	4000		3900	3750	3650	4000				3850	4000			3900	3800	4000				
	4000					4000					4000					4000				
	4000					4000					4000					4000				
	5000					5000				0000	5000					5000				
NVV63 H1/H2	-	-	-	-	-	6300				b∠00	-	-	-	-	-	6300				

Power dissipation and input / output resistance

Total power dissipation is the value measured at I_N , 50/ 60 Hz, for a 3 pole or 4 pole breaker (values above the power P = $3RI^2$). The resistance between input / output is the value

measured per pole (cold state).

Version	Drawout		Fixed	
	Power dissipation (Watts)	Input/output resistance (µohm)	Power dissipation (Watts)	Input/output resistance (µohm)
NT06 H1/L1	55/115 (H1/L1)	38/72	30/45	26/39
NT08 H1/L1	90/140 (H1/L1)	38/72	50/80	26/39
NT10 H1/L1	150/230 (H1/L1)	38/72	80/110	26/39
NT12 H1	250	36	130	26
NT16 H1	460	36	220	26
NW08 N1	137	42	62	19
NW08 H/L	100	30	42	13
NW10 N1	220	42	100	19
NW10 H/L	150	30	70	13
NW12 N1	330	42	150	19
NW12 H/L	230	27	100	13
NW16 N1	480	37	220	19
NW16 H/L	390	27	170	13
NW20 H/L	470	27	250	13
NW25 H1/H2/H3	600	19	260	8
NW32 H1/H2/H3	670	13	420	8
NW40 H1/H2/H3	900	11	650	8
NW40b H1/H2	550	7	390	5
NW50 H1/H2	950	7	660	5
NW63 H1/H2	1200	7	1050	5

Derating in switchboards

Factors affecting switchboard design

The temperature around the circuit breaker and its connections:

This is used to define the type of circuit breaker to be used and its connection arrangement.

Vents at the top and bottom of the cubicles:

Vents considerably reduce the temperature inside the switchboard, but must be designed so as to respect the degree of protection provided by the enclosure. For weatherproof heavy-duty cubicles, a forced ventilation system may be required.

The heat dissipated by the devices installed in the switchboard:

This is the heat dissipated by the circuit breakers under normal conditions (service current).

The size of the enclosure:

This determines the volume for cooling calculations.

Switchboard installation mode:

Free-standing, against a wall, etc.

Horizontal partitions:

Partitions can obstruct air circulation within the enclosure.

Masterpact NT06-16 H1/L1 (switchboard 2000 x 400 x 400)

NT06 H1/L1 NT08 H1/L1 NT10 H1/L1 NT12 H1 NT16 H1 Туре Switchboard composition 4 3 2 1 Connection type _ Ш 111 111 Busbar dimensions (mm) 2b. 40 x 5 2b. 50 x 5 3b. 63 x 5 3b. 63 x 5 3b. 80 x 5 3b. 50 x 5 3b. 63 x 5 Ventilated switchboard 4 H1/L1 H1/L1 (+ IP31) **3** 630 630 800 800 1250 1400 1520 1000/1000 1000/1000 1250 T_a = 35 °C 2 101 aC 1 4 3 630 630 800 800 1000/950 1000/1000 1250 1250 1330 1440 T_a = 45 °C 2 4 1000/890 1000/960 1340 **3** 630 630 800 800 1200 1250 1250 T_a = 55 °C 2 00 400 Non ventilated switchboard 4 (⇒ IP54) 630 800 800 1000/960 1000/1000 1250 1250 1330 1400 **3** 630 Ta = 35 °C 2 0B10149 1 4 3 630 630 800 800 1000/910 1000/980 1220 1250 1260 1330 T_a = 45 °C 2 4 800 1000/860 1000/930 1230 1260 **3** 630 630 800 1150 1200 T_a = 55 °C 2 400 400 1

Note: the values indicated in these tables have been extrapolated from test data and theoretical calculations. These tables are only intended as a guide and cannot replace industrial experience or a temperature rise test.

Basis of tables

- switchboard dimensions
- number of circuit-breakers installed
- type of breaker connections
- drawout versions
- ambient temperature outside of the switchboard: Ta (IEC 60439-1).

Masterpact N	T06-08 H1/L	.1 (swite	chboa	rd 230	0 x 11	00 x 5	600)					
Туре		NT06	H1/L1					NT08	H1/L1			
Switchboard comp	osition	5 4 3 2 1										
Connection type		Ξ						_				
Busbar dimensions	s (mm)	2b. 40	x 5					2b. 50 x	x 5			
Ventilated switchbo	oard (➡ IP31)	5				630	630					800
~		4			630	630	630				800	800
	T 05 00	3		630	630	630	630			800	800	800
1014	$I_a = 35 {}^{\circ}C$	2 630	630	630	630	630	630	800	800	800	800	800
		1					630					
		5				630	630					800
230	C	4			630	630	630				800	800
	T _a = 45 °C	3		630	630	630	630			800	800	800
	-	2 630	630	630	630	630	630	800	800	800	800	800
		1					630					
		5				630	630					800
		4			630	630	630				800	800
20	⁰ T _a = 55 °C	3		630	630	630	630			800	800	800
300 - 000	u	2 630	630	630	630	630	630	800	800	800	800	800
500		1					630					
Non ventilated swit	chboard	5				630	630					800
(⇒ IP54)		4			630	630	630				800	800
\sim	T₂ = 35 °C	3		630	630	630	630			800	800	800
	u	2 630	630	630	630	630	630	800	800	800	800	800
31014		1					630					
ä		5				630	630					800
		4			630	630	630				800	800
2300	⁾ T _a = 45 °C	3		630	630	630	630			800	800	800
	u	2 630	630	630	630	630	630	800	800	800	800	800
		1					630					
		5				630	630					800
		4			630	630	630				800	800
200	⁰ T₂ = 55 °C	3		630	630	630	630			800	800	800
300-600-	-u •	2 630	630	630	630	630	630	800	800	800	800	800
500		1					630					

Disjoncteurs N	Disjoncteurs Masterpact NT10-16 H1/L1 (switchboard 2300 x 1100 x 500)												
Туре		NT10 H	1/L1			NT12 H	11			NT16 H	11		
Switchboard compos	sition	5 4 3 2 1											
Connection type		Ξ				Ξ	Ш	Ш		Ξ	Ш		
Busbar dimensions ((mm)	3b. 63 x	5			3b. 63 x	5			3b. 80 x	5		
			2b. 63 x	5			3b. 50 x	ĸ 5			3b. 63 x	: 5	
Ventilated switchboa	rd (➡ IP31)	5 H1/L1	H1/L1	H1/L1	H1/L1								
		4			1000/1000				1250				
	T 35 °C	3		1000/10	001000/1000			1250	1250			1500	
		2 1000/100	001000/10	001000/10	001000/1000	1250	1250	1250	1250	1460	1600	1550	
2300	T _a = 45 °C	5 4 3 2 1000/960	0 1000/10	1000/10 0001000/10	1000/1000 001000/1000 001000/1000	1250	1250	1250 1250	1250 1250 1250	1400	1500	1420 1480	
		5											
.200		4			1000/920				1250				
600	T _a = 55 °C	3		1000/95	50 1000/930			1250	1250			1330	
500		2 1000/90	0 1000/10	000 1000/97	0 1000/950	1250	1250	1250	1250	1300	1400	1370	
Non ventileted ewite	hhaard	1											
(⇒ IP54)	liboaru	3			1000/950				1250				
	T. = 35 °C	3		1000/10	00 1000/960			1250	1250			1370	
		2 1000/100	01000/10	001000/10	00 1000/970	1250	1250	1250	1250	1400	1500	1400	
1014		5											
	T 45 00	4			1000/900				1180				
	$I_a = 45 °C$	3		1000/95	50 1000/910			1250	1190			1300	
		2 1000/95	0 1000/10	000 1000/96	60 1000/930	1250	1250	1250	1220	1350	1430	1320	
		5											
	T 55 °C	4			1000/850				1120				
		3		1000/90	0 1000/860			1200	1130			1210	
200		2 1000/88	0 1000/97	70 1000/91	0 1000/870	1210	1250	1210	1150	1250	1350	1250	
300 600 200													









Substitution kit Fixed / drawout devices 800 to 3200 A

It is possible to replace a **Masterpact (M08 to M32)** with a new **Masterpact (NW08 to NW32)** with the same power rating.

Substitution is possible for the following types of circuit breakers:

- N1, H1, H2 for both fixed and drawout versions
- L1 for drawout versions up to 2000 A.



Fixed version



■ with the new escutcheon, the cut-out is different. Drawout version



Raccordement de puissance

Select a set of retrofit connectors to replace the standard connectors and avoid any modifications to the busbars (see the retrofit section in "orders and quotations").

Note:

(1) Without escutcheon.

(2) With escutcheon.

References **X** and **Y** represent the symmetry planes for threepole devices.

Substitution kit Fixed / drawout devices 800 to 3200 A

Electrical diagrams

Correspondences between Masterpact NW and Masterpact M terminal blocks.





Additional characteristics

Presentation	6
Functions and characteristics	13
Dimensions and connection	59
Electrical diagrams	87
Installation recommendations	97
Tripping curves	122
Limitation curves	124
Current limiting	124
Energy limiting	125
Catalogue numbers, spare parts and order form	127

Tripping curves

Additional characteristics



.5 .7 1

234 — xlr-

3 4 5 7 10

20 3 5 7 10

-

– x In —

20 30

Tripping curves

Additional characteristics

Earth fault protection (Micrologic 6.0)



IDMTL curve (Micrologic P and H)



Additional characteristics

Limitation curves Current limiting

Voltage 380/415/440 V AC



Voltage 660/690 V AC





Additional characteristics

Limitation curves Energy limiting

Voltage 380/415/440 V AC



Voltage 660/690 V AC



Masterpact

Catalogue numbers, spare parts and order form

Presentation Functions and characteristics Dimensions and connection Electrical diagrams	6 13 59 87
Installation recommendations Additional characteristics	97 121
Communication bus accessories and Display Modules	128
Retrofit solutions	129
Connection for fixed devices	129
Connection for drawout devices	130
Masterpact NT	131
Connection	131
Micrologic control unit, communication option	132
Remote operation	133
Chassis locking and accessories	134
Clusters	135
Circuit breaker locking and accessories	136
Mechanical interlocking for source changeover	137
Indication contacts	138
Instructions	139
Masterpact NW	140
Connection	140
Micrologic control unit, communication option	141
Remote operation	142
Chassis locking and accessories	143
Clusters	144
Circuit breaker locking and accessories	145
Mechanical interlocking for source changeover	146
Indication contacts	147
Instructions	148
Masterpact NT and NW order form	149

Catalogue numbers

Communication bus accessories and Display Modules

Display modules									
DMB300									
	Monochrome display module	Max. 4 breakers	50894						
10000			I						
DMC300									
	Color display module	Max. 16 breakers	50895						
E67955									
Spare parts									
E67965									
RS485 Modbus pr	e-wired system								
RS485 Modbus junctio	on block								
~	CJB306: 6 SubD 9 pins conr	ectors junction block	50963						
Eervage			I						
RS485 Modbus conne	ctor								
1	CSD309: 9 pins SubD with s	crew terminals	50964						
RS485 Modbus cables									
	CDM303: display module pre	e-wired cable, 3 m length	50960						
Eerraeo									
	CCP303: Masterpact or Com	pact pre-wired cable (4 RS485 wires + 2 power wires) 3	3 m length 50961						
73015									
^w 🍯	CCR301: RS485 roll cable (2	2 RS485 wires + 2 power wires) 60 m length	50965						
E677961									
External 24 V DC	power-supply module								
External 24 V DC powe	er-supply module								
- Sad	Input 24/30 V DC		54440						
*	48/60 V DC		54441						
84051	100/125 V D	C	54442						
	110/130 V A	C	54443						
Allan	200/240 V A	C	54444						
	380/415 V A	C	54445						
Converter									
	RS485/RS232 (ACE909) 12	V DC power supply included	59648						
	RS485/RS232		TSX SCA72	(1)					
	RS485/Ethernet		174 CEV 300-20	(1)					
	RS485/Ethernet (SMS comp	atible)	EGX 200/400	(2)					
Micro Power Server M	PS100		2011 2001 400						
	MPS100		33507						
1010									

(1) See catalogue Telemecanique.(2) See catalogue PowerLogic System.

Catalogue numbers

Retrofit solutions (*) Connection for fixed devices

To replace a Masterpact M with a Masterpact NW, order a retrofit device (without connections) and select a set of connectors corresponding to the replaced device.

The Masterpact NW is installed in exactly the same place as the old Masterpact M device, without any modifications required on the switchboard.

Horizontal rear connection

Device to be replaced		Connection to be ordered		
Masterpact M08 to M12				
Type N1/NI				
		3P		4P
Тор	3 x	48951	4 x	48951
Bottom	3 x	48964	4 x	48964
Type H1/H2/HI/HF				
Тор	3 x	48954	4 x	48954
Bottom	3 x	48965	4 x	48965
Masterpact M16				
Type N1/NI/H1/H2/HI/HF				
Тор	3 x	48954	4 x	48954
Bottom	3 x	48965	4 x	48965
Masterpact M20 and M25				
Type N1/NI/H1/H2/HI/HF				
Тор	3 x	48957	4 x	48957
Bottom	3 x	48958	4 x	48958
Masterpact M32				
Type H1/H2/HI/HF				
Тор	1 x	48962	1 x	48960
Bottom	1 x	48961	1 x	48960
(*) Please contact LI2R (Retrofit	Renl	acement Init)		

Please contact U2R (Retrofit Replacement Unit).

Catalogue numbers

Retrofit solutions (*) Connection for drawout devices

To replace a Masterpact M with a Masterpact NW, order a retrofit device (without connections) and select a set of connectors corresponding to the replaced device.

The Masterpact NW is installed in exactly the same place as the old Masterpact M device, without any modifications required on the switchboard.

Vertical rear connection

Device to be replaced		Connection to be ordered		
Masterpact M08 to M12				
Type N1/NI				
		3P		4P
Тор	3 x	48966	4 x	48966
Bottom	3 x	48966	4 x	48966
Type H1/H2/HI/HF				
Тор	3 x	48969	4 x	48969
Bottom	3 x	48969	4 x	48969
Masterpact M16				
Type N1/NI/H1/H2/HI/HF				
Тор	3 x	48969	4 x	48969
Bottom	3 x	48969	4 x	48969
Masterpact M20 and M25				
Type N1/NI/H1/H2/HI/HF				
Тор	3 x	48970	4 x	48970
Bottom	3 x	48970	4 x	48970
Masterpact M32				
Type H1/H2/HI/HF				
Тор	1 x	48974	1 x	48978
Bottom	1 x	48974	1 x	48978

Horizontal rear connection

Device to be replaced		Connection to be ordered		
Masterpact M08 to M12				
Type N1/NI				
		3P		4P
Top 3	х	48951	4 x	48951
Bottom 3	х	48964	4 x	48964
Type H1/H2/HI/HF				•
Тор 3	х	48954	4 x	48954
Bottom 3	х	48965	4 x	48965
Masterpact M16				
Type N1/NI/H1/H2/HI/HF				
Тор 3	х	48954	4 x	48954
Bottom 3	х	48965	4 x	48965
Masterpact M20 and M25				
Type N1/NI/H1/H2/HI/HF				
Тор 3	х	48957	4 x	48957
Bottom 3	х	48958	4 x	48958
Masterpact M32 neutral on l	ef	t-hand side		
Type H1/H2/HI/HF				
Тор 1	х	48973	1 x	48976
Bottom 1	х	48973	1 x	48977
Masterpact M32 neutral on r	ig	ht-hand side		
Type H1/H2/HI/HF				
Top 1	х	48973	1 x	48977
Bottom 1	х	48973	1 x	48976
	-			

(*) Please contact U2R (Retrofit Replacement Unit)

Masterpact NT Connection

(*) Installation manual must be ordered separatly, it is not supply with the component

Connection					
Connoolion	•			30	4P
Fixed circuit b	roakors			51	
Front connection	n / Bonlacomont	kit (2 or 4 parts)			
	n / Replacement	Top or bottom	630/1600 A	47069	47070
* 69 69			650/1000 A	47009	47070
" Ostala Balana					
		Installation manual		47102	
Poor connection	(vortical or hori	installation manual	nont kit (2 or 4 norte)	47102	
		zontai mounting) / Replacei	630/1600 A	33584	23585
	. AND		050/1000 A	33304	33303
444 449 449 449 449 449 449 449 449 449	4643				
Vert. mounting.	Horiz. mountina.	Installation manual		47102	
Drawout circu	it breakers				
Front connection	n / Replacement	kit (6 or 8 parts)			
-		Top and bottom	630/1600 A	33588	33589
*PPP		•		1	•
8 C C					
10000					
600		Installation manual		47102	
Rear connection	(vertical or hori	zontal mounting) / Replacer	ment kit (3 or 4 parts)		
	(AR CON		630/1600 A	33586	33587
	⁸ 20 0				
E46	E46				
Vert. mounting.	Horiz. mounting.	Installation manual		47102	
Connection	accessorie	es			
				3P	4P
Vertical conne	ection adapters	630/1600 A / Replaceme	ent kit (3 or 4 parts)		
		For fixed and drawout front-o	connected circuit breakers	33642	33643
* 19 No 10					
E4		Installation manual		47102	
Cable lug ada	oters 630/1600	A / Replacement kit (3 o	or 4 parts)		
a la		For fixed and drawout front-o	connected circuit breakers	33644	33645
47 0000 00 1		Installation manual		47102	
Spreaders / Re	eplacement kit	(3 or 4 parts)			
		For fixed and drawout front a	and rear-connected circuit breakers	33622	33623
5000000000					•
		Installation manual		47100	
	riero / Deples			47102	
interphase bar	ners / Replace	For fixed and drawaut frants)	and root connected sizewith breaks	22649	22649
PAd		For drawout rear connected		33040	22769
79151				47102	55100
Mrs shuts sau	on (1 nort)			102	
Arc chute scre	en (1 part)	Factored front comments in the		47005	47000
	>	For fixed front-connected cire	Cuit dreakers	47335	47336
4437		Installation manual		47400	
ш ~		installation manual		4/ 102	

Masterpact NT Micrologic control unit, communication option

(*) Installation manual must be ordered separatly, it is not supply with the component

		•	
Replacement parts for	Micrologic control	units	
Long-time rating plug (limits	s setting range for highe	r accuracy) / 1 part	
	Standard	0.4 at 1 x Ir	33542
1 2 2 °	Low-setting option	0.4 at 0.8 x lr	33543
E 466	High-setting option	0.8 at 1 x Ir	33544
	Without long-time protection	off	33545
	Installation manual		33075
Battery + cover			
	Battery (1 part)		33593
	Cover (1 part)	For Micrologic A	33592
		For Micrologic P and H	47067
			22075
	Installation manual		53075
Communication option	า		
Chassis			
	Modbus COM		33852
¥ 00000	Digipact COM		33855
	6 wires terminal drawout (1 p	part)	33099
	6 wires terminal fixed (1 part	i)	47075
AN	Installation manual		33088
External sensors			
External sensor for earth-fault p	rotection (TCE) / 1 part		
\sim	Sensor rating	400/1600 A	33576
E 49671			•
Source ground return (SGR) ear	th-fault protection / 1 part		
	External sensor (SGR)		33579
E46671	MDGF summing module		48891
Rectangular sensor for earth-lea	kage protection + Vigi cable	e / 1 part	
	280 mm x 115 mm		33573
E 46672			
Vigi cable or external voltag	e cable / 1 part		
	Vigi cable or external voltage	e cable (1 part)	47090
External power supply modu	ule / 1 part		
(Inc.)		24-30 V DC	54440
58 manual 200		48-60 V DC	54441
E		100-125 V DC	54442
		110-130 V AC	54443
		200-240 V AC	54444
		380-415 V AC	54445
Battery module / 1 part			
	1 battery	24 V DC	54446
Test equipments / 1 part			
-	Mini test kit		33594
9956	Portable test kit		33595
E Contraction of the second se	vviring kit or mini test kit or p	iortable test kit	33590
	2 pin test cable		548908 (*)

(*) Consult us.

Masterpact NT Remote operation

(*) Installation manual must be ordered separatly, it is not supply with the component

	MCH (1 part)		
n Da	AC 50/60 Hz	48 V	33186
		100-130 V	33176
) [200-240 V	33177
1 Mai		277-415 V	33179
		440-480 V	33179
		+ resistor	33193
	DC	24-30 V	33185
\checkmark		48-60 V	33186
		100-125 V	33187
		200-250 V	33188
	Terminal block (1 part)	For fixed circuit breaker	47074
		For drawout circuit breaker	33098
			•
E 1951			
E96171			
ked. Drawou	t.		

	Installation manual		47103			
Closing and opening rele	ease (XF or MX)					
	Standard coil (1 part)					
1 Pa	AC 50/60 Hz	12 V DC	33658			
2 Hon	DC	24-30 V AC/DC	33659			
EB62		48-60 V AC/DC	33660			
- P		100-130 V AC/DC	33661			
		200-250 V AC/DC	33662			
		277 V AC	33663			
- Г -		380-480 V AC	33664			
	Communicating coil (1 p	Communicating coil (1 part)				
	AC 50/60 Hz	12 V DC	33032			
	DC	24-30 V AC/DC	33033			
		48-60 V AC/DC	33034			
		100-130 V AC/DC	33035			
		200-250 V AC/DC	33036			
		277 V AC	33037			
		380-480 V AC	33038			
	Terminal block (1 part)	For fixed circuit breaker	47074			
R		For drawout circuit breaker	33098			
			•			









Drawout.

	Installation manual		47103		
Undervoltage release MN					
	Undervoltage release (1	part)			
	AC 50/60 Hz	24-30 V DC, 24 V AC	33668		
2	DC	48-60 V DC, 48 V AC	33669		
E		100-130 V AC/DC	33670		
		200-250 V AC/DC	33671		
		380-480 V AC	33673		
	Terminal block (1 part)	For fixed circuit breaker	47074		
т Т		For drawout circuit breaker	33098		

E95171 Fixed.

	Installation manual			47103	
MN delay unit					
a for	MN delay unit (1 pa	rt)			
5 000000			R (non-adjustable)	Rr (adjustable)	
E400	AC 50/60 Hz	48-60 V		33680	
	DC	100-130 V	33684	33681	
		200-250 V	33685	33682	
		380-480 V		33683	
	Installation manual			47103	



Masterpact NT Chassis locking and accessories

(*) Installation manual must be ordered separatly, it is not supply with the component

Chassis locking						
"Disconnected" position loc	king / 1 part					
0 m	By padlocks					
			Standard			
Ete	By keylocks		1			
	Profalux	1 lock	33773			
		1 lock + 1 lock with same key profile	33774			
	····	2 locks (different key profiles)	33775			
	1 identical keylock Profalux	with the same key:				
		key: random not identified combination	33173			
		key: random identified 215470 combination	33174			
	Ponio	1 look	33173			
	Roms	1 lock + 1 lock with same key profile	33777			
		2 locks (different key profiles)	33778			
	1 identical keylock Ronis wit	h the same key :	33110			
		key: random not identified combination	33189			
		key: random identified EL24135 combination	33190			
		key: random identified EL24153 combination	33191			
		key: random identified EL24315 combination	33192			
	Locking kit without locks for	Profalux	33769			
	5	Ronis	33770			
		Castell	33771			
		Kirk	33772			
	Installation manual		47104			
Door interlock / 1 part						
L. V.	Right and left-hand side of c	hassis (VPECD or VPECG)	33172			
2 0			•			
199 L 0						
	Installation manual		47104			
Racking interlock / 1 part						
	Racking interlock (VPOC)		33788			
5 C						
E46						
()						
			L			
	Installation manual		47104			
Breaker mismatch protection	n / 1 part		1			
	Breaker mismatch protection	n (VDC)	33767			
55 0 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5						
± o						
	Installation manual		47104			
Chassis accessories						
Auxiliary terminal shield (CB	B) / 1 part					
	Terminal shield	3P	33763			
865		4P	33764			
18						
~	Installation manual		47104			
Safety shutters + locking / 1	part					
	Safety shutters (VO)	3P	33765			
in and a second		4P	33766			
and the second s	Installation manual		47104			
	Nota : the locking of safety s	shutters is integrated.				
	· · ·					

Masterpact NT Clusters

CI	ust	ers



Grease for disconnecting contact clusters (1 kg)	54122
1 disconnecting contact cluster for chassis (see table below) 1 part	33166

47098

Table : number of clusters required for the different chassis models

Chassis rating (A)	Masterpact NT			
	3P	4P		
630	12	18		
800	12	18		
1000	12	18		
1250	12	18		
1600	18	24		
Nota : the minimum order is 6 parts.				

Racking handle

Racking handle / 1 part



Masterpact NT Circuit breaker locking and accessories

(*) Installation manual must be ordered separatly, it is not supply with the component

Circuit breaker locking						
Pushbutton locking device / 1 part						
	By padlocks				33897	
E40666						
	Installation manual				47103	
OFF position locking / 1 part	By nodlocko y DDEE over	t				
- 0000	By paulocks + BFFE Supp	Joit			47514	
	By keylocks + BPFE support					
	Profalux	1 lock			47519	
		1 lock + 1 lock with same key p	orofile		47520	
	1 identical keylock Profalux	with the same key:			00470	
	key: random not identified combination				33173	
		key: random identified 215470	combination		33174	
	Ronis	1 lock			47521	
		1 lock + 1 lock with same key p	orofile		47522	
	1 identical keylock Ronis wit	h the same key :				
		key: random not identified com	bination		33189	
		key: random identified EL2413	5 combination		33190	
		key: random identified EL2413	5 combination		33192	
	Locking kit without locks for	Profalux			47515	
		Ronis			47516	
		Kirk			47517	
	1. A. H. A	Castell			47518	
Other circuit breeker o					47103	
Other Circuit breaker a						
Mechanical operation counter	Operation counter CDM				33805	
E 4000					55655	
	Installation manual				47103	
Escutcheon and accessories	s / 1 part		1			
		Facutaboon	Fixed		Drawout	
	// L994 500 1	Transparent cover (IP 54)	33718		33859	
		Escutcheon blanking plate			33858	
					•	
EscutcheonCoverBlanking plate		Installation manual			47103	
Front cover (3P / 4P) / 1 part						
	Front cover				47094	
	Instaliation manual				47103	
Spring charging handle / 1 p	art					
n	Spring charging handle				47092	
9	Installation manual				47103	
Arc chute for Masterpact NT	/ 1 part					
			3P		4P	
	Type H1	3	x 47095	4 x	47095	
EBECEBOO	і уре L1	3	x 47096	4 x	47096	
	Installation manual				47103	

Masterpact NT Mechanical interlocking for source changeover

Mechanical interlocking for source changeover						
Interlocking using connect	cting rods					
AT THE .	Complete assembly with 2 adaptation fixtures + rods					
99	2 Masterpact NT fixed devices	33912				
E41	2 Masterpact NT drawout devices	33913				
	Nota : the installation manual is enclosed.					



Interlocking using cables (1)

Į

	Choose 2 adaptation fixtures (1 for each breaker) + 1 set of cables	
	1 adaptation fixture for Masterpact NT fixed devices	33200
	1 adaptation fixture for Masterpact NT drawout devices	33201
	1 set of 2 cables	33209
	(1) Can be used with any combination of NT or NW, fixed or drawout devices.	
Cable-type door i	interlock	
\sim	1 complete assembly for Masterpact NT fixed devices	33920
45	1 complete assembly for Masterpact NT drawout devices	33921
EZ01	Nota : the installation manual is enclosed.	

Merlin Gerin

137

Masterpact NT Indication contacts

(*) Installation manual must be ordered separatly, it is not supply with the component

Indication contacts			
ON/OFF indication contacts	(OF) / 1 part		
	Changeover contacts (6 A	- 240 \/)	47076
	1 low-level OF to replace 1	standard OF (4 max)	47077
898 999	Wiring	For fixed circuit breaker	47074
	······g	For drawout circuit breaker	33098
	Installation manual		47103
"Fault trip" indication conta	cts (SDE) / 1 part		
	1 additional SDE (5 A - 240) V)	47078
	1 additional low-level SDE		47079
	Wiring	For fixed circuit breaker	47074
	5	For drawout circuit breaker	33098
S	Installation manual		47103
"Ready to close" contact (1	max.) / 1 part		
	, ,		PF
	1 changeover contact (5 A	- 240 V)	47080
E 4666	1 low-level changeover cor	ntact	47081
	Wiring	For fixed circuit breaker	47074
E E	Ū.	For drawout circuit breaker	33098
	Installation manual		47103
Electrical closing pushbutto	on / 1 part		
Q			BPFE
	1 pushbutton		47512
E49			•
	Installation manual		47103
Carriage switches (connected	ed / disconnected / test	position) / 1 part	
₽~\	Changeover contacts (6	A - 240 V)	
	1 connected position conta	ct (3 max.)	33170
E466	1 test position contact (1 m	lax.)	33170
	1 disconnected position co	ntact (2 max.)	33170
	And/or low-level change	over contacts	· · · · · · · · · · · · · · · · · · ·
	1 connected position conta	ict (3 max.)	33171
	1 test position contact (1 m	lax.)	33171
	1 disconnected position co	ntact (2 max.)	33171
Auxiliary terminals for chase	sis alone		
R	3 wire terminal (1 part), ter	minal block (1 part)	33098
17	Jumpers (10 parts)		47900
	Installation manual		47104

Masterpact NT Instructions

(*) Installation manual must be ordered separatly, it is not supply with the component

Instructions		
Chassis accessories		47104
Circuit breaker accessories		47103
Fixed and drawout circuit brea	aker	47102
Micrologic user manual	20 / 50 (French)	33076
	20 / 50 (English)	33077
	2A / 7A (French)	33079
	2A / 7A (English)	33080
	5P / 7P (French)	33082
	5P / 7P (English)	33083
	5H / 7H (French)	33085
	5H / 7H (English)	33086
NT user manual	French	47106
	English	47107
Modbus communication notic	e for manual	33088
Micrologic accessories replac	ement guide	33075

Masterpact NW Connection

(*) Installation manual must be ordered separatly, it is not supply with the component

Connection				
			3P	4P
Fixed circuit breakers				
Front connection / Replacement	t kit (3 or 4 parts)			
- Jeee	800/1600 A	Тор	47990	47991
49	2000/3200 A	Тор	47992	47993
			-	
00000				
ţ,				-
	800/1600 A	Bottom	47932	47933
00000	2000/3200 A	Bottom	47942	47943
E32				
	Installation manual		47950	
Rear connection (vertical or hor	izontal mounting) / Replace	ement kit (3 or 4 parts)		
	800/2000 A	Vertical	47964	47965
¥ 6 9 9 9 9		Horizontal	47964	47965
	2500/3200 A	Vertical	47966	47967
Vertical mounting		Horizontal	47966	47967
	4000 A	Vertical	47968	47969
		Horizontal	47970	47971
	4000b/5000 A	Vertical 2x	47966 2x	47967
E46		Horizontal 2x	47966 2x	47967
Horizontal mounting	6300 A	Vertical 2x	47968 2x	47969
	Installation manual		47950	
Drawout circuit breakers				
Front connection / Replacement	t kit (3 or 4 parts)			
	800/1600 A	Top or bottom	47960	47961
	2000/3200 A	Top or bottom	47962	47963
E464			•	•
000				
00000				
	Installation manual		47950	
Rear connection (vertical or hor	izontal mounting) / Replace	ement kit (3 or 4 parts)		
~ 53	800/2000 A types N1/H1/H2	2 Vertical	47964	47965
¥ 6 9 6 9 6 9	800/1600 A types H3/L1	Horizontal	47964	47965
	2500/3200 A types H1/H2	Vertical	47966	47967
Vertical mounting	2000/3200 A types H3/L1	Horizontal	47966	47967
Ventical mounting	4000 A	Vertical	47968	47969
The sea		Horizontal	47970	47971
* Per Per	4000b/5000 A	Vertical 2x	47966 2x	47967
E464		Horizontal 2x	47966 2x	47967
Horizontal mounting	6300 A	Vertical 2x	47968 2x	47969
	Installation manual		47950	-
Connection accessori	es			
			3P	4P
Disconnectable front-conne	ction adapter for fixed o	ircuit breaker (3 or 4 parts)		1
	1600 A		48464	48466
1000	2000/3200 A		48465	48467
466	2000/0200 A			10701
	Installation manual		47950	
Interphase barriers / Replac	ement kit (3 parts)			
	For fixed rear-connected cir	cuit breaker	48599	48599
	For drawout rear-connected	l circuit breaker	48600	48600
₹ <u>₹</u>			•	•
	Installation manual		47050	
✓ ·	installation manual		47950	

Masterpact NW Micrologic control unit, communication option

(*) Installation manual must be ordered separatly, it is not supply with the component

Replacement parts for	Micrologic control	units	
Long-time rating plug (limits	setting range for highe	r accuracy) / 1 part	
	Standard	0.4 at 1 x lr	33542
2	Low-setting option	0.4 at 0.8 x lr	33543
E 466	High-setting option	0.8 at 1 x lr	33544
	Without long-time protection	off	33545
	Installation manual		33075
Battery + cover			
$\sim \sim 0$	Battery (1 part)		33593
	Cover (1 part)	For Micrologic A	33592
	••••• (• p•••)	For Micrologic P and H	47067
	Installation manual		33075
Communication option	1		1
Chase is			
Chassis	M # 00M		00050
			33852
199		0	33855
	6 wires terminal drawout (1	part)	47850
	6 wires terminal fixed (1 par	t)	47075
0	la stallation as social		00000
	Installation manual		33088
Extornal concore			
External sensor for earth fault n	rotaction (TCE) / 1 part		
External sensor for earth-fault p	Sensor roting	400/2000 A	24025
	Sensor raung	400/2000 A	24035
		1000/4000 A	49192
" "		4000/0300 A	46162
Source around return (SGR) ear	th-fault protection /1 part		
	External sensor (SGR)		33570
	MDGE summing module		48801
			40031
Rectangular sensor for earth-lea	kage protection + Vigi cabl	e / 1 part	
	280 mm x 115 mm		33573
	470 mm x 160 mm		33574
E 466			1
Vigi cable or external voltage	e cable / 1 part		
	Vigi cable or external voltag	e cable	47090
	vigi cablo of oxformal voltag		41000
External power supply modu	ile / 1 part		
	no, i part	24-30 \/ DC	54440
- Connort -		48-60 V DC	54441
000000		100-125 V DC	54442
"		110-130 \/ AC	54443
		200-240 \/ AC	54444
		380-415 \/ AC	54445
Battory modulo / 1 part		380-413 V AC	34443
Dattery module / 1 part	1 hotton/		54446
Test equipments (4 yest	Dattery		J4440
rest equipments / 1 part			
ta la	Mini test kit		33594
8999	Portable test kit		33595
E	Wiring kit or mini test kit or p	portable test kit	33590
	2 pin test cable		S48908 ^(*)
H L I H			

(*) Consult us.

Masterpact NW Remote operation

(*) Installation manual must be ordered separatly, it is not supply with the component

0			
Gear motor			
	MCH (1 part)		
B	AC 50/60 Hz	48 V	47889
		100-130 V	47893
A Faller		200-240 V	47894
		250-277 V	47895
		380-415 V	47896
		440-480 V	47897
	DC	24-30 V	47888
		48-60 V	47889
EG 8		100-125 V	47890
E95		200-250 V	47891
1 and	Terminal block (1 part)	For fixed circuit breaker	47074
		For drawout circuit breaker	47849
			•
Fixed. Drawout.			
	Installation manual		47951
losing and opening rele	ease (XF or MX)		
	Standard coil (1 part)		
1 Rea	AC 50/60 Hz	12 V DC	33658
	DC	24-30 V AC/DC	33659
<i>\\\\</i>		48-60 V AC/DC	33660
		100-130 V AC/DC	33661
		200-250 V AC/DC	33662
		277 V AC	33663
4		380-480 V AC	33664
	Communicating coil (1 p	part)	
	AC 50/60 Hz	12 V DC	33032
	DC	24-30 V AC/DC	33033
		48-60 V AC/DC	33034
		100-130 V AC/DC	33035
E.		200-250 V AC/DC	33036
-		277 V AC	33037
-1136211 		380-480 V AC	33038
	Terminal block (1 part)	For fixed circuit breaker	47074
	· ····································	For drawout circuit breaker	47849
114 44			VFV IT

	Installation manual		47951
Undervoltage release	MN		
	Undervoltage release (1	part)	
1 mail	AC 50/60 Hz	24-30 V DC, 24 V AC	33668
2	DC	48-60 V DC, 48 V AC	33669
East		100-130 V AC/DC	33670
RA		200-250 V AC/DC	33671
		380-480 V AC	33673
	Terminal block (1 part)	For fixed circuit breaker	47074
a 7 8		For drawout circuit breaker	47849
1987 B			

MN delay ur	nit
-------------	-----

Drawout.

Installation manual

A

Fixed.

E46694	

		R (non-adjustable)	Rr (adjustable)
AC 50/60 Hz	48-60 V		33680
DC	100-130 V	33684	33681
	200-250 V	33685	33682
	380-480 V	•	33683
Installation manual			47951

47951
Masterpact NW Chassis locking and accessories

(*) Installation manual must be ordered separatly, it is not supply with the component

Chassis locking				
"Disconnected" position loc	king / 1 part			
	By padlocks			
	By koylocks			Standard
	Profalux	1 lock		48568
	Toldidx	$\frac{1}{1 \text{ lock} + 1 \text{ lock with same key profile}}$		48569
		2 locks (different key profiles)		48570
	1 identical keylock Profalux v	with the same key:		
		key: random not identified combination	on	33173
		key: random identified 215470 comb	ination	33174
		key: random identified 215471 comb	ination	33175
	Ronis	1 lock		48572
		1 lock + 1 lock with same key profile		48573
		2 locks (different key profiles)		48574
	1 identical keylock Ronis with	n the same key :		
		key: random not identified combination	on	33189
		key: random identified EL24135 com	bination	33190
		key: random identified EL24153 com	bination	33191
	Locking kit without locks for	key: random identified EL24315 com	IDINATION	33192
	LOCKING KIL WILLOUT IOCKS TOP			40004
		Kirk		48566
	Installation manual	NIK		40300
Door interlock / 1 part	motaliation manual			41332
	Right and left-hand side of d	hassis (VPECD or VPECG)		47914
				1011
Eaders				
N.	Installation manual			47952
Racking interlock				
~~~~	5 parts			48582
E46453				
Baral an advantation of the	Installation manual			47952
Breaker mismatch protection	1/1 part	(1/00)		00707
				53707
	Installation manual			47952
Chassis accessories				
Auxiliary terminal shield (CB	s) / 1 part			
	800/4000 A	3P		48595
22		4P		48596
lo l	4000b/6300 A	3P		48597
		4P		48598
U	Installation manual			47952
Safety shutters + locking blo	ock / 1 part			
	800/4000 A	3P		48721
	40001 /0000 1	4P		48723
	4000b/6300 A	<u>3</u> 2 4D		48722
	Installation manual	4٣		40/24
Shutter locking block for re-	nistaliation manual			41 302
Shutter locking block (for re	2 parts for 800/4000 A			49504
	2 parts for 800/4000 A			40091
■ ⁄AHY	Installation manual			47952
Earthing kit for chassis	6			
			3P	4P
Types for N1/H1/NA/HA				
			48433	48434
	Nota : the installation manua	al is enclosed.	1	<u> </u>

# Masterpact NW Clusters

(*) Installation manual must be ordered separatly, it is not supply with the component

Clusters		
SB	Grease for disconnecting contact clusters (1 kg)	54122
: Ener	1 disconnecting contact cluster for chassis (see table below) (part 1)	33166

Table : number of clusters required for the different chassis models

Chassis rating (A)	Masterp	act NW	3P		Masterp	act NW	4P	
	N1	H1/H2	H3	L1	N1	H1/H2	H3	L1
630								
800	6	12		24	8	16		32
1000	6	12		24	8	16		32
1250	6	12		24	8	16		32
1600	12	12		24	16	16		32
2000		24	24	42		32	32	56
2500		24	24			32	32	
3200		36	36			48	48	
4000		42	42			56	56	
4000b		72				96		
5000		72				96		
6300		72				96		

Nota : the minimum order is 6 parts.

#### **Racking handle**

FIND CONTRACTOR



Racking handle

47944

🖁 Merlin Gerin

#### Masterpact NW Circuit breaker locking and accessories

(*) Installation manual must be ordered separatly, it is not supply with the component

Circuit breaker locking	]			
Pushbutton locking device /	1 part			
	By padlocks			48536
The second se				
	Installation manual			47951
OFF position locking / 1 par	t			•
	By padlocks / 1 part			
2 Porton	S house of here			48539
	By padlocks and keylocks	s/1 part		
	Profalux	1 lock		48545
		1 lock + 1 lock with same key pro	ofile	48546
		2 locks (different key profiles)		48547
	1 identical keylock Profalux	with the same key:		
Ũ	,	kev: random not identified combi	ination	33173
		kev: random identified 215470 c	ombination	33174
		key: random identified 215471 c	ombination	33175
	Ronis	1 lock		48549
		1 lock + 1 lock with same key pro	ofile	48550
		2 locks (different key profiles)		48551
	1 identical kevlock Ronis wit	h the same kev :		-
		kev: random not identified combi	ination	33189
		key: random identified EL24135	combination	33190
		key: random identified EL24153	combination	33191
		kev: random identified EL24315	combination	33192
	Locking kit without locks for	Profalux. Ronis		48541
	<b>3</b>	Kirk		48542
		Castell		48543
	Installation manual			47951
Other circuit breaker a	ccessories			
Machanical encretion count				
mechanical operation count	er / i part			40505
TOR A	Operation counter CDM			48535
" De la	Installation manual			47054
Frankshoon and second	Installation manual			47951
Escutcheon and accessories	s/1 part		1	
	1	E	Fixed	Drawout
	// 199		48601	48603
	, <u> </u>	Fransparent cover (IP 54)	40005	48604
		Escutcheon blanking plate	48605	48605
Facutebach Cover	<b>Blanking plate</b>	Installation manual		47054
Escuicheon Cover	Bianking plate	Installation manual		47951
	Frank anna			47000
	Front cover			47939
	Installation manual			47054
	Installation manual			47951
Spring charging handle / 1 p	bart			L
A	Spring charging handle			47940
238				
ESC ESC				
GRV (				
<b>P</b> P	Installation manual			47951
Arc chute for Masternact NV	V / 1 part			I
			3P	4P
	Type N1	3 v	47935 ⁴ v	47935
	Type H1/H2 (NI\//08 to NI\//4	0) 3×	47935 4 4	47935
3000 000 000 000 000 000 000 000 000 00	Type H1/H2 (NIM/40b to NIM/	c, 3 X 63) 6 v	47936 8 v	47936
	Type H3	0X 2 V	47936 4v	47936
10000000000000000000000000000000000000		3 X	47937 4 v	47937
oden inn.		3 S X	47934 4×	47934
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	5.	44	

#### Masterpact NW Mechanical interlocking for source changeover

(*) Installation manual must be ordered separatly, it is not supply with the component

Mechanical interlo	ocking for source changeover	
nterlocking of 2 devic	es using connecting rods	
1000 50	Complete assembly with 2 adaptation fixtures + rods	
1500 FB	2 Masterpact NW fixed devices	48612
	2 Masterpact NW drawout devices	48612
	Can be used with 1 NW fixed + 1 NW drawout.	
	<b>Nota :</b> the installation manual is enclosed.	
terlocking of 2 devic	es using cables ⁽¹⁾	
	Choose 2 adaptation sets (1 for each device + 1 set of cables)	
	1 adaptation fixture for Masterpact NW fixed devices	47926
	1 adaptation fixture for Masterpact NW drawout devices	47926
	1 set of 2 cables	33209
	(1) Can be used with any combination of NT or NW, fixed or drawout devices.	
terlocking of 3 devic	es using cables	
-	Choose 3 adaptation (inclusing 3 adaptation fixtures + cables)	
	3 sources, only 1 device closed, fixed or drawout devices	48610
	2 sources + 1 coupling, fixed or drawout devices	48609

	2 normal + 1 replacement source, fixed or drawout devices	48608
Cable-type door interloo	ck	
	1 complete assembly for Masterpact NW fixed or drawout device	48614
	Nota : the installation manual is enclosed.	

### Masterpact NW Indication contacts

(*) Installation manual must be ordered separatly, it is not supply with the component

Indicatio	n contacts			
ON/OFF ind	dication contacts	(OF) / 1 part		
	~ #	1 additional block of 4 conta	cts	47887
68	88553	Wiring	For fixed circuit breaker	47074
E4661		Ū	For drawout circuit breaker	47849
				1
	and the second s			
	Alter	Installation manual		47951
"Fault trip"	indication conta	cts (SDE) / 1 part		
	R	Changeover contact (SDE)	6 A - 240 V	47915
691			Low-level	47916
E 46		Wiring	For fixed circuit breaker	47074
	and the second s		For drawout circuit breaker	47849
	Mr			
A BOOM	1 4			
	~	Installation manual		47951
"Ready to o	close" contact (1	max.) / 1 part		
				PF
		1 changeover contact (5 A -	240 V)	47080
		1 low-level changeover cont	act	47081
		Wiring	For fixed circuit breaker	47074
			For drawout circuit breaker	47849
		Installation manual		47951
"Connected	d, disconnected,	test position" indication	contact (carriage switches) / 1 part	
R		Changeover contacts	6 A - 240 V	33170
		CE, CD, CT	Low-level	33171
2ª				
		Installation manual		47952
Set of addit	tional actuaters f	or carriage switches / 1	set	
		1 set		48560
Combined	alagad / agamagt	ad aantaata far waa with	1 auviliant contact / 1 nort	
Combined	ciosea / connecte	4 contacts for use with	Tauxillary contact / T part	49.477
₽S -		r 1 low lovel contact		404/7
		or i low-level contact		46478
" <b>N</b>				
elle in				
				47050
		Installation manual		47952
Electrical c	losing pushbutto	on / 1 part		1
				BPFE
i An		1 pushbutton		48534
4 L ¹⁰				
$\square$				17051
		Installation manual		47951
Auxiliary te	erminals for chase	sis alone		
		3 wire terminal (1 part)		47849
		6 wire terminal (1 part)		47850

Jumpers (10 parts)

47900

### Masterpact NW Instructions

Instructions		
Chassis accessories		47952
Circuit breaker accessories		47951
Fixed and drawout circuit brea	aker	47950
User manual	NW AC (French)	47954
	NW AC (English)	47955
	NW DC (French)	47957
	NW DC (English)	47958
Micrologic user manual	20 / 50 (French)	33076
	20 / 50 (English)	33077
	2A / 7A (French)	33079
	2A / 7A (English)	33080
	5P / 7P (French)	33082
	5P / 7P (English)	33083
	5H / 7H (French)	33085
	5H / 7H (English)	33086
Modbus communication notic	e for manual	33088
Micrologic accessories replac	ement guide	33075

#### Order form

### Masterpact NT and NW order form

To indicate your choice, check the applicable square boxes

and enter the appropriate information in the rectangles

Circuit breake	r				(	Du	ant	itv		
or switch-disc	onnecto	r					anne	,	-	
Masternact type	NT	•					NW			
Rating	A									
Sensor rating	А									
Circuit breaker	N1	. H1	. Н2	. н:	3. L1					
Special circuit bre	aker <b>H2</b>	anti	, icor	ros	ion.	H1	0		-	
Switch-disconnect	or NA	. НА	. н	F. H	A10	. E	S		-	
Number of poles	3 0	or 4	-,	,		, –			-	
Brand	MC	3						SD		
Option: neutral on	right side	-						-		
Type of equipmen	t	Fixe	ed							
		Dra	wou	ıt wi	ith ch	nas	sis			
		Dra	wou	ıt wi	ithou	t cł	nass	sis		
		(mc	oving	g pa	rt on	ly)				
		Cha	assi	s alo	one					
Earthing switch kit	for chassi	S								
Micrologic co	ntrol unit	t								
A - ammeter	2.0		5.0		e	6.0			7.0	
P - power meter			5.0		6	5.0			7.0	
H - harmonic me	ter		5.0		6	6.0			7.0	
LR - long-time rati	ng plug	Sta	nda	rd 0	.4 to	11	r			
		Low	v se	tting	g 0.4	to	0.8	lr		
		Hig	h se	ettin	g 0.8	to	1 Ir			
		LR	OFF	-						
AD - external pow	er-supply i	modu	ule					V		
BAI - battery mod										
and residual earth	nsor (CT) f -fault prote	or ne	eutra n	al					1	
TCE - external set (3P - Micrologic P	nsor (CT) f / H) and re	or ov esidu	/er s ial e	size arth	d ne n-fau	utra It p	al rote	ctic	on	
TCW - external se	nsor for S	GR p	orote	ectic	n					
Rectangular sen	sor		NT	(28)	) x 1	15	mm	)		
for earth-leakage	protection		NW	、 (47	'0 x ⁻	160	) mn	n)		
PTE - external vol	tage conne	ector						,		
Communicatio	on									
COM module	JBus/	De	vice	•			Cha	ssi	s	
	ModBus			i i					i i	
	Digipact	De	evice	3			Cha	issi	S	
Eco COM	ModBus (for XE or	MY	com	mu	nicat	ina	rola	226	۵)	
Connection		IVIZ V	com	ma	nout	ing	TOIC	,43	0)	
Horizontal			Top	,			Bott	om	1	
Vertical			Тор	,			Bott	om		
Front			Тор	,			Bott	om		
Vertical-connectio	n adapters	;	NT	- FC	C fixe	ed.	drav	N.	-	
Cable-lug adapter	s		NT	- FC	C fixe	ed.	drav	N.		
Arc chute screen			NT	- FC	C fixe	d				
Interphase barrier	S		NT.	NV	/ fixe	ed,	drav	vol	Jt	
Spreaders			NT	fixe	d, dr	aw	out			
Disconnectable			NW	fixe	ed					
front connection a	dapter									
Lugs for 240° or 3	00 ⁿ cables	;	NT	fixe	d, dr	aw	out			
Micrologic control 2.0 : basic protect	unit functio ion (long ti	ons: me +	⊦ ins	st.)						

5.0 : selective protection (long time + inst.)
5.0 : selective + earth-fault protection
(long time + short time + inst. + earth-fault)
7.0 : selective + earth-leakage protection
(long time + short time + inst. + earth-leakage)

OF - ON/OFF indication conta	acts		
Standard	4 OF 6 A-240 V AC (10 A-240 V	AC and low-level	for NW)
Alternate	1 OF low-level for NT	Max. 4	qty
Additional	1 block of 4 OF for NW	Max. 2	qty
EF - combined "connected/cl	osed" contacts		
	1 EF 6 A-240 V AC for NW	Max. 8	qty
	1 EF low-level for NW	Max. 8	qty
SDE - "fault-trip" indication c	ontact		
Standard	1 SDE 6 A-240 V AC		
Additional	1 SDE 6 A-240 V AC	1 SDE low le	vel
Programmable contacts	2 M2C contacts	6 M6C conta	cts
Carriage switches	Low level	6 A-240 V A0	C
CE - "connected" position	Max. 3 for NW/NT		qty
CD - "disconnected" position	Max. 3 for NW - 2 for NT		qty
CT - "test" position	Max. 3 for NW - 1 for NT		qty
AC - NW actuator for 6 CE - 3 0	CD - 0 CT additional carriage swit	ches	qty
Remote operation			
Remote ON/OFF	MCH - gear motor		v
	XF - closing voltage release		v
	MX - opening voltage release		v
	PF - "ready to close" contact	Low level	<u> </u>
		6 A-240 V A0	C (
	BPFE - electrical closing pushbu	utton	
	Res - electrical reset option		v
	RAR - automatic reset option		
Remote tripping	MN - undervoltage release		V
	<b>R</b> - delay unit (non-adjustable)		
	Res - adjustable delay unit		
	2 nd MX - shunt release		v
Locking			- <u>_</u>
VBP - ON/OFF pushbutton lo	cking (by transparent cover + pa	adlocks)	
		-	
OFF position locking:			
OFF position locking: VCPO - by padlocks	Keyock kit (w/o keylock)	Profalux	Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks	Keyock kit (w/o keylock)	Profalux	Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identicel keylocks_1 key	Profalux Profalux	Ronis Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocka different keyo (NW)	Profalux Profalux Profalux	Ronis Ronis Ronis Bonis
OFF position locking: VCPO - by padlocks VSPO - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW)	Profalux Pro	Ronis Ronis Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock)	Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) ected" position: Keyock kit (w/o keylock)	Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) cted" position: Keyock kit (w/o keylock)	Profalux Profalux Profalux Profalux Profalux Profalux Strik Profalux Profal	Ronis Ronis Ronis Ronis Castell
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key	Profalux Profalux Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalu	Ronis Ronis Ronis Ronis Castell Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylock different keyo	Profalux Pro	Ronis Ronis Ronis Ronis Castell Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Ortigene generated (discovery of the sector)	Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected	Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VPEC - door interlock	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VPEC - door interlock VPOC - racking interlock	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Higher Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock IPA - cable-type door interlock	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>cted" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Higher Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis is
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VPEC - door interlock VPOC - racking interlock IPA - cable-type door interlock VDC - mismatch protection	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>cted" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Higher Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VPEC - door interlock VPOC - racking interlock IPA - cable-type door interlock VDC - mismatch protection VIVC - shutter position indication	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) Ected" position: Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) ected" position: Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for I	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>cted" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for I rge before breaker removal for Northere	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Ronis Castell Ronis Ronis k sis sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar Accessories	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>cted" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for I rige before breaker removal for NW	Profalux Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Ronis Castell Ronis Ronis k sis sis
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar Accessories VO - safety shutters on chassis	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>cted" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for I rge before breaker removal for NW 5 for NT and NW	Profalux Profalux Profalux Profalux Profalux Wrofalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Pro	Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis is
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar Accessories VO - safety shutters on chassis CDM - mechanical operation co	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for 1 rge before breaker removal for NW et for NT and NW punter NT, NW	Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Castell Ronis Ronis Ronis k sis is
OFF position locking: VCPO - by padlocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPOC - racking interlock VPOC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar Accessories VO - safety shutters on chassis CDM - mechanical operation co CB - auxiliary terminal shield for	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for 1 rge before breaker removal for NW et or NT and NW punter NT, NW or chassis NT, NW	Profalux Profalux Profalux Profalux Kirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Castell Ronis Ronis k sis is
OFF position locking: VCPO - by padlocks VSPO - by keylocks VSPO - by keylocks Chassis locking in "disconne VSPD - by keylocks VPEC - door interlock VPCC - racking interlock VPCC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio IBPO - racking interlock betwee DAE - automatic spring dischar Accessories VO - safety shutters on chassis CDM - mechanical operation co CB - auxiliary terminal shield fo CC - arc chute cover for fixed N	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for NW en crank and NW punter NT, NW or chassis NT, NW NT	Profalux Profalux Profalux Profalux Wirk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Castell Ronis Ronis k sis is
OFF position locking: VCPO - by padlocks VSPO - by keylocks VSPO - by keylocks VSPD - by keylocks VSPD - by keylocks VPEC - door interlock VPCC - racking interlock VPCC - racking interlock VDC - mismatch protection VIVC - shutter position indicatio BPO - racking interlock betwee DAE - automatic spring dischar Accessories VO - safety shutters on chassis CDM - mechanical operation co CB - auxiliary terminal shield fo CC - arc chute cover for fixed N CDP - escutcheon NT, NW	Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys (NW) <b>ected" position:</b> Keyock kit (w/o keylock) 1 keylock 2 identical keylocks, 1 key 2 keylocks, different keys Optional connected/disconnected On rig On left on and locking for NW en crank and OFF pushbutton for I rge before breaker removal for NW en or nand NW ounter NT, NW or chassis NT, NW NT	Profalux Profalux Profalux Profalux Profalux Virk Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalux Profalu	Ronis Ronis Ronis Castell Ronis Ronis k sis is

NW fixed

Mini test kit

Brackets for mounting

Test kits

On backplates

Portable test kit

Schneider Electric Industries SAS

89, boulevard Franklin Roosevelt F - 92500 Rueil-Malmaison (France) Tel : +33 (0)1 41 29 85 00

http://www.schneider-electric.com

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.

 $\overset{\text{(b)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{\text{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset{(c)}}{\overset$ 

Design: Schneider Electric - Ameg Photos: Schneider Electric Printed: